

**SUZUKI**

**SF413**

**SUPPLEMENTARY SERVICE MANUAL**

USE THIS SUPPLEMENTARY SERVICE MANUAL  
WITH MANUALS MENTIONED IN FOREWORD  
OF THIS MANUAL

**SUZUKI**  
*Caring for Customers*

99501-63B30-01E

(英)

# IMPORTANT

## WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the words **WARNING**, **CAUTION**, and **NOTE** have, special meanings. Pay special attention to the messages highlighted by these signal words.

### **WARNING:**

Indicates a potential hazard that could result in death or injury.

### **CAUTION:**

Indicates a potential hazard that could result in vehicle damage.

### **NOTE:**

Indicates special information to make maintenance easier or instructions clearer.

## FOREWORD

This SUPPLEMENTARY SERVICE MANUAL contains those items on the structure, service procedures, etc. that were modified for the FACE-LIFT model produced in and after June 1991. Its applicability by body numbers is as follows.

For European/ Australian markets	For other markets
(X) JSAAEA35S00140001 (X)~	AA34S-200001 ~
(X) JSAAEB35S00140001 (X)~	AB34S-200001 ~
(X) JSAAEF35S00140001 (X)~	AF34S-200001 ~
(X) JSAAEH35S00140001 (X)~	

When servicing a car with a body number after the above listed numbers, refer to this Supplementary Service Manual first.

If necessary information is not found in this Supplementary Service Manual, refer to respective Supplementary Service Manuals specified below for Electronic Fuel Injection, 4WD and Sedan models and also below specified Service Manual for other models.

### RELATED SERVICE MANUALS :

- SF413 Service Manual  
99500-63B01
- SF413 Supplementary Service Manual for Electronic Fuel Injection system  
99501-63B01
- SF413 Supplementary Service Manual for Sedan  
99501-63B10
- SF413 Supplementary Service Manual for 4WD  
99501-63B20

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others. Therefore, note that illustrations may differ from the vehicle being actually serviced. The right is reserved to make changes at any time without notice.

TABLE OF CONTENTS	SECTION
<b>GENERAL INFORMATION</b> Maintenance and Lubrication	<b>0B</b>
<b>HEATING AND AIR CONDITIONING</b> Heating and Ventilation	<b>1A</b>
<b>BUMPER AND SHEET METAL</b>	<b>2</b>
<b>STEERING, SUSPENSION WHEEL AND TIRES</b> Power Steering (P/S) System (If equipped)	<b>3</b> <b>3B1</b>
Steering Wheel and Column	<b>3C</b>
<b>BRAKES</b>	<b>5</b>
<b>ENGINE</b> Engine Mechanical	<b>6</b> <b>6A</b>
Carburetor	<b>6D</b>
Electronic Fuel Injection System	<b>6E</b>
Ignition System (For Carburetor Car)	<b>6F</b>
Ignition System (For Car with Fuel Injection Model)	<b>6F1</b>
Cranking System (1.2 kW and 1.4 kW Type)	<b>6G1</b>
Engine Exhaust	<b>6K</b>
<b>TRANS.</b> Manual Transmission	<b>7A</b>
Automatic Transmission	<b>7B</b>
<b>BODY ELECTRICAL SYSTEM</b>	<b>8</b>
<b>BODY SERVICE</b>	<b>9</b>

## SUZUKI MOTOR CORPORATION

TECHNICAL DEPARTMENT  
AUTOMOBILE SERVICE DIVISION

## SECTION 0B

# MAINTENANCE AND LUBRICATION

**NOTE:**

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

### CONTENTS

MAINTENANCE SCHEDULE ..... 0B-1  
 MAINTENANCE SERVICE ..... 0B-1  
 RECOMMENDED FLUIDS AND LUBRICANTS ..... 0B-1

## MAINTENANCE SCHEDULE

Interval: This interval should be judged by odometer reading or months, whichever comes first.	This table includes services as scheduled up to 48,000 miles (80,000 km) mileage. Beyond 48,000 miles (80,000 km), carry out the same services at the same intervals respectively.								
	Km (x 1,000)	10	20	30	40	50	60	70	80
	Miles (x 1,000)	6	12	18	24	30	36	42	48
	Months	6	12	18	24	30	36	42	48
<b>CHASSIS AND BODY</b>									
Power steering (P/S) system									

**NOTE:**

"|": Inspect and correct or replace if necessary

## MAINTENANCE SERVICE

### POWER STEERING (P/S) SYSTEM INSPECTION

- 1) Visually check power steering system for leaks or damage.  
Repair or replace defective parts, if any.
- 2) Remove oil tank cap and check fluid level indicated on level gauge, which should be between MAX and MIN marks. If it is lower than MIN, fill fluid up to MAX mark.

**NOTE:**

Fluid level should be checked when fluid is cool.

- 3) Make sure that power steering belt deflects 8 – 10 mm (0.31 – 0.39 in.) with 10 kg (22 lb) thumb pressure applied on the midway point between the pulleys.  
Also, visually check the belt for damage. If necessary, have the belt adjusted or replaced.

## RECOMMENDED FLUIDS AND LUBRICANTS

Power steering fluid	Automatic transmission fluid DEXRON-II
----------------------	----------------------------------------



**SECTION 1A****HEATER AND VENTILATION****NOTE:**

- For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.
- The blower motor installing position is different between the right-hand side steering car and the left-hand side steering car. In either car, the motor is installed on assistant seat side. The illustration in this manual shows the left-hand side steering car.


**CONTENTS**

<b>GENERAL DESCRIPTION</b> .....	1A-2	<b>ON-CAR SERVICE</b> .....	1A-4
Heater .....	1A-2	Heater Control Cables .....	1A-4
Heater Control Operation .....	1A-3	Heater Unit .....	1A-5
		Rear Duct .....	1A-7

## GENERAL DESCRIPTION

### HEATER

The heater and ventilation of this car consist of following parts.



1. Side ventilator outlet
2. Side defroster outlet
3. Center ventilator outlet
4. Floor outlet
5. Front defroster outlet
6. Heater unit
7. Air duct
8. Blower motor unit
9. Control lever
10. Defroster nozzle
11. Side demister duct
12. Center ventilator duct
13. Side ventilator duct
14. Outside air
15. Inside air

Fig. 1A-1

## HEATER CONTROL OPERATION

Heater control panel is as shown below.




Fig. 1A-2

## ON-CAR SERVICE

### HEATER CONTROL CABLES




Fig. 1A-3

#### REMOVAL

- 1) Remove console box.
- 2) Remove ashtray and ashtray upper plate.
- 3) Remove cigarette lighter.
- 4) Remove radio. (If equipped)
- 5) Remove control lever knobs and control panel garnish.
- 6) Remove control panel.
- 7) Disconnect lead wire from blower motor switch at coupler.
- 8) Disconnect control cables from blower motor unit and heater unit.
- 9) Remove control lever ass'y.
- 10) Disconnect control cables from control lever.




Fig. 1A-4

#### INSTALLATION

Install control cables by reversing removal procedure, noting the following point. After installing control cables to control levers, move control levers to such position as to pull cables fully, then connect and clamp control cables to heater unit and blower motor unit levers as shown.




Fig. 1A-5

#### NOTE:

After installing control cables, be sure that control knobs move smoothly and stop at proper position.

## HEATER UNIT

### REMOVAL

1. Disconnect battery (-) leadwire, drain coolant and disconnect 2 water hoses from heater unit.
2. Remove instrument panel as follows.
  - 1) Remove console box.
  - 2) Disconnect wires and cables from heater and blower unit.
  - 3) Remove steering wheel, steering column unit and steering joint upper bolt. (Refer to SECTION 3C.)
  - 4) Remove front speaker covers and front speakers (if equipped).
  - 5) Disconnect speedometer cable and remove speedometer ass'y.
  - 6) Remove engine hood opener.
  - 7) Remove instrument panel member mounting bolts.




Fig. 1A-6

- 8) Remove instrument panel together with instrument panel member.




Fig. 1A-7

3. Remove heater unit.




Fig. 1A-8

4. Remove heater unit clips and screws to separate heater unit.




Fig. 1A-9

5. Pull out heater core from unit.




Fig. 1A-10

## INSTALLATION

Install heater unit by reversing removal procedure, noting the following items.

- 1) Adjust control cables. (Refer to p. 1A-4)
- 2) Fill coolant to radiator.

### NOTE:

- When installing each part, be careful not to catch any cable or wiring harness.
- When installing steering shaft to steering shaft joint, set front wheels (right and left) in the straight ahead state and check to make sure that steering wheel is also in that state.
- When fastening steering column ass'y to car body, start with lower nuts on column and then upper nuts. Be sure to tighten them to specified torque. (Refer to SECTION 3C.)


**REAR DUCT (If equipped)**

Fig. 1A-11

**DESCRIPTION**

Through the rear duct, air is drawn into the rear seat foot space.

**REMOVAL**

1) Remove front seats.

**NOTE:**

If seat belt warning light is provided, disconnect its switch wire.

2) Remove dash side trim and side sill front scuff from both sides (right and left).




Fig. 1A-12

3) Remove console box.

4) Loosen instrument panel member support mounting screw/bolt.

Then move support in arrow direction as shown below.




Fig. 1A-13

5) Remove rear No. 2 duct.

- 6) Take off floor carpet till rear duct is totally exposed.
- 7) Remove rear No. 1 duct and rear hoses.

**INSTALLATION**

Reverse removal sequence to install rear duct.  
But note following point.

Refer to Section 9 for tightening torque for front seat mounting bolts.



**SECTION 2**

**BUMPERS AND SHEET METAL**

**NOTE:**

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

**BUMPERS** ..... 2-1

**BUMPERS**

**NOTE:**

Fasteners are important attaching parts in that they could affect the performance of vital components and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary.

Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of these parts.

## FRONT BUMPER




Fig. 2-1

### REMOVAL

- 1) Remove front fender lining.
- 2) Remove front turn signal lamps.
- 3) Remove bumper fitting bolts and nuts shown in Fig. 2-2.




Fig. 2-2

### INSTALLATION

- 1) Slide bumper onto bumper side attachments on both fenders.
- 2) Use five bolts and four nuts to fix bumper in position.

- 4) Slide bumper (with bumper member) forward to remove it.

**REAR BUMPER (For Hatch-Back model)**




Fig. 2-3

**REMOVAL**

- 1) Remove rear garnish and then detach rear combination lights (R & L) from body without disconnecting coupler of combination rights.
- 2) Disconnect coupler of licence plate light.




Fig. 2-4




Fig. 2-5

## 2-4 BUMPERS AND SHEET METAL

- 3) Remove rear bumper bolts and nuts shown in figure below.

To remove nut "A", removal of back panel inner trim is prerequisite.




Fig. 2-6

- 4) Temporarily install rear combination lights in position with screws.
- 5) Slide bumper (with bumper member) backward to remove it.





Fig. 2-7

## INSTALLATION

- 1) Insert side sliders (R & L) of fenders and tighten bumper bolts and nuts.
- 2) Connect coupler of licence plate light securely.
- 3) Install combination lights (R & L) and then rear garnish.

**REAR BUMPER (For Sedan model)**



- 1. Rear upper bumper
- 2. Rear lower bumper
- 3. Rear bumper member
- 4. Bumper absorber (If equipped)
- 5. Bumper attachment
- 6. Bumper side slider
- 7. Bumper side holder
- 8. Member seal
- 9. Bumper bolt

Fig. 2-8

**REMOVAL**

- 1) Remove mud flaps. (If equipped)
- 2) Remove bumper fitting nuts shown in Fig. 2-2.




Fig. 2-9

**INSTALLATION**

- 1) Slide bumper onto side attachments on both fenders.
- 2) Install removed parts in reverse order of removal.

- 3) Slide bumper (with bumper member) backward to remove it.

**SECTION 3B1****POWER STEERING (P/S) SYSTEM**  
**(If equipped)****NOTE:**

- All steering gear fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during re-assembly to assure proper retention of these parts.
- For items related to the rack and pinion, if not included in this section, refer to SECTION 3B MANUAL RACK AND PINION of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

<b>GENERAL DESCRIPTION</b> .....	3B1- 2
<b>CONSTRUCTION AND OPERATION</b> .....	3B1- 4
Steering Gear Box .....	3B1- 4
Power Steering (P/S) Pump .....	3B1- 8
<b>DIAGNOSIS</b> .....	3B1-10
<b>ON CAR SERVICE</b> .....	3B1-12
Inspection .....	3B1-12
Steering wheel play .....	3B1-12
Steering force .....	3B1-12
Power steering fluid level .....	3B1-13
Power steering belt tension .....	3B1-13
Power steering belt tension adjustment .....	3B1-13
Idle up system .....	3B1-13
Fluid leakage .....	3B1-14
Hydraulic pressure in P/S circuit .....	3B1-15
Steering rack boot .....	3B1-16
Tie rod end boot .....	3B1-17
Steering shaft joint .....	3B1-17
Air Breeding Procedure .....	3B1-17
Remove and Install Tie Rod End .....	3B1-17
Remove and Install Power Steering Gear Box .....	3B1-19
Remove and Install Power Steering Pump .....	3B1-26
<b>SPECIAL TOOLS</b> .....	3B1-32

## GENERAL DESCRIPTION

The power steering (P/S) system in this car reduces the driver's effort needed in turning the steering wheel by utilizing the hydraulic pressure generated by the power steering (P/S) pump which is driven by the engine.

It is an integral type with the rack and pinion gears and the control valve unit, hydraulic pressure cylinder unit all built in the steering gear box.

There are two types of this system: one for the RH steering model and the other for the LH steering model.

### For LH-steering model




Fig. 3B1-1-1 Power Steering System Layout




Fig. 3B1-1-2 Hydraulic Pressure Circuit

For RH-steering model




Fig. 3B1-2-1 Power Steering System Layout




Fig. 3B1-2-2 Hydraulic Pressure Circuit



# CONSTRUCTION AND OPERATION

## STEERING GEAR BOX

- For LH steering model

The steering gear box consists of two sections: one including a cylinder and the other a valve. Main components of the cylinder section are a gear box, a rack and a tube and those of the valve section are a valve case, a sleeve and a stub shaft. The sleeve is linked with the pinion through a pin and the valve and stub shaft are integrated into one unit. Then the pinion and the stub shaft are linked to each other by means of the torsion bar.

Thus, when the stub shaft moves, the valve changes its position, thereby switching the hydraulic passage from the pump to the cylinder to help steering operation.

When turning the steering wheel feels heavy due to P/S fluid leakage or for some other reason (i.e., when in the manual steering mode), the stub shaft and pinion are in direct linkage and the force is output directly through the pinion and rack.




Fig. 3B1-3-1 Steering Gear and Valve Unit

**WHEN STEERING WHEEL HELD AT STRAIGHT POSITION**

When the steering wheel is not turned, the valve is held at the neutral position by the torsion bar and the fluid from the pump flows through the valve back to the tank.




Fig. 3B1-4 Hydraulic Pressure Circuit When Steering Wheel at Straight

**WHEN STEERING WHEEL TURNED (to the right)**

Turning the steering wheel clockwise will cause the stub shaft to turn clockwise, twisting the torsion bar. Then the valve is switched to allow the fluid pressure to be applied to the cylinder which then pushes the rack.

As the rack moves, the pinion turns clockwise to actuate the torsion bar which then causes the valve to return to the neutral position. This is called the feed back operation of the power steering system.




Fig. 3B1-5 Operation When Steering Wheel Turned to the Right

• For RH steering model

The steering gear box contains a gear, valve and cylinder sections. The gear and valve section consist of a valve case, spool valve, lever, pinion and other parts. There are two bearings to support the pinion in the gear case whose section is an oblong hole so that the bearing and pinion shaft can move to the right and left. And as the pinion shaft moves, the spool valve moves in the same direction, for they are connected. Such valve movement opens and closes the hydraulic pressure passage from the pump to either right or left cylinder port to assist the steering operation.




Fig. 3B1-3-2 Steering Gear and Valve Unit

**WHEN STEERING WHEEL HELD AT STRAIGHT POSITION**

When the steering wheel is not turned in either way, the spool valve is kept at its neutral position by the spring force and the hydraulic pressure from the pump passes through the short circuit.




Fig. 3B1-4 Hydraulic Pressure Circuit When Steering Wheel at Straight Position

**WHEN STEERING WHEEL TURNED (to the right)**

Turning the steering wheel to the right causes the pinion shaft to move to the right by the amount equal to the play in the oblong hole provided in the periphery of the bearing. At the same time, the spool valve moves to the right through the lever, allowing hydraulic pressure to flow into the cylinder and push the rack shaft. When the force in the rotation direction of the pinion is released, the spool valve is returned to its neutral position by the reaction of the spring, thus shutting off the hydraulic pressure to the cylinder.




Fig. 3B1-5 Operation When Steering Wheel Turned to the Right

## POWER STEERING (P/S) PUMP

The power steering pump is a vane type and is driven by the V-ribbed belt from the crankshaft.




Fig. 3B1-6 Components of P/S Pump

Model		Vane type
Discharge rate		5.1 cm <sup>3</sup> /rev
Hydraulic pressure control	Hydraulic pressure	4900 kPa 50 kg/cm <sup>2</sup> 711 psi
	Control device	Flow control valve Relief valve
Specified fluid		DEXRON-II A/T fluid
Capacity		600 – 650 cm <sup>3</sup> (1.27/1.06 – 1.37/1.14 US/Imp. pt)
Idle-up system		Idle-up function performed when hydraulic pressure in P/S pump rises higher than following value. 1470 – 1960 kPa 15 – 20 kg/cm <sup>2</sup> 213 – 284 psi




Fig. 3B1-7 P/S Pump Layout (Vehicle with A/C)

### FLOW CONTROL VALVE

As the discharge rate of the P/S pump increases in proportion to the pump revolution speed, a flow control valve is added to control it so that the optimum amount of fluid for steering operation is supplied according to the engine speed (driving condition).

Described below is its operation at different engine speed.

#### When Idling

The fluid discharged from the pump is supplied through the clearance around the rod in orifice A<sub>1</sub> to the gear box.




Fig. 3B1-8 Operation of Flow Control Valve (When Idling)

#### When Running at Low Speed

As the engine speed rises, the pump discharge rate increases and causes a pressure difference to occur between both ends of the orifice ( $P_1 - P_2$ ). Thus the pressure exceeding the flow control spring force pushes the flow control valve to the right in the below figure, making the opening in the orifice narrower through which only a necessary amount of fluid is fed to the gear box and the excess fluid is returned to the pump.




Fig. 3B1-9 Operation of Flow Control Valve (When Running at Low Speed)

#### When Running at High Speed

As the engine speed rises higher, opening in the orifice is made narrower and fluid flow to the gear box reduces. As a result, hydraulic pressure application is slow at the start of the steering wheel turn. This provides straight-ahead stability to suit the driving condition with the steering wheel operated near its neutral position.




Fig. 3B1-10 Operation of Flow Control Valve (When Running at High Speed)

### RELIEF VALVE

The relief valve located in the flow control valve controls the maximum hydraulic pressure.

The steel ball in the relief valve is under the hydraulic pressure in the circuit coming through orifice A<sub>2</sub>. When the steering wheel is turned and the hydraulic pressure increases higher than 4900 kPa (50 kg/cm<sup>2</sup>, 711 psi), it compresses the relief spring to push the steel ball which then allows the fluid to flow to the P/S pump.

Such relief valve operation causes a pressure difference to occur between chambers A and B. Then the flow control valve moves to the right to make opening in orifice A<sub>1</sub> narrower, maintaining the hydraulic pressure constant.




Fig. 3B1-11 Operation of Relief Valve

## DIAGNOSIS

Condition	Possible Cause	Correction
<b>Steering wheel feels heavy (at low speed)</b>	<ol style="list-style-type: none"> <li>1. Fluid deteriorated, low viscosity, different type of fluid mixed</li> <li>2. Pipes or hoses deformed, air entering through joint</li> <li>3. Insufficient air purging from P/S circuit</li> <li>4. P/S belt worn, lacking in tension</li> <li>5. Tire inflation pressure excessively low</li> <li>6. Front end alignment maladjusted</li> <li>7. Steering wheel installed improperly (twisted)</li> <li>8. Bind in tie rod or tie rod end ball joint</li> <li>9. P/S pump hydraulic pressure fails to increase</li> <li>10. P/S pump hydraulic pressure increases but slowly</li> </ol> <p><b>NOTE:</b> Make sure to warm up engine fully before measuring hydraulic pressure from pump.</p>	<p>Replace fluid.</p> <p>Replace defective part.</p> <p>Purge air.</p> <p>Adjust belt tension or replace belt as necessary.</p> <p>Inflate tire.</p> <p>Check and adjust front end alignment.</p> <p>Install steering wheel correctly.</p> <p>Replace defective part.</p> <p>Replace P/S pump.</p> <p>Replace P/S pump.</p>
<b>Steering wheel feels heavy momentarily when turning it to the left (right)</b>	<ol style="list-style-type: none"> <li>1. Air drawn in due to insufficient amount of fluid</li> <li>2. Slipping P/S belt</li> <li>3. Refer to check items 9 and 10 in above section</li> </ol>	<p>Add fluid and purge air.</p> <p>Adjust belt tension or replace belt as necessary.</p>
<b>No idle-up</b>	<ol style="list-style-type: none"> <li>1. P/S pressure switch defective</li> </ol>	<p>Replace P/S pressure switch.</p>
<b>Poor recovery from turns</b>	<p><b>NOTE:</b> To check steering wheel for recovery, with car running at 22 mile/h (35 km/h), turn it 90° and let it free. It should return more than 60°.</p> <ol style="list-style-type: none"> <li>1. Deformed pipes or hoses</li> <li>2. Steering column installed improperly</li> <li>3. Front end alignment maladjusted</li> <li>4. Ball joints binding</li> <li>5. Refer to items 9 and 10 in above section</li> </ol>	<p>Replace defective part.</p> <p>Install steering column correctly.</p> <p>Check and adjust front end alignment.</p> <p>Replace defective part.</p>

Condition	Possible Cause	Correction
<b>Vehicle pulls to one side during straight driving</b>	<ol style="list-style-type: none"> <li>1. Low or uneven tire inflation pressure</li> <li>2. Front end alignment maladjusted</li> <li>3. Malfunction of control valve in gear box</li> <li>4. Refer to check items 9 and 10 in previous page</li> </ol>	<p>Inflate tires to proper pressure or adjust right &amp; left tires inflation pressure.</p> <p>Check and adjust front end alignment.</p> <p>Replace gear box.</p>
<b>Steering wheel play is large and vehicle wanders</b>	<ol style="list-style-type: none"> <li>1. Loose steering shaft nut</li> <li>2. Loose linkage or joints</li> <li>3. Loose gear box fastening bolt</li> <li>4. Front wheel bearing worn</li> </ol>	<p>Retighten.</p> <p>Retighten.</p> <p>Retighten.</p> <p>Replace wheel bearing.</p>
<b>Oil leakage</b>	<ol style="list-style-type: none"> <li>1. Loose joints of (hydraulic pressure) pipes and hoses</li> <li>2. Deformed or damaged pipes or hoses</li> </ol>	<p>Retighten.</p> <p>Replace defective part.</p>
<b>Abnormal noise</b>	<p><b>NOTE: (For RH steering model)</b> Some sound may be heard through steering column when turning steering wheel with vehicle at a stop but it is not an abnormal noise but operating sound of valve in gear box.</p> <ol style="list-style-type: none"> <li>1. Air drawn in due to insufficient amount of fluid</li> <li>2. Air mixed into fluid from pipes or hoses</li> <li>3. Slipping (loose) P/S belt</li> <li>4. Worn P/S belt</li> <li>5. Loose gear box fastening bolt</li> <li>6. Loose linkage or joints</li> <li>7. Pipes or hoses in contact with part of vehicle body</li> <li>8. Vanes of P/S pump defective</li> <li>9. Malfunction of control valve in gear box</li> <li>10. Bearing of P/S pump shaft defective</li> </ol>	<p>Add fluid and purge air.</p> <p>Replace pipes or hoses.</p> <p>Adjust belt tension.</p> <p>Replace belt.</p> <p>Retighten bolts.</p> <p>Retighten.</p> <p>Install pipes and hoses correctly.</p> <p>Replace pump.</p> <p>Replace gear box.</p> <p>Replace pump.</p>



## ON CAR SERVICE

### INSPECTION

#### STEERING WHEEL PLAY

- With engine stopped, check steering wheel play as follows. Move steering wheel from its straight-ahead position lightly in both directions and measure distance along its circumference it must be turned before wheels start to move. It should be within below specification.

Steering wheel play	Less than 30 mm (1.2 in.)
---------------------	------------------------------

- Check steering wheel for looseness or rattle by trying to move it in its shaft direction and lateral direction.




Fig. 3B1-12 Steering Wheel Play




Fig. 3B1-13 Checking Fluid Temperature

- 4) With engine idling, measure steering force by pulling spring balancer hooked on steering wheel in tangential direction.

Steering force	Less than 4.0 kg (8.8 lb)
----------------	------------------------------




Fig. 3B1-14 Checking Steering Force

#### STEERING FORCE

- 1) Place vehicle on level road and set steering wheel at straight-ahead position.
- 2) Check that tire inflation pressure is as specified. (Refer to tire placard).
- 3) Start engine and keep it running till power steering fluid is warmed to 50 to 60°C (122 to 140°F).

**POWER STEERING FLUID LEVEL**

With engine stopped, remove oil tank cap and check fluid level indicated on level gauge, which should be between MAX and MIN marks. If it is lower than MIN, fill fluid up to MAX mark.

**NOTE:**

- Be sure to use A/T fluid DEXRON-II.
- Fluid level should be checked when fluid is cool.





Fig. 3B1-15 Checking P/S Fluid Level

**POWER STEERING BELT TENSION**

- Check that belt is free from any damage and properly fitted in pulley groove.
- Check belt tension by measuring how much it deflects when pushed at intermediate point between P/S pump pulley and crank pulley with about 10 kg (22 lb) force.

Deflection of P/S belt (A)	8 – 10 mm (0.31 – 0.39 in.)
----------------------------	--------------------------------



- 1. P/S pump pulley
- 2. A/C compressor pulley (if equipped)
- 3. Crankshaft pulley
- 4. Tension pulley
- 5. Water pump pulley
- 6. Generator

Fig. 3B1-16 Checking P/S Belt Tension

**POWER STEERING BELT TENSION ADJUSTMENT**

1. Remove splash cover and loosen tension nut.
2. Adjust belt tension. With A/C equipped vehicles, turning tension bolt counterclockwise causes pulley to rise, increasing belt tension. With A/C non-equipped vehicles, turning tension bolt clockwise causes pulley to lower, increasing belt tension. In both cases, turning tension bolt in the other way decreases belt tension.

Be sure to tighten tension nut after adjusting belt tension.




Fig. 3B1-17 Adjusting P/S Belt Tension

**IDLE UP SYSTEM**

With air conditioner turned OFF (if equipped), turn steering wheel and check that engine idling speed is not slowed down even when load is imposed on engine by P/S pump.

### FLUID LEAKAGE

Start engine and turn steering wheel fully to the right and left so that maximum hydraulic pressure is provided. Then visually check gear box, P/S pump and oil tank themselves and each joint of their connecting pipes for leakage.

**CAUTION:** Never keep steering wheel turned fully for longer than 10 seconds.




Fig. 3B1-18 Check for Fluid Leakage

### HYDRAULIC PRESSURE IN P/S CIRCUIT

1. After cleaning joint of high pressure hose and oil pump thoroughly, disconnect it and install oil pressure gauge, oil pressure gauge attachment and hose (Spare part).

**CAUTION:**

Take care not to cause damage to air-conditioner condenser during service operation.




Fig. 3B1-19 Setting Oil Pressure Gauge

2. Bleed air. (Refer to AIR BLEEDING PROCEDURE.)
3. With engine idling, turn steering wheel and warm up engine till temperature of fluid in tank rises to 50 – 60°C (122 – 140°F).




Fig. 3B1-20 Checking Fluid Temperature

#### 4. Back pressure check

Check back pressure by measuring hydraulic pressure with engine idling and hands off steering wheel.

Back pressure	Lower than 980 kPa (10 kg/cm <sup>2</sup> , 142 psi)
---------------	------------------------------------------------------------

When back pressure is higher than 980 kPa (10 kg/cm<sup>2</sup>, 142 psi), check control valve and piping for clogging.




Fig. 3B1-21 Checking Back Pressure

5. Relief pressure check

- Increase engine speed to about 1,500 r/min (rpm). Close gauge valve gradually while watching pressure increase indicated by gauge and take reading of relief pressure (maximum hydraulic pressure).

Relief pressure	4400 – 6400 kPa (45 – 65 kg/cm <sup>2</sup> ) (640 – 924 psi)
-----------------	---------------------------------------------------------------------

- When it is higher than 6400 kPa (65 kg/cm<sup>2</sup>, 924 psi), possible cause is malfunction of relief valve.  
Replace steering gear box comp.
- When it is lower than 4400 kPa (45 kg/cm<sup>2</sup>, 640 psi), possible cause is either failure of P/S pump or settling of relief valve spring.

**CAUTION:**  
Be sure not to close gauge valve for longer than 10 seconds.




Fig. 3B1-22 Relief Pressure Check

Next, open gauge valve fully and increase engine speed to about 1,500 r/min. Then turn steering wheel to the left or right fully and take reading of relief pressure.

Relief pressure	4400 – 6400 kPa (45 – 65 kg/cm <sup>2</sup> ) (640 – 924 psi)
-----------------	---------------------------------------------------------------------

- When it is lower than 4400 kPa (45 kg/cm<sup>2</sup>, 640 psi), possible cause is failure in steering gear box.  
Replace gear box.

**CAUTION:**  
Be sure not to hold steering wheel at fully turned position for longer than 10 seconds.




Fig. 3B1-23 Relief Pressure Check

**STEERING RACK BOOT**

Check boot for crack and damage which, if any, means possibility of rusty gear, entry of dust or lack of grease. Also, check if any of such faulty conditions exists.




Fig. 3B1-24

**TIE ROD END BOOT**

Check boot for crack and damage and if any, replace it with a new one.




Fig. 3B1-25

**STEERING SHAFT JOINT**

Check each shaft joint for wear, breakage and any other damage and if any, replace it with a new one.




Fig. 3B1-26

**AIR BLEEDING PROCEDURE**

1. Jack up the front end of car and apply rigid rack.
2. Fill oil tank with fluid up to specified level. Then turn steering wheel to the right and left for 3 or 4 times.
3. After running engine at idling speed for 3 to 5 seconds, stop it and add fluid to satisfy specification.
4. With engine stopped, turn steering wheel to the right and left as far as it stops, repeat it a few times and fill fluid to specified level.

5. With engine running at idling speed, repeat stop-to-stop turn of steering wheel till all foams in oil tank are gone.

**NOTE:**

Make sure to bleed air completely. If air remains in fluid, P/S pump may make humming noise or steering wheel may feel heavy.

6. Finally check to make sure that fluid is filled to specified level.

**REMOVE AND INSTALL TIE ROD END****REMOVAL**

1. Jack up vehicle and remove wheel.
2. Remove split pin and tie rod end castle nut.




Fig. 3B1-27 Tie Rod End

3. Using special tool, remove tie rod end from knuckle.




Fig. 3B1-28 Removing Tie Rod End

- To facilitate adjustment after installation, put a mark on tie rod thread indicating position of tie rod end lock nut. Then loosen lock nut and remove tie rod end from tie rod.




Fig. 3B1-29

**INSPECTION**

**Tie-rod End Ball Joint**

Inspect for play in tie-rod end ball joint. If found defective, replace.




Fig. 3B1-30 Inspection of Ball Joint

**INSTALLATION**




Fig. 3B1-31

- Install tie rod end lock nut and tie rod end to tie rod. Tighten lock nut to mark on tie rod thread.
- Install tie rod end to knuckle. Tighten castle nut till holes for split pin are aligned but within specified torque range.

Tightening torque	N-m	kg-m	lb-ft
	30 - 55	3.0 - 5.5	22.0 - 39.5

- Bend split pin as shown in figure.




Fig. 3B1-32 Tightening Castle Nut

- Check that proper amount of toe-in is obtained. (Refer to FRONT WHEEL ALIGNMENT.)
- After confirming proper amount of toe-in, tighten tie rod end lock nut to specified torque.

Tightening torque	N-m	kg-m	lb-ft
	35 - 55	3.5 - 5.5	25.5 - 39.5




Fig. 3B1-33 Tightening Lock Nut

- After installing wheels, lower car and tighten wheel nuts to specified torque.

## REMOVE AND INSTALL POWER STEERING GEAR BOX

### POWER STEERING GEAR BOX COMPONENTS

For LH steering model




Fig. 3B1-34 Exploded View of Power Steering Gear Box



## STEERING GEAR BOX

### Removal

1. Loosen steering shaft upper joint bolt (but it must not be removed).
2. Remove lower joint bolt and separate pinion and lower joint.




Fig. 3B1-35 Removing Joint Bolt

3. Jack up vehicle and remove both right and left wheels.
4. Remove split pin and then remove tie rod castle nut from steering knuckle.




Fig. 3B1-36

5. Using special tool, remove tie rod end from knuckle.




Fig. 3B1-37 Removing Tie Rod End

6. Remove exhaust pipe.
7. For A/T model:  
Remove engine rear torque rod with torque rod bracket.  
For M/T model:  
Disconnect both gear shift control shaft and extension rod at their transmission side.
8. Remove all pipes from steering gear box.




Fig. 3B1-38 Removing Pipes

9. Remove steering gear box mounting bolts and then remove steering gear box from car.

**Installation**

Reverse removal procedure for installation of steering gear box.

	Tightening torque		
	N·m	kg·m	lb·ft
Gear box mounting bolt	20 – 30	2.0 – 3.0	14.5 – 21.5

For specific tightening torque for each part, refer to respective section as indicated in below table.

<ul style="list-style-type: none"> <li>● Rear torque rod bolt</li> <li>● Rear torque rod bracket bolts</li> </ul>	SECTION 6A
<ul style="list-style-type: none"> <li>● Gear shift control shaft bolt/nut</li> <li>● Extension rod nut</li> </ul>	SECTION 7A
<ul style="list-style-type: none"> <li>● Exhaust pipe bolts and nuts</li> </ul>	SECTION 6K
<ul style="list-style-type: none"> <li>● Castle nut</li> <li>● Steering shaft lower joint bolts</li> </ul>	SECTION 3B

- Tighten flare nuts to specified torque.

	N·m	kg·m	lb·ft
"A"	40 – 50	4.0 – 5.0	29.0 – 36.0
"B"	30 – 40	3.0 – 4.0	22.0 – 28.5
"C"	20 – 30	2.0 – 3.0	14.5 – 21.5




Fig. 3B1-38-1

**NOTE:**

After installation, be sure to fill A/T fluid (DEXRON-II) and bleed air.

**OIL SEAL**

**Removal**

1. Remove gear box from car.  
Refer to item STEERING GEAR BOX.
2. As shown below, move boot so that joint section of tie rod and steering rack is exposed.




Fig. 3B1-39

3. Remove tie rod with tie rod end from gear box as shown below.




Fig. 3B1-40

4. Using special tool, remove box.





Fig. 3B1-41

5. Remove O-ring and/or U-packing.

**Installation**

Reverse removal procedure to install oil seals noting following points.

- Apply SUZUKI SUPER GREASE E to O-ring and U-packing of box and install them into groove in box.



*Fig. 3B1-42*

- Tighten box and tie rod to specified torque.

Tightening torque	N·m	kg·m	lb-ft
for box	40 – 50	4.0 – 5.0	29.0 – 36.0
for tie rod	60 – 80	6.0 – 8.0	43.5 – 57.5

- Make sure to use new tie rod lock washer and caulk it after installation.

## For RH steering model




Fig. 3B1-34 Exploded View of Power Steering Gear Box

## STEERING GEAR BOX

### Removal

1. Loosen steering shaft upper joint bolt (but it must not be removed).
2. Remove lower joint bolt and separate pinion and lower joint.




Fig. 3B1-35 Removing Joint Bolt

3. Jack up vehicle and remove both right and left wheels.
4. Remove split pin and then remove tie rod castle nut from steering knuckle.




Fig. 3B1-36

5. Using special tool, remove tie rod end from knuckle.




Fig. 3B1-37 Removing Tie Rod End

6. Remove high pressure pipe and low pressure pipe from steering gear box.




Fig. 3B1-38 Removing Pressure Pipe

7. Remove steering gear box mounting bolts and then remove steering gear box from vehicle.

### Installation

Reverse removal procedure for installation of steering gear box.

	Tightening torque		
	N·m	kg·m	lb·ft
Gear box mounting bolt	20 - 30	2.0 - 3.0	14.5 - 21.7
Castle nut	30 - 55	3.0 - 5.5	21.7 - 39.8
Joint bolt	20 - 30	2.0 - 3.0	14.5 - 21.7

### NOTE:

After installation, be sure to fill A/T fluid (DEXRON-II) and bleed air.

**OIL SEAL****Removal**

1. Remove gear box, tie rod end and tie rod.
2. Using special tool, remove box.




Fig. 3B1-39 Removing Box

3. Remove oil seal by using screwdriver or the like.




Fig. 3B1-40 Removing Oil Seal

**NOTE:**

Use care not to damage pinion shaft with screwdriver.

**Installation**

Reverse removal procedure, noting the following.

- Apply SUZUKI SUPER GREASE E to inside and outside of oil seal lip and press-fit it till its upper surface becomes flush with end face of steering gear case.

**NOTE:**

- Cover serrated part of pinion shaft with vinyl tape or the like so as to prevent damage to oil seal lip.
- Use care not to allow oil seal lip to turn over.




Fig. 3B1-41 Press-fitting Oil Seal

- Apply SUZUKI SUPER GREASE E to O-ring and U-packing of box and install them into groove in box.





Fig. 3B1-42 Installing U-packing

## REMOVE AND INSTALL POWER STEERING PUMP


Components (For LH steering model)



- |                                             |                                   |
|---------------------------------------------|-----------------------------------|
| 1. Power steering pump assembly             | 14. High pressure pipe            |
| 2. Pulley set                               | 15. Low pressure pipe             |
| 3. Connector set                            | 16. Pipe clamp                    |
| 4. Terminal set (Including pressure switch) | 17. High pressure hose            |
| 5. Seal set                                 | 18. Low pressure hose No. 1       |
| 6. Power steering bracket assembly          | 19. Low pressure hose No. 2       |
| 7. Pump bracket                             | 20. Low pressure hose No. 1 clamp |
| 8. Power steering oil tank                  | 21. Low pressure hose No. 2 clamp |
| 9. Oil tank bracket                         | 22. Oil tank stay                 |
| 10. Belt tension pulley                     | 23. Bushing                       |
| 11. Belt tension pulley bolt                | 24. Hose                          |
| 12. Belt tension bolt                       | 25. Clamp                         |
| 13. Power steering belt                     |                                   |

Fig. 3B1-43 P/S Pump Components

Components (For RH steering model)



- |                                           |                                   |
|-------------------------------------------|-----------------------------------|
| 1. Power steering pump assembly           | 14. High pressure pipe            |
| 2. Pulley set                             | 15. High pressure union bolt      |
| 3. Connector set                          | 16. Low pressure pipe             |
| 4. Terminal set (Include pressure switch) | 17. Low pressure union bolt       |
| 5. Seal set                               | 18. Pipe clamp                    |
| 6. Power steering bracket assembly        | 19. Pipe bushing (D8)             |
| 7. Pump bracket                           | 20. Pipe bushing (D10)            |
| 8. Power steering oil tank                | 21. High pressure hose            |
| 9. Oil tank bracket                       | 22. Low pressure hose No. 1       |
| 10. Belt tension pulley                   | 23. Low pressure hose No. 2       |
| 11. Belt tension pulley bolt              | 24. Low pressure hose No. 1 clamp |
| 12. Belt tension bolt                     | 25. Low pressure hose No. 2 clamp |
| 13. Power steering belt                   |                                   |

Fig. 3B1-43 P/S Pump Components



### Removal

1. Remove splash cover, loosen belt tension pulley and remove P/S V-ribbed belt.
2. Disconnect high pressure hose and low pressure hose.
3. Disconnect pressure switch lead harness.
4. Remove compressor and bracket.  
Compressor needs not be removed with A/C equipped vehicle.
5. Remove oil pump together with its bracket (and 3 fixing bolts).

### NOTE:

- Be sure to clean each joint of suction and discharge sides thoroughly before removal.
- Plug each port of removed pump to prevent dust or any other foreign matter from entering.

### Installation

Reverse removal procedure.

### NOTE:

Fill A/T fluid (DEXRON-II) after installation and bleed air without failure.

### Disassembly

1. Using special tool, remove oil pump pulley.




Fig. 3B1-44 Removing Oil Pump Pulley

2. Remove suction connector by removing its fixing bolts (M6, 2 pcs).
3. Remove terminal assembly and discharge connector.




Fig. 3B1-45 Removing Terminal Assembly and Discharge Connector

4. Remove oil pump cover by removing its fixing bolts (M8, 4 pcs).




Fig. 3B1-46 Removing Oil Pump Cover

5. Remove cam ring.




Fig. 3B1-47 Removing Cam Ring

6. Remove snap ring and pull out rotor.

**NOTE:**

When pulling rotor out of shaft, be careful not to lose vane.




Fig. 3B1-48 Removing Rotor

7. Pull out shaft.

8. Remove oil seal.




Fig. 3B1-49 Removing Oil Seal

**Assembly**

Reverse disassembly procedure for assembly, noting the following.

1. Apply DEXRON-II to shaft where bushing slides against and insert shaft from oil seal side.




Fig. 3B1-50 Installing Shaft

2. Install rotor to shaft facing its splined part chamfered side up (to cover).




Fig. 3B1-51 Installing Rotor

3. Apply DEXRON-II to each vane and install it to rotor with its R part faced outward as shown below.




Fig. 3B1-52 Installing Vane

4. Apply DEXRON-II to O-ring and install it to pump body securely.  
5. Install cam ring.




Fig. 3B1-53 Installing Cam Ring

6. Install snap ring to shaft.  
7. Tighten cover bolts to specified torque.

Tightening torque for cover bolts	N·m	kg·m	lb·ft
	18 - 22	1.8 - 2.2	13.5 - 15.5

**NOTE:**

After installing cover, check to make sure that shaft can be turned by hand.




Fig. 3B1-54 Installing Cover

8. Check that flow control valve slides smoothly and tighten discharge (delivery) connector to specified torque.

Tightening torque for discharge connector	N·m	kg·m	lb·ft
	40 - 60	4.0 - 6.0	29.0 - 43.0




Fig. 3B1-55 Installing Flow Control Valve

9. Tighten terminal ass'y (pressure switch) to specified torque.

Tightening torque for terminal ass'y	N·m	kg·m	lb·ft
	25 - 30	2.5 - 3.0	18.5 - 21.5




Fig. 3B1-56 Installing Terminal

10. Tighten suction connector bolts to specified torque.

Tightening torque for suction con- nector bolts	N·m	kg·m	lb·ft
	6 - 10	0.6 - 1.0	4.5 - 7.0




Fig. 3B1-57 Installing Suction Connector

## INSPECTION

### P/S Pump Body and Shaft

- Wear and damage of pump body sliding surface.
  - Stepped wear and damage of shaft where bushing slides against.
- Replace P/S pump if any of the above is found.




Fig. 3B1-58 Inspecting Pump Body and Shaft

### Cam Ring

Inspect vane sliding surface of cam ring for wear and damage. Replace P/S pump if either of the above is found.




Fig. 3B1-59 Inspecting Cam Ring

**Rotor and Vane**

- Wear and damage of rotor sliding surface against pump body.
- Wear and damage of vane sliding surface against cam ring.
- Vane to rotor clearance.

Standard	0.01 mm (0.0004 in.)
Limit	0.06 mm (0.0023 in.)

Replace P/S pump if any of the above is found.




Fig. 3B1-60 Inspecting Rotor and Vane

**Flow Control Valve**

- Wear and damage on outside of valve.
- Obstruction in connector orifice.
- Free length of flow control spring.

Standard	36.5 mm (1.43 in.)
Limit	33.5 mm (1.32 in.)

Replace P/S pump if any of the above is found.




Fig. 3B1-61 Inspecting Flow Control Spring

**SPECIAL TOOLS**





 <p>09915-77410 Oil pressure gauge</p>	 <p>09913-65210 Tie-rod end remover</p>	 <p>09917-23610 Ring nut wrench</p>	 <p>09930-40113 Transfer flange lock holder</p>
-------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------

Fig. 3B1-62

**SECTION 3C****STEERING WHEEL AND COLUMN****NOTE:**

- All steering wheel and column fasteners are important parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- For the descriptions (items) not found in this section of this manual, refer to the same section of Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

<b>DIAGNOSIS</b> .....	3-1
<b>GENERAL DESCRIPTION</b> .....	3C-2
<b>ON CAR SERVICE</b> .....	3C-2
Remove and Install Steering Wheel .....	3C-2
Checking Steering Column for Accident Damage .....	3C-3
<b>SPECIAL TOOLS</b> .....	3C-4

## GENERAL DESCRIPTION

The steering wheel and column consist of following parts.




Fig. 3C-1 Steering Wheel and Column

## ON CAR SERVICE

### REMOVE AND INSTALL STEERING WHEEL

#### REMOVAL

- 1) Disconnect negative battery cable.
- 2) Remove pad by pulling it upward.
- 3) Remove steering shaft nut and mass damper screws.
- 4) Make alignment marks on steering wheel and shaft for a guide during reinstallation.




Fig. 3C-2

5) Remove steering wheel with special tool (A).




Fig. 3C-3

### INSTALLATION

- 1) Install mass damper to steering wheel.
- 2) Install steering wheel onto shaft, aligning alignment marks on them.
- 3) Torque steering shaft nut to specification as given below.
- 4) Install pad.




Fig. 3C-4

5) Connect negative battery cable.

### CHECKING STEERING COLUMN FOR ACCIDENT DAMAGE

#### NOTE:

Cars involved in accidents resulting in body damage or where the steering column has been impacted may also have a damaged or misaligned steering column.

#### CHECKING PROCEDURE

Take measurement "A" as shown. If it is shorter than specified length, replace column assembly with new one.

#### NOTE:

Specified length "A" varies depending on vehicle specifications. Measure measurement "B" first and by using that data, check specified length "A" applicable to specifications and then take measurement "A".





Fig. 3C-5

#### NOTE:

For any checking procedure other than the above, consult the Service Manual mentioned in the FOREWORD of this manual.



## SPECIAL TOOL



*Fig. 3C-6*

# SECTION 5

# BRAKES

**NOTE:**

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## CONTENTS

<b>BRAKE HOSE/PIPE R &amp; I</b> .....	<b>5-2</b>
1. Remove and Install Front Brake Hose/Pipe .....	5-2

## BRAKE HOSE/PIPE R & I

### 1. REMOVE AND INSTALL FRONT BRAKE HOSE/PIPE

1) Raise and suitably support car. Remove tire and wheel.

This operation is not necessary when removing pipes connecting master cylinder and P valve.

2) Clean dirt and foreign material from both hose end or pipe end fittings. Remove brake hose or pipe.

3) Reverse brake hose installation procedure.

For installation, make sure that steering wheel is in straightforward position and hose has no twist or kink. Check to make sure that hose doesn't contact any part of suspension, both in extreme right and extreme left turn conditions. If it does at any point, remove and correct. Fill and maintain brake fluid level in reservoir. Bleed brake system.




Fig. 5-1 Front Brake Hose/Pipe R & I

---

**SECTION 6****ENGINE****NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

ENGINE DIAGNOSIS .....	6-2	ENGINE IGNITION SYSTEM	
ENGINE MECHANICAL .....	6A-1	(FUEL INJECTION MODEL) .....	6F1-1
CARBURETOR .....	6D-1	ENGINE CRANKING SYSTEM	
ENGINE ELECTRONIC FUEL		(1.2 kW and 1.4 kW type) .....	6G1-1
INJECTION SYSTEM .....	6E-1	ENGINE EXHAUST .....	6K-1
ENGINE IGNITION SYSTEM			
(CARBURETOR MODEL) .....	6F-1		

## ENGINE DIAGNOSIS

Condition	Possible Cause	Correction
<b>Hard Starting (Engine cranks OK)</b>	<p><b>Ignition system out of order</b></p> <ul style="list-style-type: none"> <li>● Blown fuse</li> <li>● Faulty spark plug</li>   <li>● Leaky high-tension cord</li> <li>● Loose connection or disconnection of high-tension cords or lead wires</li> <li>● Maladjusted signal rotor air gap</li> <li>● Faulty pickup coil or igniter</li> <li>● Defective generator assembly in distributor</li> <li>● Improper ignition timing</li> <li>● Faulty ignition coil</li> <li>● Cracked rotor or cap in distributor</li> <li>● Faulty igniter (power unit)</li> <li>● Faulty noise suppressor</li> <li>● Faulty CAS (in distributor) (FUEL INJECTION MODEL)</li> <li>● Faulty ECM (FUEL INJECTION MODEL)</li> </ul> <p><b>Fuel system out of order</b></p> <ul style="list-style-type: none"> <li>● Lack of fuel in fuel tank</li> <li>● Dirty fuel filter</li> <li>● Dirty or clogged fuel hose or pipe</li> <li>● Malfunctioning fuel pump</li> <li>● Carburetor choke not working properly (CARBURETOR MODEL)</li> <li>● Air inhaling from intake system</li> <li>● Improper adjustment of float level (CARBURETOR MODEL)</li> <li>● Malfunctioning fuel cut solenoid valve (CARBURETOR MODEL)</li> <li>● Carburetor out of adjustment (CARBURETOR MODEL)</li> </ul>	<p>Repair or replace</p> <p>Clean and adjust plug gap or replace</p> <p>Replace</p> <p>Repair or replace.</p> <p>Adjust</p> <p>Replace</p> <p>Replace.</p> <p>Adjust</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Refill</p> <p>Replace</p> <p>Clean</p> <p>Replace</p> <p>Check and adjust</p> <p>Repair or replace</p> <p>Adjust</p> <p>Check solenoid valve for operation Replace if necessary</p> <p>Adjust</p>

Condition	Possible Cause	Correction
	<p><b>Electronic Fuel Injection system out of order</b></p> <p><b>Low compression</b></p> <ul style="list-style-type: none"> <li>● Poor spark plug tightening or faulty gasket</li> <li>● Compression leak from valve seat</li> <li>● Sticky valve stem</li> <li>● Weak or damaged valve springs</li> <li>● Compression leak at cylinder head gasket</li> <li>● Sticking or damaged piston ring</li> <li>● Worn piston, ring or cylinder</li> </ul> <p><b>Others</b></p> <ul style="list-style-type: none"> <li>● Broken valve timing belt</li> <li>● Malfunctioning PCV valve</li> </ul>	<p>Refer to SECTION 6E</p> <p>Tighten to specified torque or replace gasket</p> <p>Remove cylinder head and lap valves</p> <p>Correct or replace valve and valve guide</p> <p>Replace</p> <p>Repair or replace</p> <p>Replace</p> <p>Replace ring and piston Rebore or replace cylinder</p> <p>Replace</p> <p>Replace</p>
<p><b>Engine has no power</b></p>	<p><b>Ignition system out of order</b></p> <ul style="list-style-type: none"> <li>● Incorrect ignition timing</li> <li>● Faulty spark plug</li> <li>● Worn distributor terminals</li> <li>● Leaks, loose connection or disconnection of high-tension cord</li> <li>● Faulty ESA system (FUEL INJECTION MODEL)</li> <li>● Malfunctioning ignition timing advancers (CARBURETOR MODEL)</li> </ul> <p><b>Engine overheating</b></p> <p><b>Fuel system out of order</b></p> <ul style="list-style-type: none"> <li>● Clogged fuel hose or pipe</li> <li>● Dirty or clogged fuel filter</li> <li>● Clogged air cleaner element</li> <li>● Air inhaling from intake manifold gasket or throttle body gasket</li> </ul> <p><b>Electronic Fuel Injection system out of order</b></p> <p><b>Low compression</b></p>	<p>Adjust</p> <p>Adjust or replace</p> <p>Dress or replace. Also check rotor</p> <p>Connect or replace as necessary</p> <p>Refer to SECTION 6F1</p> <p>Replace</p> <p>Refer to "Overheating" section</p> <p>Clean</p> <p>Replace</p> <p>Clean or replace</p> <p>Replace</p> <p>Refer to SECTION 6E</p> <p>Previously outlined</p>

Condition	Possible Cause	Correction
	<p><b>Others</b></p> <ul style="list-style-type: none"> <li>● Loose connection or disconnection of vacuum hoses</li> <li>● Malfunctioning EGR valve (if equipped)</li> <li>● Dragging brakes</li> <li>● Slipping clutch</li> </ul>	<p>Connect securely</p> <p>Check and replace as necessary</p> <p>Repair or replace</p> <p>Adjust or replace</p>
<p><b>Improper engine idling or engine fails to idle</b></p>	<p><b>Ignition system out of order</b></p> <ul style="list-style-type: none"> <li>● Faulty spark plug</li> <li>● Leaky or disconnected high tension cord</li> <li>● Worn distributor terminals</li> <li>● Improper ignition timing</li> <li>● Cracked cap in distributor with leakage inside</li> <li>● Faulty ESA system (FUEL INJECTION MODEL)</li> <li>● Malfunctioning ignition timing advancer</li> </ul> <p><b>Fuel system out of order</b></p> <ul style="list-style-type: none"> <li>● Shortage of fuel in fuel tank</li> <li>● Clogged air cleaner element</li> <li>● Leaky manifold, throttle body, or cylinder head gasket</li> <li>● Improper adjustment of float level (CARBURETOR MODEL)</li> <li>● Clogged carburetor jets (CARBURETOR MODEL)</li> <li>● Loose manifold and carburetor bolts and nuts (CARBURETOR MODEL)</li> <li>● Malfunctioning accelerator pump (CARBURETOR MODEL)</li> </ul> <p><b>Electronic Fuel Injection system out of order</b></p> <p><b>Engine overheating</b></p> <p><b>Low compression</b></p> <p><b>Others</b></p> <ul style="list-style-type: none"> <li>● Loose connection or disconnection of vacuum hoses</li> <li>● Malfunctioning EGR valve (if equipped)</li> <li>● Malfunctioning PCV valve</li> </ul>	<p>Adjust or replace</p> <p>Connect or replace</p> <p>Replace</p> <p>Adjust</p> <p>Replace</p> <p>Refer to SECTION 6F1</p> <p>Replace</p> <p>Refill</p> <p>Clean or replace</p> <p>Replace</p> <p>Adjust</p> <p>Clean</p> <p>Retighten</p> <p>Check and replace as necessary</p> <p>Refer to SECTION 6E</p> <p>Refer to "Overheating" section</p> <p>Previously outlined</p> <p>Connect securely</p> <p>Check and replace as necessary</p> <p>Check and replace as necessary</p>

Condition	Possible Cause	Correction
<p><b>Engine hesitates</b> (Momentary lack of response as accelerator is depressed. Can occur at all car speeds. Usually most severe when first trying to make car move, as from a stop sign.)</p>	<p><b>Ignition system out of order</b></p> <ul style="list-style-type: none"> <li>● Improper ignition timing</li> <li>● Spark plug faulty or plug gap out of adjustment</li> <li>● Leaky high tension cord</li> </ul> <p><b>Fuel system out of order</b></p> <ul style="list-style-type: none"> <li>● Clogged air cleaner element</li> <li>● Clogged fuel filter, hose or pipe</li> <li>● Malfunction of choke system (CARBURETOR MODEL)</li> <li>● Fuel pump not working properly</li> <li>● Clogged carburetor jets (CARBURETOR MODEL)</li> </ul> <p><b>Electronic Fuel Injection system out of order</b></p> <p><b>Engine overheating</b></p> <p><b>Low compression</b></p> <p><b>Others</b></p> <ul style="list-style-type: none"> <li>● Malfunctioning EGR valve (if equipped)</li> </ul>	<p>Adjust</p> <p>Replace or adjust gap</p> <p>Replace</p> <p>Clean or replace</p> <p>Clean or replace</p> <p>Adjust or replace</p> <p>Replace</p> <p>Clean</p> <p>Refer to SECTION 6E</p> <p>Refer to "Overheating" section</p> <p>Previously outlined</p> <p>Check and replace as necessary</p>
<p><b>Surges</b> (Engine power variation under steady throttle or cruise. Feels like car speeds up and down with no change in accelerator pedal.)</p>	<p><b>Ignition system out of order</b></p> <ul style="list-style-type: none"> <li>● Improper ignition timing</li> <li>● Malfunctioning ignition timing advancers (mechanical and vacuum) (CARBURETOR MODEL)</li> <li>● Leaky or loosely connected high-tension cord</li> <li>● Defective spark plug (excess carbon deposits, improper gap, and burned electrodes, etc.)</li> <li>● Cracked rotor or cap in distributor</li> <li>● Faulty ESA system (FUEL INJECTION MODEL)</li> </ul> <p><b>Fuel system out of order</b></p> <ul style="list-style-type: none"> <li>● Clogged fuel filter</li> <li>● Kinky or damaged fuel hose and lines</li> <li>● Improper float level (CARBURETOR MODEL)</li> </ul> <p><b>Electronic Fuel Injection system out of order</b></p> <p><b>Others</b></p> <ul style="list-style-type: none"> <li>● Malfunctioning EGR valve (if equipped)</li> </ul>	<p>Adjust</p> <p>Check or replace</p> <p>Check and repair or replace</p> <p>Check and clean, adjust or replace</p> <p>Replace</p> <p>Refer to SECTION 6F1</p> <p>Replace</p> <p>Check and replace as necessary</p> <p>Adjust</p> <p>Refer to SECTION 6E</p> <p>Check and replace as necessary</p>



Condition	Possible Cause	Correction
<p><b>Excessive detonation</b> (Engine makes sharp metallic knocks that change with throttle opening. Sounds like pop corn popping.)</p>	<p><b>Engine overheating</b></p> <p><b>Ignition system out of order</b></p> <ul style="list-style-type: none"> <li>● Faulty spark plug</li> <li>● Improper ignition timing</li> <li>● Loose connection of high tension cord</li> </ul> <p><b>Fuel system out of order</b></p> <ul style="list-style-type: none"> <li>● Clogged fuel filter or fuel lines</li> <li>● Air inhaling from intake manifold or throttle body (carburetor) gasket</li> <li>● Clogged carburetor jets (CARBURETOR MODEL)</li> <li>● Improper adjustment of float level (CARBURETOR MODEL)</li> </ul> <p><b>Electronic Fuel Injection system out of order</b></p> <p><b>Others</b></p> <ul style="list-style-type: none"> <li>● Loose connection or disconnection of vacuum hoses</li> <li>● Excessive combustion chamber deposits</li> <li>● Malfunctioning EGR valve (if equipped)</li> </ul>	<p>Refer to "Overheating" section</p> <p>Replace Adjust Connect securely</p> <p>Replace or clean Replace</p> <p>Clean</p> <p>Adjust</p> <p>Refer to SECTION 6E</p> <p>Connect securely</p> <p>Remove carbon Check and replace as necessary</p>
<p><b>Overheating</b></p>	<ul style="list-style-type: none"> <li>● Insufficient coolant</li> <li>● Loose water pump belt</li> <li>● Inoperative thermostat</li> <li>● Poor water pump performance</li> <li>● Improper ignition timing</li> <li>● Clogged or leaky radiator</li> <li>● Improper engine oil grade</li> <li>● Clogged oil filter or oil strainer</li> <li>● Not enough oil</li> <li>● Poor oil pump performance</li> <li>● Oil leakage</li> <li>● Dragging brakes</li> <li>● Slipping clutch</li> <li>● Blown cylinder head gasket</li> </ul>	<p>Replenish Adjust Replace Replace Adjust Flush, repair or replace Replace with proper grade oil Replace or clean (oil strainer) Replenish Repair or replace Repair Repair or replace Adjust or replace Replace</p>

Condition	Possible Cause	Correction
<b>Poor gasoline mileage</b>	<b>Fuel system out of order</b> <ul style="list-style-type: none"> <li>● Fuel leakage from fuel tank and lines</li> <li>● Clogged air cleaner element</li> <li>● Malfunctioning carburetor choke system (CARBURETOR MODEL)</li> <li>● Improper float level (CARBURETOR MODEL)</li> <li>● Dirty or clogged carburetor jets (CARBURETOR MODEL)</li> </ul> <b>Ignition system out of order</b> <ul style="list-style-type: none"> <li>● Improper ignition timing</li> <li>● Leaks or loose connection of high-tension cord</li> <li>● Faulty spark plug (improper gap, heavy deposits, and burned electrodes, etc.)</li> <li>● Malfunctioning mechanical and vacuum advancers in distributor (CARBURETOR MODEL)</li> <li>● Faulty ESA system</li> </ul> <b>Electronic Fuel Injection system out of order</b> <p>Low compression</p> <p>Others</p> <ul style="list-style-type: none"> <li>● Poor valve seating</li> <li>● Dragging brakes</li> <li>● Slipping clutch</li> <li>● Thermostat out of order</li> <li>● Improper tire pressure</li> <li>● Malfunctioning EGR valve (if equipped)</li> </ul>	Repair or replace Clean or replace Repair or replace Adjust Clean Adjust Repair or replace Clean, adjust or replace Check and repair or replace Refer to SECTION 6F1 Refer to SECTION 6E Previously outlined Repair or replace Repair or replace Adjust or replace Replace Adjust Check and replace as necessary
<b>Excessive engine oil consumption</b>	<b>Oil leakage</b> <ul style="list-style-type: none"> <li>● Loose oil drain plug</li> <li>● Loose oil pan bolts</li> <li>● Deteriorated or broken oil pan sealant</li> <li>● Leaky crankshaft oil seals</li> <li>● Leaky cylinder head cover gasket</li> <li>● Improper tightening of oil filter</li> <li>● Loose oil pressure switch</li> <li>● Blown cylinder head gasket</li> <li>● Leaky camshaft oil seals</li> </ul>	Tighten Tighten Replace sealant Replace Replace Tighten Tighten Replace Replace

Condition	Possible Cause	Correction
	<p><b>Oil entering combustion chamber</b></p> <ul style="list-style-type: none"> <li>● Sticky piston ring</li> <li>● Worn piston and cylinder</li> <li>● Worn piston ring groove and ring</li> <li>● Improper location of piston ring gap</li> <li>● Worn or damaged valve stem seal</li> <li>● Worn valve stem</li> </ul>	<p>Remove carbon and replace rings</p> <p>Replace or rebore cylinder, and replace piston</p> <p>Replace piston and ring</p> <p>Reposition ring gap</p> <p>Replace</p> <p>Replace</p>
<p><b>Low oil pressure</b></p>	<ul style="list-style-type: none"> <li>● Not enough oil</li> <li>● Improper oil viscosity</li> <li>● Malfunctioning oil pressure switch</li> <li>● Clogged oil strainer</li> <li>● Functional deterioration of oil pump</li> <li>● Worn oil pump relief valve</li> <li>● Excessive clearance in various sliding parts</li> </ul>	<p>Replenish</p> <p>Use oil of proper viscosity</p> <p>Replace</p> <p>Clean</p> <p>Replace</p> <p>Replace</p> <p>Replace worn parts</p>
<p><b>Engine noise</b></p> <p>Note: Before checking mechanical noise, make sure that:</p> <ul style="list-style-type: none"> <li>● Ignition timing is properly adjusted.</li> <li>● Specified spark plug is used.</li> <li>● Specified fuel is used.</li> </ul>	<p><b>Valve noise</b></p> <ul style="list-style-type: none"> <li>● Improper valve lash</li> <li>● Worn valve stem and guide</li> <li>● Weak or broken valve spring</li> <li>● Warped or bent valve</li> </ul> <p><b>Piston, ring and cylinder noise</b></p> <ul style="list-style-type: none"> <li>● Worn piston ring and cylinder bore</li> </ul> <p><b>Connecting rod noise</b></p> <ul style="list-style-type: none"> <li>● Worn rod bearing</li> <li>● Worn crank pin</li> <li>● Loose connecting rod nuts</li> <li>● Low oil pressure</li> </ul> <p><b>Crankshaft noise</b></p> <ul style="list-style-type: none"> <li>● Low oil pressure</li> <li>● Worn bearing</li> <li>● Worn crankshaft journal</li> <li>● Loose bearing cap bolts</li> <li>● Excessive crankshaft thrust play</li> </ul>	<p>Adjust</p> <p>Replace</p> <p>Replace</p> <p>Replace</p> <p>Rebore or replace cylinder</p> <p>Replace piston and ring</p> <p>Replace</p> <p>Repair by grinding or replace crankshaft</p> <p>Tighten to specification</p> <p>Previously outlined</p> <p>Previously outlined</p> <p>Replace</p> <p>Repair by grinding, or replace crankshaft</p> <p>Tighten to specification</p> <p>Replace thrust bearing</p>

Condition	Possible Cause	Correction
<b>Dieseling</b> (Engine continues to run after ignition switch is turned off. It runs unevenly and may make knocking noise.)	Malfunctioning fuel cut solenoid valve in carburetor (CARBURETOR MODEL)	Check valve for proper operation, and replace as necessary.

## SECTION 6A

## ENGINE MECHANICAL

## NOTE:

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## CONTENTS

ON CAR SERVICE .....	6A-1
Compression Check .....	6A-1
Engine Vacuum Check .....	6A-2
Oil Pressure Check .....	6A-2
Crankshaft Pulley .....	6A-2
Engine Mounting .....	6A-3

## ON CAR SERVICE

## COMPRESSION CHECK

Check compression pressure on all four cylinders as follows:

1. Warm up engine.
2. Stop engine after warming up.
3. Remove all spark plugs and disconnect ignition coil wire harness at coupler.

**WARNING:**

Failure in disconnecting ignition coil coupler can cause spark to occur in engine room possibly resulting in a dangerous explosion.

4. Install special tool (Compression gauge) into spark plug hole.




Fig. 6A-1 Installing Compression Gauge

5. Disengage clutch (to lighten starting load on engine) for M/T model, and depress accelerator pedal all the way to make throttle valve full-open.
6. Crank engine with fully charged battery, and read the highest pressure on compression gauge.

	Compression pressure
Standard	14.0 kg/cm <sup>2</sup> (199.0 psi, 1400 kPa)/250 r/min or higher
Limit	11.0 kg/cm <sup>2</sup> (156.4 psi, 1100 kPa)/250 r/min or higher
Max. difference between any two cylinders	1.0 kg/cm <sup>2</sup> (14.2 psi, 100 kPa)

7. Carry out steps 4 through 6 on each cylinder to obtain four readings.
8. After checking, connect coupler of ignition coil and install spark plugs.

## ENGINE VACUUM CHECK

Engine vacuum that develops in intake line is a good indicator of engine condition. Check engine vacuum as follows:

1. Warm up engine to normal operating temperature.
2. Remove blind plug from intake manifold and install special tool (vacuum gauge) to vacated threaded hole.




Fig. 6A-2 Installing Vacuum Gauge

3. Run engine at specified idle speed (see section 6E1), and read vacuum gauge. Vacuum should be within following specification.

Vacuum specification	40 – 50 cmHg (15.7 – 19.7 in.Hg) at specified idling speed
----------------------	------------------------------------------------------------------

4. After checking, apply sealant to thread of blind plug and install it to intake manifold.

## OIL PRESSURE CHECK

Check engine oil pressure according to the same procedure as those described in Service Manual mentioned in the FOREWORD of this manual.

Oil pressure specification	3.3 – 4.3 kg/cm <sup>2</sup> 46.9 – 61.1 psi at 4,000 r/min.
----------------------------	--------------------------------------------------------------------

## CRANKSHAFT PULLEY

Following bolts are used for crankshaft pulley. Tighten them to specified torque below.

Tightening torque for pulley bolts	N-m	kg-m	lb-ft
	14 – 18	1.4 – 1.8	10.5 – 13.0




Fig. 6A-3 Crankshaft Pulley Bolt

## ENGINE MOUNTINGS

Right mounting and rear torque rod bracket (A/T) are equipped with damper respectively. When removing or installing, refer to following figure.




Fig. 6A-4 Engine Mounting (For 2WD M/T Model)




Fig. 6A-5 Engine Mounting (For A/T Model)

**SECTION 6D****CARBURETOR****NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

<b>GENERAL DESCRIPTION</b> .....	6D-2
Idle Up Systems .....	6D-3
<b>ON CAR SERVICE</b> .....	6D-5
Electric Load Idle Up System .....	6D-5
"D" Range Idle Up System .....	6D-6
P/S Load Idle Up System .....	6D-7



## GENERAL DESCRIPTION

This carburetor is a 2-barrel downdraft type having a primary system and a secondary system.

The primary system operates under normal driving condition, and the secondary system operates under high speed, high load driving condition.

In the primary system, a choke valve is incorporated.

### NOTE:

The following variations in system or parts are used depending on specifications and as required by regulations of each country.

- Air vent solenoid valve — Equipped and not equipped.
- Idle up actuator 2 — Equipped and not equipped.
- Throttle sensor — For automatic transmission car.




Fig. 6D-1

## IDLE UP SYSTEMS

The structure of this system is as shown below. For the manual transmission car, the system operates to stabilize the engine idle speed when one of the following electric circuits is ON. For the automatic transmission car, the system operates when the selector lever is shifted to one of R, D, 2 and L ranges. And idle up system for power steering load operates when the steering wheel is turned. By using this system, the engine idle speed can be decreased under ordinary conditions.

- ① Headlight and small light      ③ Engine cooling fan
- ② Heater fan                              ④ Rear defogger




Fig. 6D-2

VSV opens to apply vacuum when it senses, through a signal, electric load of one of above circuits (M/T model), shifting of select lever to R, D, 2 or L range or P/S load (if equipped) when steering wheel is turned. Then vacuum from the intake manifold pulls up the diaphragm of the idle up actuator. In accordance with the diaphragm movement, the idle up rod and the idle up lever move and push down the throttle lever a little further than the ordinary idle speed position, thereby opening the throttle valve by the amount corresponding to the throttle lever movement (about  $1.5^\circ$ ), which results in the idle up state. (When headlight switch turns on, engine runs at 650 – 750 r/min.).

When the VSV stops operating (no electric load from the above circuits), air is introduced into the idle up actuator. Then the diaphragm and the rod move down and the idle up lever leaves the throttle lever to release the idle up state. The idle up engine speed is adjusted by turning the idle up adjusting screw.

### **IDLE UP DUE TO POWER STEERING ASSIST LOAD**

When the power steering starts steering assist function, the hydraulic pressure in the P/S pump rises. This pressure rise causes the pressure switch in the P/S pump to close to transmit a signal to the P/S idle up relay which then turns ON. As a result, a voltage is applied to the idle up VSV2 to actuate it. What takes place after this is the same as the description for "Idle up due to electric load" above.

## ON CAR SERVICE

### ELECTRIC LOAD IDLE UP SYSTEM

#### INSPECTION

- 1) Adjust idle speed to specification by referring to **Idle Speed and Idle Mixture** and maintain engine at that speed.
- 2) Turn ON head light. If engine idle speed keeps at specified idle speed, that proves normal function of idle up.

If found faulty, check following parts individually according to each procedure.

#### VSV (Vacuum Switching Valve)

- 1) Make sure that head light, small light, engine cooling fan, heater fan and rear defogger (if equipped) are all turned OFF.
- 2) Disconnect VSV vacuum hoses from gas filter and actuator.
- 3) By blowing air into hose disconnected from intake manifold, make sure there is no continuity between these hoses.
- 4) Turn ON head light and by blowing air into hose disconnected from intake manifold, make sure that there is continuity between hoses.

If found defective in above steps 3) and 4), replace hoses, wiring harness or VSV.

#### Actuator

- 1) Disconnect hose from actuator.
- 2) Pull actuator rod by hand all the way up and apply finger to the joint from which actuator hose has been disconnected.
- 3) In the state of 2), take hand off rod. If actuator rod stays up, it is normal. If defective, replace.

#### ADJUSTMENT

If VSV, actuator, hose wiring harness and battery capacity are normal and yet idle up speed is not attained, adjust as follows.

- 1) Start engine.
- 2) Turn ON head light. Engine speed in this state should be within 650 – 750 r/min (rpm). If not within specification, adjust with idle up adjusting screw.

Engine idle speed when idle up system is operated	700 ± 50 r/min
---------------------------------------------------	----------------




Fig. 6D-3

## "D" RANGE IDLE UP SYSTEM

### INSPECTION

1. Adjust idle speed to specification and maintain engine at that speed.
2. When selector lever is shifted to each "R", "D", "2" and "L" range, if engine speed keeps at below specified idle speed, that proves normal function of idle up.

Engine idle speed when shift lever is shifted to "R", "D", "2" or "L" range	700 ± 50 r/min
-----------------------------------------------------------------------------	----------------

If found faulty, check following parts individually according to each procedure.

### VSV (Vacuum Switching Valve)

- 1) Make sure that selector lever is shifted to "P" range.
- 2) Disconnect VSV vacuum hoses from gas filter and actuator.
- 3) Turn ignition switch to "ON" position.
- 4) By blowing air into hose disconnected from actuator, make sure there is no continuity between these hoses. Then, shift selector lever to "N" range and also check to make sure that there is no continuity between these hoses.
- 5) Shift selector lever to "R" range, by blowing air into the hose disconnected from actuator, make sure that there is continuity between hoses. Also, with selector lever shifted to "D", "2" and "L" ranges, check to make sure that there is continuity between these hoses in each range. If found faulty in steps 4) and 5), proceed to following checks.
- 6) With ignition switch at "OFF" position, disconnect lead wire coupler from VSV.
- 7) Turn ignition switch to "ON" position.
- 8) Connect voltmeter to coupler terminals. Shift selector lever to "P" and then "N" ranges and check that voltmeter indicates 0V in each range. Also, shift selector lever to "R", "D", "2" and "L" ranges and check that voltmeter indicates about 12V in each range.




Fig. 6D-4

- 9) If found faulty in step 8), inspect shift lever switch and its circuit by referring to description of shift lever switch inspection of "AUTOMATIC TRANSMISSION" section.
- 10) If found faulty in above step 9), replace shift lever switch or wire harness. If found faulty in step 8), and yet it is proved in step 9) that shift lever switch and wire harness are in good condition, replace AT controller or wire harness.
- 11) If found faulty in steps 4) and 5) checks and yet it is proved in step 8) that VSV electric circuit is in good condition, replace VSV.
- 12) After checking, be sure to reconnect disconnected couplers and vacuum hoses.

**Actuator**

- 1) Disconnect hose from actuator.
- 2) Pull actuator rod with finger all the way up and apply finger to the joint from which actuator hose has been disconnected.
- 3) In the state of 2), take finger off rod. If actuator rod stays up, it is in good condition. If defective, replace.




Fig. 6D-5

**ADJUSTMENT**

If idle up system is normal and yet idle up speed is not attained, adjust as follows.

1. Check to be sure that:
  - Engine idle speed with selector lever shifted to "P" or "N" range is as specified.
  - Parking brake is pulled fully and drive wheels are blocked.
2. Engine speed with selector lever shifted to "D", "2", "L" or "R" range should be within specification. (See p. 6D-15)  
If not within specification, adjust with idle up adjusting screw.




Fig. 6D-6

**P/S LOAD IDLE UP SYSTEM**

**INSPECTION**

- 1) Adjust idle speed to specification by referring to **Idle Speed and Idle Mixture** and maintain engine at that speed.
- 2) Turn steering wheel fully and while holding it there lightly, check that engine idle speed is within below specification.

Engine idle speed when P/S load idle up is operated	700 ± 50 r/min (M/T model) 850 ± 50 r/min (A/T model)
-----------------------------------------------------	----------------------------------------------------------

If found faulty in above step 2), check following parts individually according to each procedure.

**VSV (Vacuum Switching Valve)**

- 1) Make sure that headlight, small light, engine cooling fan, heater fan and rear defogger (if equipped) are all turned OFF.
- 2) Disconnect VSV2 vacuum hose from joint and actuator.
- 3) By blowing air into hose, make sure there is no continuity between these hoses.
- 4) Check to make sure that there is air continuity between hoses when steering wheel is turned fully and holding it there lightly.  
If found defective in above steps 3) and 4), repair or replace hoses, wiring harness.

**Actuator**

- 1) Disconnect hose from actuator.
- 2) Pull actuator rod by hand all the way up and apply finger to the joint from which actuator hose has been disconnected.
- 3) In the state of 2), take hand off rod. If actuator rod stays up, it is normal. If defective, replace.

**ADJUSTMENT**

If VSV, actuator, hose wiring harness and battery capacity are normal and yet idle up speed is not attained, adjust as follows.

- 1) Start engine.
- 2) Turn On headlight. Engine speed in this state should be within specification.  
If not within specification, adjust with idle up adjusting screw.




Fig. 6D-7

Turn OFF headlight and small light.

- 3) Turn steering wheel fully and while holding it there lightly.  
If engine speed is not within specification, adjust with idle up adjusting screw.




Fig. 6D-8

**SECTION 6E****ELECTRONIC FUEL INJECTION SYSTEM****(Single-point Throttle Body Fuel Injection System)****NOTE:**

Whether following systems (parts) are used in the particular car or not depends on specifications. Be sure to bear this in mind when performing service work.

- Shift-up indicator light control system (Shift-up indicator light).

**CONTENTS**

<b>GENERAL DESCRIPTION</b> .....	6E- 3	Fuel Injection Control System .....	6E-22
<b>AIR AND FUEL DELIVERY SYSTEM</b> ..	6E- 6	Fuel Pump Control System .....	6E-26
Fuel Pump .....	6E- 7	ISC Solenoid Valve Control System ...	6E-27
Throttle Body .....	6E- 8	EGR Control System .....	6E-28
Fuel Injector .....	6E- 9	Shift Up Indicator Light Control	
Fuel Pressure Regulator .....	6E- 9	System (If equipped) .....	6E-29
Air Valve .....	6E-10	Throttle Valve Opening Signal Output	
ISC Solenoid Valve .....	6E-11	For A/T .....	6E-30
<b>ELECTRONIC CONTROL SYSTEM</b> ....	6E-12	ESA (Electronic Spark Advance)	
Electronic Control Module (ECM) ..	6E-16	Control System .....	6E-30
Pressure Sensor (PS) .....	6E-18	<b>DIAGNOSIS</b> .....	6E-32
Throttle Position Sensor (TPS) ....	6E-18	Precautions in Diagnosing Troubles in	
Air Temperature Sensor (ATS) ....	6E-19	Electronic Fuel Injection System ....	6E-32
Water Temperature Sensor (WTS) ...	6E-19	<b>DIAGNOSTIC FLOW CHART</b> .....	6E-35
Oxygen Sensor .....	6E-19	Diagnostic Code Table .....	6E-36
Vehicle Speed Sensor .....	6E-20	A-1 ECM Power and Ground Circuit	
Crank Angle Sensor .....	6E-20	Check .....	6E-37
Ignition Fail Safe Signal .....	6E-20	A-2 "CHECK ENGINE" Light	
Enginen Start Signal .....	6E-20	Circuit Check .....	6E-38
"R", "D", "2" or "L" Range Signal		A-3 "CHECK ENGINE" Light	
(A/T model only) .....	6E-21	Circuit Check .....	6E-39
Electric Load Signal .....	6E-21	Code No. 13 Oxygen Sensor Circuit ...	6E-40
Air-Conditioner Signal		Code No. 14 WTS Circuit .....	6E-41
(Car with air-conditioner only) ....	6E-21	Code No. 15 WTS Circuit .....	6E-42
Battery Voltage .....	6E-21	Code No. 21 TPS Circuit .....	6E-43
Power Steering Signal (If equipped) ..	6E-21	Code No. 22 TPS Circuit .....	6E-44
Diagnosis Switch Terminal .....	6E-21	Code No. 23 ATS Circuit .....	6E-45
Test Switch Terminal .....	6E-21	Code No. 25 ATS Circuit .....	6E-46



Code No. 24 Vehicle Speed Sensor		ELECTRONIC CONTROL SYSTEM . . . . .	6E -80
Circuit . . . . .	6E -47	ECM (Removal and installation) . . . . .	6E -80
Code No. 31 PS Circuit . . . . .	6E -48	PS (Inspection) . . . . .	6E -81
Code No. 32 PS Circuit . . . . .	6E -49	TPS (Inspection, adjustment, removal and installation) . . . . .	6E -82
Code No. 41 Ignition Fail Safe Signal		ATS (Removal, inspection and installation) . . . . .	6E -84
Circuit . . . . .	6E -50	WTS (Removal, inspection and installation) . . . . .	6E -84
Code No. 42 Crank Angle Sensor		Oxygen Sensor (Removal and installation) . . . . .	6E -85
Circuit . . . . .	6E -51	Vehicle Speed Sensor (Inspection) . . . . .	6E -85
Code No. 51 EGR System		Main Relay (Inspection) . . . . .	6E -86
(California spec. model only) . . . . .	6E -52	Fuel Pump Relay (Inspection) . . . . .	6E -87
Trouble Diagnosis . . . . .	6E -53	Fuel Injector Resistor (Inspection) . . . . .	6E -87
B-1 Fuel Injector and Its Circuit		Fuel Cut Operation (Inspection) . . . . .	6E -87
Check . . . . .	6E -57	ISC Solenoid Valve (Inspection) . . . . .	6E -88
B-2 Fuel Pump and Its Circuit		EGR Control System . . . . .	6E -89
Check . . . . .	6E -59	System Inspection . . . . .	6E -89
B-3 Fuel Pressure Check . . . . .	6E -60	Vacuum Hose Inspection . . . . .	6E -89
B-4 ISC Solenoid Valve Control		EGR Valve Inspection . . . . .	6E -89
System Check . . . . .	6E -62	EGR Modulator Inspection . . . . .	6E -90
B-5 Engine Start Signal Check . . . . .	6E -64	VSV Inspection . . . . .	6E -90
B-6 "R", "D", "2" and "L" Range		Shift Up Indicator Light Control	
Signal Check (A/T model only) . . . . .	6E -64	System (If equipped) . . . . .	6E -91
Inspection of ECM and Its Circuits . . . . .	6E -65	System Inspection . . . . .	6E -91
Voltage Check . . . . .	6E -65	Shift Up Indicator Light and Its Circuit Inspection . . . . .	6E -92
Resistance Check . . . . .	6E -68	Output Signal of Throttle Valve	
<b>ON CAR SERVICE . . . . .</b>	<b>6E -69</b>	Opening (Inspection) . . . . .	6E -92
General . . . . .	6E -69	Power Steering VSV (If equipped) . . . . .	6E -93
Accelerator Cable Adjustment . . . . .	6E -69	<b>SPECIAL TOOLS . . . . .</b>	<b>6E -94</b>
Idle Speed/ISC Duty Adjustment . . . . .	6E -69	<b>RECOMMENDED TORQUE</b>	
<b>AIR AND FUEL DELIVERY SYSTEM . . . . .</b>	<b>6E -71</b>	<b>SPECIFICATIONS . . . . .</b>	<b>6E -94</b>
Fuel Pressure Inspection . . . . .	6E -71		
Fuel Pump (On car inspection, removal, inspection and installation) . . . . .	6E -73		
Throttle Body (On car inspection, removal, disassembly, cleaning, assembly and installation) . . . . .	6E -74		
Air Valve (Inspection) . . . . .	6E -77		
Fuel Injector (On car inspection, removal, inspection and installation) . . . . .	6E -78		


## GENERAL DESCRIPTION

The Electronic Fuel Injection system in this car supplies the combustion chambers with air/fuel mixture of optimized ratio under widely varying driving conditions. It uses the single-point throttle body injection system which injects fuel into the throttle body through one injector.

This system has 2 major sub-systems: air/fuel delivery system and electronic control system. Air/fuel delivery system includes fuel pump, throttle body, etc.. Electronic control system includes ECM, various sensors and controlled devices.

This section explains the system related to the electronic fuel injection as well as such functions of ECM as listed below.

- EGR control system
- Shift-up indicator light control system (If equipped)
- Throttle valve opening signal output for A/T
- ESA (Electronic Spark Advance) system






Fig. 6E-1 Electronic Fuel Injection System

1. Fuel tank
2. Fuel pump
3. Fuel filter
4. Fuel pump relay
5. Fuel injector resistor
6. Fuel injector
7. Fuel pressure regulator
8. Throttle body
9. Pressure sensor
10. WTS
11. TPS
12. Air valve
13. PCV valve
14. Power steering VSV (if equipped)
15. Intake manifold
16. Exhaust manifold
17. Oxygen sensor
18. Three-way catalyst
19. ATS
20. ISC solenoid valve
21. Air-conditioner VSV (if equipped)
22. Air-conditioner amplifier (if equipped)
23. CAS (in distributor)
24. Blank
25. Idle speed adjusting screw
26. EGR valve
27. EGR modulator
28. EGR VSV
29. BVS
30. Charcoal canister
31. Diagnosis switch terminal
32. Test switch terminal
33. ECM
34. Electric load signal
  - Radiator fan
  - Heater blower
  - Rear window defogger (if equipped)
  - Stop light
  - Headlight or small light
35. A/T control module
36. Vehicle speed sensor
37. Igniter
38. Ignition coil
39. "CHECK ENGINE" light
40. Shift-up indicator light (if equipped)
41. Main relay
42. Main switch
43. Clutch switch (M/T) or shift switch (A/T)
44. Starter magnetic switch
45. Main fuse
46. Battery
47. Power steering pressure switch (if equipped)

## AIR AND FUEL DELIVERY SYSTEM

The main components of this system are fuel tank, fuel pump, fuel filter, throttle body (including fuel injector, fuel pressure regulator and air valve), fuel feed line, fuel return line, air cleaner and ISC solenoid valve.

The fuel in the fuel tank is pumped up by the fuel pump, filtered by the fuel filter and fed under pressure to injector installed in throttle body. As the fuel pressure applied to the fuel injector (the fuel pressure in the fuel feed line) is always kept a certain amount higher than the pressure in the intake manifold by the fuel pressure regulator, the fuel is injected into the throttle body in conic dispersion when the injector opens according to the injection signal from ECM. The fuel relieved by the fuel pressure regulator returns through the fuel return line to the fuel tank.

The injected fuel is mixed with the air which has been filtered through the air cleaner in the throttle body. The air/fuel mixture is drawn through clearance between throttle valve and bore and idle bypass passage into intake manifold. Then the intake manifold distributes the air/fuel mixture to each combustion chamber.

When the engine is cold, the air is drawn through air valve bypassing the throttle valve into the intake manifold.

When ISC solenoid valve opens according to the signal from ECM, the air is drawn through hose bypassing the throttle valve into the intake manifold.

For the structure and operation of the fuel tank and filter, refer to SECTION 6C "ENGINE FUEL".




Fig. 6E-3 Air and Fuel Delivery System

**FUEL PUMP**

The electric fuel pump located in the fuel tank consists of armature, magnet, impeller, brush, check valve, etc.. The ECM controls its ON/OFF operation as described under "Fuel Pump Control System" included in later part of this section.

**Operation**

When power is supplied to the fuel pump, the motor in the pump runs and so does the impeller. This causes a pressure difference to occur between both sides of the impeller as there are many grooves around it. Then the fuel is drawn through the inlet port, and with its pressure increased it is discharged through the outlet port. The fuel pump also has a check valve to keep some pressure in the fuel feed line even when the fuel pump is stopped.




Fig. 6E-4 Fuel Pump Mounting




Fig. 6E-5 Fuel Pump Cross-Section

**THROTTLE BODY**

The throttle body consists of the main bore, air and/or fuel passage, vacuum passage (for pressure sensor, ignition timing vacuum advancer, evaporative emission control system and EGR system), air induction passage and the following parts.

- Fuel injector which injects fuel according to the signal from ECM.
- Fuel pressure regulator which maintains the fuel pressure to the injector a certain amount higher than the pressure in the intake manifold.

- Throttle valve which is interlocked with the accelerator pedal and controls the amount of the air/fuel mixture drawn into the combustion chamber.
- Air valve which supplies the bypass air when engine is cold.
- Idle speed adjusting screw which controls the amount of bypass air to adjust engine idle speed.
- TPS which detects the throttle valve opening and sends a signal to ECM.




Fig. 6E-6 Throttle Body Cross-Section

**FUEL INJECTOR**

It is an electromagnetic type injection nozzle which injects fuel in the throttle body bore according to the signal from ECM.

**Operation**

When the solenoid coil of the injector is energized by ECM, it becomes an electromagnet and attracts the plunger. At the same time, the needle valve which is incorporated with the plunger opens and the injector which is under the fuel pressure injects fuel in conic dispersion. As the lift stroke of the needle valve of the injector is set constant, the amount of fuel injected at one time is determined by the length of time during which the solenoid coil is energized (injection time).




Fig. 6E-7 Fuel Injector Cross-Section

**FUEL PRESSURE REGULATOR**

The fuel pressure regulator is diaphragm-operated relief valve consisting of diaphragm, spring and valve. It keeps the fuel pressure applied to the injector 1.8 kg/cm<sup>2</sup> (180 kPa, 25.6 psi) higher than that in the intake manifold at all times.

The pressure applied to the chamber "A" of fuel pressure regulator is intake manifold pressure and that to the chamber "B" is fuel pressure. When the fuel pressure rises more than 1.8 kg/cm<sup>2</sup> (180 kPa, 25.6 psi) higher than the intake manifold pressure, the fuel pushes the valve in the regulator open and excess fuel returns to the fuel tank via the return line.




Fig. 6E-8 Pressure Regulator Cross-Section



**AIR VALVE**

The air valve consists of thermo-wax, springs and valve.

When the engine is cold, it sends the air into the intake manifold without letting it pass through the throttle valve to increase the engine speed, and thus the engine is warmed up.

**Operation**

When the engine is cold (or engine cooling water is lower than about 80°C (176°F)), the thermo-wax contracts.

In this state, the valve opens by the spring force, allowing the air to be drawn into the intake manifold. Thus the amount of intake air increases even when the throttle valve is at the idle position and the engine speed rises to the fast idle state which is higher than the idle speed.




Fig. 6E-9 Opening Air Valve

As the engine is warmed up, the thermo-wax expands gradually, then the piston pushes down the valve gradually, and the amount of air passing through the air valve decreases and so does the engine speed. When the engine cooling water temperature reaches about 80°C (176°F), the valve is fully closed and the engine speed is back to the normal idle speed.




Fig. 6E-10 Closing Air Valve

**ISC (Idle Speed Control) SOLENOID VALVE**

The ISC solenoid valve opens and closes air by-pass passage according to the signal from ECM.

When it opens, the air is supplied to the intake manifold.




Fig. 6E-10-1 ISC Solenoid Valve Cross-Section

### ELECTRONIC CONTROL SYSTEM


The electronic control system consists of 1) various sensors which detect the state of engine and driving conditions, 2) ECM which controls various devices according to the signals from the sensors and 3) various controlled devices.

Functionally, it is divided into five sub systems:

- Fuel injection control system
- ISC solenoid valve control system
- Fuel pump control system

- EGR control system
- Shift-up indicator light control system (If equipped)
- ESA (Electronic Spark Advance) system

Also, with A/T model ECM sends throttle valve opening signal to A/T control module to control A/T.



**INFORMATION SENSORS**

- 1. Pressure sensor
- 2. TPS
- 3. ATS
- 4. WTS
- 5. Oxygen sensor
- 6. Vehicle speed sensor
- 7. A/T control module (A/T model only)
- 8. Junction/fuse block (Diagnosis switch terminal)
- 9. Igniter
- 10. Battery
- 11. CAS (in distributor)
- 12. P/S pressure switch (if equipped)

**CONTROLLED DEVICES**

- a : Fuel injector
- b : ISC solenoid valve
- c : Fuel pump relay
- d : EGR VSV
- e : "CHECK ENGINE" light
- f : Shift-up indicator light (if equipped)
- g : Igniter (Power unit)
- h : P/S VSV (if equipped)

**OTHERS**

- A : ECM
- B : Electronic Fuel Injection main relay
- C : EGR valve
- D : EGR modulator
- E : Canister
- F : Monitor coupler
- G : Injector resistor
- H : BVS
- J : Electric load diode
- K : Serial data coupler (Assembly line diag. link)
- L : A/C VSV (if equipped)

Fig. 6E-11 Parts Location




Fig. 6E-12 System Schematic




Fig. 6E-13 System Wiring Diagram

	Wire color	
1. Fuel pump relay		
2. Fuel pump	B : Black	
3. Fuel injector	B/Bl : Black/Blue	P : Pink
4. Resistor	B/G : Black/Green	P/W : Pink/White
5. ISC solenoid valve	B/R : Black/Red	R/W : Red/White
6. EGR VSV	B/W : Black/White	Sb : Skyblue
7. Power steering VSV for idle up (if equipped)	B/Y : Black/Yellow	V : Violet
8. Shift-up indicator light (if equipped)	Bl/R : Blue/Red	V/G : Violet/Green
9. "CHECK ENGINE" light	Bl/Y : Blue/Yellow	V/R : Violet/Red
10. A/T control module	Br : Brown	V/W : Violet/White
11. Serial data terminal (Assembly line diag. link)	Br/B : Brown/Black	V/Y : Violet/Yellow
12. Monitor coupler	Br/R : Brown/Red	W : White
12-1. Duty output terminal	Br/W : Brown/White	W/Bl : White/Blue
12-2. Test switch terminal	Br/Y : Brown/Yellow	W/R : White/Red
12-3. Diag. switch terminal	G : Green	Y : Yellow
12-4. Diag. output terminal	Gr : Gray	Y/B : Yellow/Black
13. Diode	Gr/W : Gray/White	Y/G : Yellow/Green
14. To radiator fan switch	Lg : Lightgreen	Y/R : Yellow/Red
15. To heater blower switch	Lg/B : Lightgreen/Black	
16. To stop light switch	Lg/R : Lightgreen/Red	
17. To lighting switch	Lg/W : Lightgreen/White	
18. To rear window defogger switch (if equipped)	Lg/Y : Lightgreen/Yellow	
19. Battery		
20. Main fuse box		
21. Main switch		
22. Clutch switch (M/T) or shift switch (A/T)		
23. Starter magnetic switch		
24. Main relay		
25. Air-conditioner amplifier (if equipped)		
26. Air-conditioner VSV (if equipped)		
27. Distributor		
27-1. Crank angle sensor		
28. Oxygen sensor		
29. Vehicle speed sensor		
30. Air temp. sensor		
31. Water temp. sensor		
32. Throttle position sensor		
32-1. Idle switch		
33. Pressure sensor		
34. Noise suppressor		
35. Ignition coil		
36. Ignitor		
37. ECM		
38. Power steering pressure switch (if equipped)		

### Electronic Control Module (ECM)

ECM is installed to the underside of the instrument panel at the driver's seat side.

ECM is a precision unit consisting of micro-computer, A/D (Analog/Digital) converter, I/O (Input/Output) unit, etc..

It is an essential part of the electronic control system, for its functions include not only such a major function as to control fuel injector, ISC solenoid valve, fuel pump relay, etc. but also self-diagnosis function and fail-safe function as described in the following section.




Fig. 6E-15 ECM Location

### Self-diagnosis function

ECM diagnoses troubles which may occur in the area including the following parts when the ignition switch is ON and the engine is running, and indicates the result by turning on or flashing "CHECK ENGINE" light.

- Oxygen sensor
- Water temp. sensor
- Throttle position sensor
- Air temp. sensor
- Pressure sensor
- Ignition fail safe signal
- Vehicle speed sensor
- EGR system (California spec. vehicle only)
- CPU (Central Processing Unit) of ECM

ECM and "CHECK ENGINE" light operate as follows.

- "CHECK ENGINE" light lights when the ignition switch is turned ON (but the engine at stop) with the diagnosis switch terminal ungrounded regardless of the condition of

Electronic Fuel Injection system. This is only to check the "CHECK ENGINE" light turns OFF.

- If the above areas of Electronic Fuel Injection system is free from any trouble after the engine start (while engine is running), "CHECK ENGINE" light turns OFF.

- When ECM detects a trouble which has occurred in the above areas, it makes "CHECK ENGINE" light turn ON while the engine is running to warn the driver of such occurrence of trouble and at the same time it stores the trouble area in ECM back-up memory.

(The memory is kept as it is even if the trouble was only temporary and disappeared immediately. And it is not erased unless the power to ECM is shut off for 60 seconds or longer.)

ECM also indicates trouble area in memory by means of flashing of "CHECK ENGINE" light at the time of inspection (i.e. when diagnosis switch terminal is grounded and ignition switch is turned ON).

### NOTE:

- When a trouble occurs in the above areas except EGR system and disappears soon while the diagnosis switch terminal is ungrounded and the engine is running, "CHECK ENGINE" light lights and remains ON as long as the trouble exists but it turns OFF when the normal condition is restored.

When it is EGR system where a trouble occurs, even if it is only a temporary one and disappears soon, "CHECK ENGINE" light remains ON till the ignition switch is turned OFF.

- Only ignition circuit trouble (code No. 41) is not stored in back-up memory of ECM. (in other words, even if ECM has detected a trouble in ignition circuit, once ignition switch is turned OFF, code No. 41 will not be indicated even when diagnosis switch terminal is grounded and ignition switch is turned ON.). Therefore, to check diagnostic code when engine fails to start, crank engine and then ground diagnostic switch terminal with ignition switch ON.




Fig. 6E-16 "CHECK ENGINE" Light Circuit

### Fail-safe function

Even when a trouble has occurred in such area of Electronic Fuel Injection system that includes the following parts and a failure signal is sent to ECM, control over the injector, ISC solenoid valve and others is maintained on the basis of the standard signals and/or back-up program prestored in the ECM while ignoring that failure signal and/or CPU. This function is called "fail-safe function". Thus, with this function, a certain level of engine performance is available even when some failure occurs in such area and disability in running is avoided.

- Water temp. sensor
- Throttle position sensor
- Vehicle speed sensor
- Air temp. sensor
- Pressure sensor
- CPU in ECM



**Pressure (intake manifold absolute pressure) Sensor (PS)**

This sensor senses pressure change in the intake manifold and converts it into voltage change. It consists of a semi-conductor type pressure converting element which converts a pressure change into an electrical change and an electronic circuit which amplifies and corrects the electric change. The ECM sends a 5-volt reference voltage to the pressure sensor. As the manifold pressure changes, the electrical resistance of the sensor also changes. By monitoring the sensor output voltage, ECM knows the manifold pressure (intake air volume).




Fig. 6E-17 Pressure Sensor

**Throttle Position Sensor (TPS)**

The throttle position sensor consisting of a contact point (idle switch) and a potentiometer is connected to the throttle valve shaft on the throttle body, and detects the throttle valve opening.

The throttle opening in the idle state is detected by means of the contact point which turns ON in that state.

But beyond that the full opening is detected by the potentiometer as follows.

A 5-volt reference voltage is applied to the sensor from ECM and as its brush moves over the print resistance according to the throttle valve opening, the output voltage varies accordingly.

By monitoring the ON/OFF signal and sensor output voltage, ECM detects the throttle valve opening.




Fig. 6E-20 Throttle Position Sensor




Fig. 6E-18 Output Characteristic




Fig. 6E-21 Output Characteristic

ECM uses the voltage signal from the pressure sensor as one of the signals to control fuel injector, ISC solenoid valve, shift-up indicator light and EGR VSV.

ECM uses the signal from TPS as one of the signals to control fuel injector, ISC solenoid valve and EGR VSV.

Also, ECM converts the voltage signal from TPS into ON/OFF signal and sends it to A/T control module, where it is used as one of the signals to control the automatic transmission.

#### Air Temperature Sensor (ATS)

Located at the side of air cleaner case, this sensor constantly measures the temperature of the air entering there and converts a change in the air temperature into that in resistance through its thermister. That is, as air temperature lowers, resistance increases and as it rises, resistance decreases. As air density of the intake air varies with variation in temperature, ECM, by monitoring the resistance, adjusts the amount of fuel injection according to the air temperature.

#### Water Temperature Sensor (WTS)

Located at the side of throttle body, this sensor measures the temperature of the engine cooling water and converts its change into that in resistance through the thermister like the air temperature sensor.

That is, as cooling water temperature lowers, resistance increases and as it rises, resistance decreases.

By monitoring the resistance of the water temperature sensor, ECM detects the engine cooling water temperature and that affects most systems under the control of ECM.




Fig. 6E-22 Air/Water Temperature Sensor Characteristic

#### Oxygen Sensor

The oxygen sensor is located on the exhaust manifold to detect the concentration of oxygen in the exhaust gases. It consists of the zirconia element (with thin platinum surface coating) which generates electromotive force, lead wire which draws out the electromotive force and cover and housing which protect the zirconia element from damage.

The zirconia element, by its property, generates the electromotive force when a difference in oxygen concentration exists between its faces. As its temperature rises, the change of the electromotive force is amplified by catalytic reaction of the platinum. The oxygen sensor makes use of this property. As atmosphere is introduced into the oxygen sensor, the inside of the zirconia element is exposed to the atmosphere and outside to exhaust gases. Thus the difference in concentration between the inside and the outside of the zirconia element varies with the oxygen concentration in the exhaust gases.

The large concentration difference results in about 1V of the electromotive force and small difference results in about 0V. To put in other words, if the amount of oxygen in the exhaust gases is less (air-fuel mixture is richer than the stoichiometric mixture), about 1V of electromotive force is generated and if more (air-fuel mixture is leaner than the stoichiometric mixture), almost none is generated.

In this way, the oxygen sensor detects whether the oxygen concentration is high or low (or the mixture is leaner or richer than the stoichiometric mixture).




Fig. 6E-23 Output Characteristic




Fig. 6E-24 Oxygen Sensor

**Vehicle Speed Sensor**

The speed sensor consisting of the lead switch and magnet is built in the speedometer. As the magnet turns with the speedometer cable, its magnetic force causes the lead switch to turn ON and OFF. Such ON/OFF frequency increases or decreases in proportion with the car speed and is sent to ECM as pulse signals.

ECM uses it as one of the signals to control the ISC solenoid valve and shift-up indicator light.




Fig. 6E-25 Vehicle Speed Sensor

**Crank Angle Sensor (CAS)**

The crank angle sensor located in the distributor consists of the signal generator (pick-up coil and magnet) and signal rotor.

As the signal rotor turns, AC voltage is generated in the pick-up coil which varies in pulsatory way as shown below. This pulse signal (4 pluses/revolution) is sent to ECM where it is used to calculate the engine speed and also as one of the signals to control various devices.




Fig. 6E-25-1 CAS

**Ignition Fail Safe Signal**

This signal is sent from the igniter. Monitoring this signal, ECM detects whether the ignition spark is emitted or not and stops injector operation when this signal is not inputted.

**Engine Start Signal**

This signal is sent from the engine starter circuit. Receiving it, ECM judges whether the engine is cranking or not and uses it as one of the signals to control the fuel injector and fuel pump relay.

### "R", "D", "2" or "L" Range Signal (A/T model only)

This signal is sent from A/T control module as a battery voltage signal only when A/T is in "R", "D", "2" or "L" range. Thus, ECM judges whether A/T is in one of the above ranges or otherwise (i.e. in "P" or "N" range) and uses it as one of the signals to control the fuel injector and ISC solenoid valve.

### Electric Load Signal

This signal is sent from each circuit of head & small (or clearance) lights, heater fan, radiator fan, stop light and rear window defogger. ECM uses it as one of the factors for controlling ISC solenoid valve operation.

### Air-Conditioner Signal (Car with air-conditioner only)

This signal is sent from the air-conditioner circuit. ECM detects whether the air-conditioner is operating or not through the signal and uses it as one of the signals for controlling ISC solenoid valve operation.

### Battery Voltage

The fuel injector is driven by its solenoid coil based upon the ECM output signal. There is some delay called as "Ineffective injection time", which doesn't provide fuel, between ECM signal and valve action. As the ineffective injection time depends on the battery voltage, ECM takes voltage information to compensate it in fuel injection time.

### Power Steering Signal (Car with power steering)

This signal is sent from the power steering pressure switch. The power steering pressure switch is installed on the power steering pump body. The switch turns ON when the oil pressure is higher than 15 – 20 kg/cm<sup>2</sup> (215 – 285 psi). The turning of the steering wheel causes increased oil pressure. ECM uses it for controlling idle up VSV operation.

### Diagnosis Switch Terminal

There are two diagnosis switch terminals; one included in the junction/fuse block and the other in the monitor coupler in the engine room. When either diagnosis switch terminal is grounded, a diagnosis signal is fed to ECM which then out-

puts self-diagnosis code and at the same time output ISC duty through duty output terminal.




Fig. 6E-26 Diagnosis and Test Switch Terminals

### NOTE:

Germany spec. model is not provided with a diagnosis switch terminal in the fuse box but instead a diagnosis switch is installed to the underside of the instrument panel as shown below.




Fig. 6E-26-1 Diagnosis Switch (Germany Spec. Model Only)

### Test Switch Terminal

The test switch terminal is included in the monitor coupler. When this terminal is grounded, ECM fix the ignition timing to initial one. When both test switch terminal and diagnosis switch terminal are grounded, ECM outputs A/F duty through the A/F duty output terminal.

**FUEL INJECTION CONTROL SYSTEM**

In this system, ECM controls the time (amount) and timing of the fuel injection from the fuel injector into the throttle body according to the signals from the various sensors so that suitable air/fuel mixture is supplied to the engine in each driving condition.

**Injection Timing**

There are two types of injection timing. One is "synchronous injection" in which injection is synchronous with the CAS signal and the other is "asynchronous injection" in which injection takes place independently of the CAS signal.

• **Asynchronous injection**

When the throttle valve is opened from its idle position, the injector injects fuel in addition to synchronous injection independently of the CAS signal.




Fig. 6E-28 Asynchronous Injection

• **Synchronous injection**

Normally, the injector injects fuel at every CAS signal. But when the engine cooling water temperature is low immediately after its start, the injection time for one ignition cycle is divided into some and injection takes place accordingly.




Fig. 6E-27 Synchronous Injection

### Injection Time (amount of injection)

The factors to determine the injection time are the basic injection time which is calculated on the basis of the engine speed and the intake manifold pressure (amount of the intake air) and

various compensations which are determined according to the signals from various sensors that detect the state of the engine and driving conditions.




Fig. 6E-29 Parameter Diagram for Fuel Injection Control System

#### Intake air temperature compensation

As the intake air volume varies with the temperature, it is compensated for its temperature.

#### Enriching compensation while engine starting

In order to improve starting performance, enriching compensation at start is carried out.

#### Enriching compensation after engine start

For a certain time after the engine is started, air/fuel mixture enriching compensation is made so as to stabilize the engine speed. The amount of compensation varies depending on the engine cooling water temperature and it is the largest immediately after the engine start and after that, it reduces gradually.

#### Enriching compensation while warming up

When the engine is cold, enriching compensation is made to ensure good driveability till the engine cooling water temperature reaches the specified level. The amount to enrich the air/fuel mixture is decreased as the temperature rises.

#### Power enriching compensation

To ensure smooth acceleration and good driveability under the high load driving condition, enriching compensation is carried out when the throttle valve opening is larger than specification.

### **Enriching compensation when accelerating**

To ensure smooth acceleration, enriching compensation is carried out when the intake manifold pressure varies by more than a specified amount during acceleration. The amount of compensation is determined according to the engine cooling water temperature and how much the intake manifold pressure varies.

### **Leaning compensation when decelerating**

To obtain a proper air/fuel mixture ratio during deceleration, leaning compensation is carried out when the intake manifold pressure varies by more than a specified amount during deceleration.

### **Battery voltage compensation**

A power voltage drop delays the mechanical operation of the injector. Then the actual injection time becomes shorter for the time that electricity is supplied to the injector. To compensate this, the electricity supply time is made longer when the voltage is lower.

### **Base air/fuel ratio compensation**

The air/fuel ratio may vary due to such factors as variation in each engine itself and aging. To compensate such variation, feed back compensation is used and base air/fuel mixture ratio is adjusted to a proper level for feed back compensation.

### **Fuel cut**

Fuel injection stops (with operation of the injector prevented) when decelerating (i.e. when the throttle valve is at idle position and the engine speed is high), so that unburned gas will not be exhausted and it starts again when above conditions are not met.

The fuel injection also stops when the engine speed exceeds about 6,800 r/min to prevent over-run which affects the engine adversely and it starts again when the engine speed reduces to less than about 6,600 r/min.

### **Leaning compensation when EGR valve is operating**

To ensure proper air/fuel mixture ratio even while EGR valve is open, leaning compensation is carried out when EGR VSV is ON.

### Air/fuel ratio feed back compensation

It is necessary to keep the air/fuel mixture close to the theoretical air/fuel ratio (14.7) to obtain efficient performance of the 3-way catalyst and high clarification rate of CO, HC and NO<sub>x</sub> in the exhaust gas. For that purpose, ECM operates as follows. It first compares the signal from the oxygen sensor with a specified reference voltage and if the signal is higher, it detects that the air/fuel ratio is richer than the theoretical air/fuel ratio and reduces fuel. On the other hand, if the signal is lower, it detects that the air/fuel ratio is leaner and increases fuel. By repeating these operations, it adjusts the air/fuel ratio closer to the theoretical air/fuel ratio.

1) When oxygen concentration in the exhaust gas is low, that is, when the air/fuel ratio is smaller than the theoretical air/fuel ratio (fuel is richer), electromotive force of the oxygen sensor increases and a rich signal is sent to ECM.

2) Upon receipt of the rich signal, ECM decreases the amount of fuel injection, which causes oxygen concentration in the exhaust gas to increase and electromotive force of the oxygen sensor to decrease. Then a lean signal is sent to ECM.

3) As ECM increases the amount of fuel injection according to the lean signal, oxygen concentration in the exhaust gas decreases and the situation is back to above 1).

This control process, however, will not take place under any of the following conditions.

- At engine start and when fuel injection is increased after engine start
- When engine cooling water temperature is low
- When highly loaded and fuel injection is increased
- At fuel cut
- When oxygen sensor is cold
- When engine is running at high speed (higher than about 4000 r/min).





Fig. 6E-30 A/F Ratio Feed Back Compensation



**FUEL PUMP CONTROL SYSTEM**

ECM controls ON/OFF operation of the fuel pump by turning it ON via the fuel pump relay under any of the following conditions.

- For 2 seconds after ignition switch ON.
- While cranking engine (while engine start signal is inputted to ECM).
- While CAS signal is inputted to ECM



- |              |                                              |
|--------------|----------------------------------------------|
| 1. Fuel tank | 7. Battery                                   |
| 2. Fuel pump | 8. Clutch switch (M/T) or shift switch (A/T) |
| 3. CAS       | 9. Main switch                               |
| 4. Blank     | 10. Main relay                               |
| 5. ECM       | 11. Fuel pump relay                          |
| 6. Starter   |                                              |

Fig. 6E-31 Fuel Pump Circuit

**ISC SOLENOID VALVE CONTROL SYSTEM**

This system controls the bypass air flow by means of ECM and ISC solenoid valve for the following three purposes.

- To keep the engine idle speed as specified at all times

The engine idle speed can vary due to following reasons.

- \* Load applied to engine (when electric load is applied, automatic transmission is shifted to "R", "D" "2" or "L" range, air-conditioner is turned ON, etc.)
- \* Variation in atmospheric pressure
- \* Change in engine itself with passage of time
- \* Other factors causing idle speed to change
- To improve starting performance of engine
- To compensate air/fuel mixture ratio when decelerating (Dash-pot effect)

**Operation**

ISC solenoid valve opens the bypass air passage when it is turned ON by ECM and closes it when turned OFF.

ECM detects the engine condition by using signals from various sensors and switches and while repeating ON and OFF cycle of ISC solenoid valve at a certain rate (12 times a second), it controls bypass air flow by increasing and decreasing its ON time within a cycle.

While the engine is cranking, ECM keeps ISC solenoid valve ON so as to obtain better start of the engine. After the engine has started, it reduces ON time gradually to maintain the idle speed as specified.

When the accelerator pedal is depressed (throttle valve is at other than idle position), ECM keeps ISC solenoid valve ON. When decelerating, on the other hand, it reduces its ON time gradually (thereby reducing the bypass air flow gradually) to adjust air/fuel mixture to an optimum ratio for combustion.

When the car is at a stop, the throttle valve is at the idle position and the engine is running, ECM controls the bypass air flow by increasing or decreasing ON time of ISC solenoid valve so that the engine speed is kept at a specified idle speed.

With an air-conditioner equipped car, when the air-conditioner is ON, a certain amount of the bypass air is supplied by the air-conditioner VSV independently of this system. The bypass air supplied by this system is used for fine control to keep the idle speed as specified.

Engine idle speed specifications at engine normal operating temperature are as follows.

(Unit: r/min)

		Air-conditioner OFF	Air-conditioner ON
M/T model		750 ± 50	900 ± 50
A/T model	At "P" or "N" range	850 ± 50	900 ± 50




Fig. 6E-32 ISC Solenoid Valve Control System

**EXHAUST GAS RECIRCULATION (EGR) CONTROL SYSTEM**

This system controls the formation of NOx emission by recirculating the exhaust gas into the combustion chamber through the intake manifold.

The EGR valve is controlled by EGR modulator and VSV controlled by ECM according to signals from various sensors.

The diaphragm mounted in the EGR modulator is operated by back pressure of the exhaust gas to open and close the valve. By this opening and closing action of the valve, the EGR modulator controls the vacuum transmitted to the EGR valve.

Under a low load condition such as low speed driving, the exhaust pressure is low. In this state, the diaphragm in the EGR modulator is pushed down by the spring force and the modulator valve opens to allow the air into the vacuum passage from the outside.

As a result, the vacuum transmitted to the EGR valve becomes smaller and so does the opening of the EGR valve.

Thus, less amount of exhaust gas is recirculated to the intake manifold.

Under a high load condition such as high speed driving, on the other hand, the exhaust pressure is high. By the high exhaust pressure, the diaphragm in the modulator is pushed up and closes its valve. As the air does not enter the vacuum passage in this state, the vacuum transmitted to the EGR valve grows larger and so does the opening of the EGR valve.

Thus, larger amount of exhaust gas is recirculated to the intake manifold.

Under any one of the following conditions, ECM closes the vacuum passage of VSV. In this state, as the vacuum is not transmitted to the EGR valve, it remains closed.

- When engine cooling water temperature is low.
- When throttle valve is at idle position.
- When engine is running under high load.
- When intake manifold pressure is low.

Other than the above, EGR valve opens and closes in accordance with the EGR modulator operation.




Fig. 6E-33 EGR System

**SHIFT-UP INDICATOR LIGHT CONTROL SYSTEM (If equipped)**

This system is intended for economical driving by using proper gear positions. When the following conditions are all met, it turns ON the shift-up indicator light included in the meter cluster, but for 5 seconds at the longest, so as to urge the driver to shift up the gear.

- Car speed is higher than 5 km/h (3.1 mile/h)
- Both idle switch and wide open switch are OFF
- Engine speed is higher than a specified speed (The specified engine speed varies with the intake manifold pressure and engine cooling water temperature.)




Fig. 6E-34 System Circuit

**THROTTLE VALVE OPENING SIGNAL OUTPUT FOR A/T**

Receiving the throttle valve opening signal from the throttle position sensor, ECM converts it into the three ON/OFF signals and sends their signals to A/T control module through A21, A9, and A22 terminals. Then A/T control module uses them as the signals to control the automatic transmission.




Fig. 6E-35 ON/OFF Signal Diagram




Fig. 6E-36 Signal Output Circuit

**ESA (ELECTRONIC SPARK ADVANCE) CONTROL SYSTEM**

This system controls electronically the time of electric current flow to ignition primary coil as well as ignition timing.

ECM judges the engine condition by using signals from various sensors, selects the most suitable electric current flow time and ignition timing for that engine condition from among those pre-stored in its memory and sends an ignition signal to the igniter (power unit).

Control of this system includes three different types as follows.

- Ignition timing control at engine start
- Ignition timing control after engine start
- Electric current flow time control




Fig. 6E-37 System Diagram

- |                         |                          |
|-------------------------|--------------------------|
| 1. ECM                  | 8. Pressure sensor       |
| 2. Igniter (power unit) | 9. Battery voltage       |
| 3. Ignition coil        | 10. Test switch terminal |
| 4. Distributor          |                          |
| 5. CAS                  |                          |
| 6. TPS                  |                          |
| 7. WTS                  |                          |

**Ignition Timing Control at Engine Start**

To obtain better starting performance of the engine at the engine start (when the engine speed is lower than 500 r/min.) ESA system sets the ignition timing to the initial ignition timing (5° BTDC).

**Ignition Timing Control After Engine Start**

The ignition timing after the engine start is determined as follows so that the spark occurs at the most suitable timing for each engine condition.

Ignition timing	=	Initial ignition timing	+	Basic ignition advance	+	Various compensating advance
-----------------	---	-------------------------	---	------------------------	---	------------------------------

When the idle switch is ON, the ignition timing is determined by adding basic ignition advance which varies according to the engine speed, water temperature compensating advance and compensating advance for idle speed stability to the initial ignition timing.

When the idle switch is OFF, the ignition timing is determined by adding basic ignition advance which varies according to the engine speed and intake manifold pressure and water temperature compensating advance to the initial ignition timing.

- **Water temperature compensating advance**

This compensation is added according to the signal from the water temperature sensor which detects the engine cooling water temperature.




Fig. 6E-37-1 Water Temp. Compensating Advance Characteristic

- **Compensating advance for idle speed stability**  
This compensation is carried out to stabilize the engine idle speed.

**Electric Current Flow Time Control**

To stabilize the secondary voltage generated in the ignition coil to a proper level, ESA system controls the time of primary current flow to the ignition coil.

**NOTE:**

The ignition timing is controlled by ECM as described above. Therefore, when checking or adjusting the ignition timing, the ignition timing must be fixed to the initial one by grounding the test switch terminal.

## DIAGNOSIS

ECM has a system self-diagnosis function as described previously (p. 6E-17).

Investigate where the trouble is by referring to "Diagnostic Flow Chart" and "Diagnostic Code" in this section.

### PRECAUTIONS IN DIAGNOSING TROUBLES IN ELECTRONIC FUEL INJECTION SYSTEM

#### [PRECAUTIONS IN IDENTIFYING DIAGNOSTIC CODE]

- Before identifying diagnostic code indicated by "CHECK ENGINE" light, don't disconnect couplers from ECM, battery cable from battery, ECM ground wire harness from engine or main fuse.

Such disconnection will erase memorized trouble in ECM memory.

- If abnormality or malfunction lies in two or more areas, "CHECK ENGINE" light indicates applicable codes three times each.

And flashing of these codes is repeated as long as diagnosis switch terminal is grounded (spare fuse is connected) and ignition switch is held at ON position.

- Take a note of diagnostic code indicated first.

#### [INTERMITTENT TROUBLES]

- There are cases where "CHECK ENGINE" light indicates a diagnostic code representing a trouble which occurred only temporarily and has gone. In such case, it may occur that good parts are replaced unnecessarily. To prevent such an accident, be sure to follow instructions given below when checking by using "Diagnostic Flow Chart".

\* When trouble can be identified, that is, it is not an intermittent one:

Check sensor (actuator), wires and each connection and if they are all in good condition, substitute a known-good ECM and recheck.

\* When trouble can not be identified but "CHECK ENGINE" light indicates a trouble code:

Diagnose trouble by using that code No. and if sensor (actuator), wires and each connection are all in good condition, erase diagnostic code in ECM memory. Then conduct a test run and check what "CHECK ENGINE" light indicates. Only when it indicates trouble code again, substitute a known-good ECM and check again.

If it indicates not trouble code but normal code No. 12, it means that an intermittent trouble did occur and has gone. In this case, check wires and connections carefully again.

#### [NOTES ON SYSTEM CIRCUIT INSPECTION]

- Intermittent troubles
  - Most intermittent problems are caused by faulty electrical connections or wiring. Perform careful check of suspect circuits for:
    - Poor mating of coupler halves, or terminals not fully seated in coupler body (backed out).
    - Improperly formed or damaged terminals. All coupler terminals in problem circuit should be carefully reformed to increase contact tension.
    - Poor terminal to wire connection.
- Never connect any tester (voltmeter, ohmmeter, or whatever) to ECM when its coupler is disconnected. Attempt to do it may cause damage to ECM.
- Never connect an ohmmeter to ECM with its coupler connected to it. Attempt to do it may cause damage to ECM and sensors.
- Be sure to use a voltmeter with high impedance ( $M\Omega/V$  minimum) or a digital type voltmeter. Any other voltmeter should not be used because accurate measurements are not obtained.

- When disconnecting and connecting coupler, make sure to turn ignition switch OFF.
- When checking connection of terminals, check its male half for bend and female half for excessive opening and both for locking (looseness), corrosion, dust, etc.
- When connecting a probe of ohmmeter, voltmeter, etc. to coupler terminal, be sure to connect it from wire harness side of coupler.




Fig. 6E-38 Connecting Meter Probe

- When connecting meter probe from terminal side of coupler because it can't be connected from harness side, use extra care not to bend male terminal of coupler or force its female terminal open for connection. In case of such coupler as shown below, connect probe as shown below to avoid opening female terminal. Never connect probe where male terminal is supposed to fit.




Fig. 6E-39 Connecting Meter Probe

- Before measuring voltage at each terminal, check to make sure that battery voltage is 11V or higher. Such terminal voltage check at low battery voltage will lead to erroneous diagnosis.




Fig. 6E-40 Checking Battery Voltage



- When checking voltage at each terminal of the coupler which is connected to ECM, be sure to connect negative probe to body ground and using service wire, connect ECM case to body ground as shown in Fig. 6E-41. Any other way is prohibited even by accident. Applying probes of voltmeter improperly may cause the sensor or ECM to be shorted and damaged.




Fig. 6E-41 Checking Voltage




Fig. 6E-41-1 ECM Coupler Terminals

### DIAGNOSTIC FLOW CHART





Fig. 6E-42 Diagnostic Flow Chart for Electronic Fuel Injection System

DIAGNOSTIC CODE TABLE

EXAMPLE: THROTTLE POSITION SENSOR FAILURE (CODE NO. 21)




DIAGNOSTIC CODE		DIAGNOSTIC AREA	DIAGNOSIS
NO.	MODE		
12		Normal	This code appears when none of the other codes (Below codes) are identified.
13		Oxygen sensor	
14		Water temperature sensor	
15			
21		Throttle position sensor	
22			
23		Air temperature sensor	
25			
24		Vehicle speed sensor	
31		Pressure sensor	
32			
41		Ignition fail safe signal	
42		Crank angle sensor	
51		EGR system (California spec. model only)	
ON		ECM	ECM failure

Diagnose trouble according to "DIAGNOSTIC FLOW CHART" corresponding to each code No.

Fig. 6E-43 Diagnostic Code Table


**A-1 ECM POWER AND GROUND CIRCUIT CHECK**

(“CHECK ENGINE” LIGHT DOESN’T LIGHT AT IGNITION SWITCH ON AND ENGINE DOESN’T START THOUGH IT IS CRANKED UP.)



- 1. Main fuse box
- 2. Ignition switch
- 3. Circuit fuse
- 4. Main relay
- 5. ECM
- 6. ECM ground
- 7. Ground
- 8. Intake manifold
- 9. ISC solenoid valve

Fig. 6E-44 ECM Power and Ground Circuit



To be continued




Fig. 6E-45 Diagnostic Flow Chart A-1 for ECM Power and Ground Circuit

**A-2 "CHECK ENGINE" LIGHT CIRCUIT CHECK**  
 ("CHECK ENGINE" LIGHT DOES NOT LIGHT BUT ENGINE STARTS.)




Fig. 6E-46 "CHECK ENGINE" Light Circuit





Fig. 6E-47 Diagnostic Flow Chart A-2 for "CHECK ENGINE" Light Circuit

**A-3 "CHECK ENGINE" LIGHT CIRCUIT CHECK**

("CHECK ENGINE" LIGHT DOESN'T FLASH OR JUST REMAINS ON EVEN WITH SPARE FUSE CONNECTED TO DIAGNOSIS SWITCH TERMINAL.)



- 1. Combination meter
- 2. "CHECK ENGINE" light
- 3. ECM
- 4. Diagnosis switch terminal
- 5. Monitor coupler
- 6. Body ground

Fig. 6E-48 "CHECK ENGINE" Light Circuit




Fig. 6E-49 Diagnostic Flow Chart A-3 for "CHECK ENGINE" Light Circuit

CODE NO. 13 OXYGEN SENSOR CIRCUIT (SIGNAL VOLTAGE DOESN'T CHANGE)




Fig. 6E-50 Oxygen Sensor Circuit

NOTE:

- Before diagnosing trouble according to flow chart given below, check to make sure that following system and parts other than Electronic Fuel Injection system are in good condition.
  - Air cleaner (clogged)
  - Vacuum leaks (air inhaling)
  - Spark plugs (contamination, gap)
  - High-tension cords (crack, deterioration)
  - Distributor rotor or cap (wear, crack)
  - Ignition timing
  - Engine compression
  - Any other system and parts which might affect A/F mixture or combustion.
- If code No. 13 and another code No. are indicated together, the latter has priority. Therefore, check and correct what is represented by that code No. first and then proceed to the following check.
- Be sure to use a voltmeter with high impedance ( $M\Omega/V$  minimum) or digital type voltmeter for accurate measurement.





Fig. 6E-51 Diagnostic Flow Chart for Code No. 13

**CODE NO. 14 WTS (WATER TEMPERATURE SENSOR) CIRCUIT (LOW TEMPERATURE INDICATED, SIGNAL VOLTAGE HIGH)**



- 1. ECM
- 2. WTS
- 3. WTS coupler
- 4. ECM coupler
- 5. To other sensors

Fig. 6E-52 WTS Circuit

**NOTE:**

When Code Nos. 14, 23 and 32 are indicated together, it is possible that "Lg/B" wire is open or A25 terminal connection is poor.




Fig. 6E-53 Diagnostic Flow Chart for Chart for Code No. 14



CODE NO. 15 WTS (WATER TEMPERATURE SENSOR) CIRCUIT (HIGH TEMPERATURE INDICATED, SIGNAL VOLTAGE LOW)




Fig. 6E-54 WTS Circuit





Fig. 6E-55 Diagnostic Flow Chart for Code No. 15

CODE NO. 21 TPS (THROTTLE POSITION SENSOR) CIRCUIT (SIGNAL VOLTAGE HIGH)



- 1. ECM
- 2. ECM coupler
- 3. TPS
- 4. TPS coupler
- 5. To PS
- 6. To other sensors

**NOTE:**  
Be sure to turn OFF ignition switch for this check.

Fig. 6E-58 TPS Circuit




Fig. 6E-59 Diagnostic Flow Chart for Code No. 21

CODE NO. 22 TPS (THROTTLE POSITION SENSOR) CIRCUIT (SIGNAL VOLTAGE LOW)




Fig. 6E-60 TPS Circuit




Fig. 6E-61 Diagnostic Flow Chart for Code No. 22

CODE NO. 23 ATS (AIR TEMPERATURE SENSOR) CIRCUIT (LOW TEMPERATURE INDICATED, SIGNAL VOLTAGE HIGH)




Fig. 6E-62 ATS Circuit




Fig. 6E-63 Diagnostic Flow Chart for Code No. 23

CODE NO. 25 ATS (AIR TEMPERATURE SENSOR) CIRCUIT (HIGH TEMPERATURE INDICATED, SIGNAL VOLTAGE LOW)




Fig. 6E-64 ATS Circuit





Fig. 6E-65 Diagnostic Flow Chart for Code No. 25

**CODE NO. 24 VEHICLE SPEED SENSOR (SPEED SENSOR SIGNAL NOT INPUTTED ALTHOUGH FUEL IS KEPT CUT AT LOWER THAN 4000 r/min FOR LONGER THAN 4 SECONDS)**



- 1. ECM
- 2. ECM coupler
- 3. Speed sensor
- 4. Speedometer
- 5. Coupler

**NOTE:**  
Be sure to turn OFF ignition switch for this check.

Fig. 6E-66 Speed Sensor Circuit




Fig. 6E-67 Diagnostic Flow Chart for Code No. 24

**CODE NO. 31 PS (PRESSURE SENSOR) CIRCUIT (SIGNAL VOLTAGE LOW – LOW PRESSURE – HIGH VACUUM)**




Fig. 6E-68 PS Circuit





Fig. 6E-69 Diagnostic Flow Chart for Code No. 31

**CODE NO. 32 PS (PRESSURE SENSOR) CIRCUIT (SIGNAL VOLTAGE HIGH – HIGH PRESSURE – LOW VACUUM)**



- 1. ECM
- 2. ECM coupler
- 3. PS
- 4. PS coupler
- 5. To TPS
- 6. To other sensors

Fig. 6E-70 PS Circuit





Fig. 6E-71 Diagnostic Flow Chart for Code No. 32



CODE NO. 41 IGNITION FAIL SAFE SIGNAL (IGNITION FAIL SAFE SIGNAL NOT INPUTTED) CIRCUIT



1. ECM
2. ECM coupler
3. Igniter (power unit)
4. Noise suppressor
5. Ignition coil

Fig. 6E-72 Ignition Fail Safe Signal Circuit




Fig. 6E-72-1 Diagnostic Flow Chart for Code No. 41



CODE NO. 51 EGR SYSTEM (FAULTY EGR SYSTEM)

For California spec. model only




Fig. 6E-74 EGR System




Fig. 6E-75 Diagnostic Flow Chart for Code No. 51 (California Spec. Model Only)

## TROUBLE DIAGNOSIS

This section describes trouble diagnosis of Electronic Fuel Injection system parts whose trouble is not indicated by the self-diagnosis function.

When diagnostic code No. 12 is indicated by the self-diagnosis function and assuredly those engine basic parts as described in "ENGINE DIAGNOSIS" are all in good condition, check below Electronic Fuel Injection system parts which may be a possible cause for each symptom of the engine.

SYMPTOM	POSSIBLE CAUSE	INSPECTION
<p><b>Hard or no starting (Engine cranks OK)</b></p>	<ul style="list-style-type: none"> <li>● Shortage of fuel in fuel tank</li> <li>● Injector or its circuit faulty</li> <li>● Faulty fuel pump or its circuit open</li> <li>● Fuel pressure out of specification</li> <li>● Faulty air valve</li> <li>● Engine start signal not to fed</li> <li>● Poor performance of ATS, WTS or pressure sensor</li> <li>● Faulty ECM</li> </ul>	<p>Diagnostic flow chart B-1 Diagnostic flow chart B-2 Diagnostic flow chart B-3 See p. 6E-77 Diagnostic flow chart B-5 See p. 6E-84 or 6E-81  See p. 6E-65</p>
<p><b>NOTE:</b></p> <ul style="list-style-type: none"> <li>● If engine doesn't start at all, perform fuel injector and its circuit check first. (Advance to "Diagnostic Flow Chart B-1".)</li> <li>● If engine is hard to start only when it is cold, check air valve first.</li> </ul>		
<p><b>Engine fails to idle</b></p>	<ul style="list-style-type: none"> <li>● Shortage of fuel in fuel tank</li> <li>● Faulty ISC solenoid valve control system</li> <li>● Maladjusted idle speed adjusting screw</li> <li>● Faulty air valve</li> <li>● Faulty EGR system</li> <li>● Fuel pressure out of specification</li> <li>● Faulty injector</li>   <li>● Poor performance of ATS, WTS or pressure sensor</li> <li>● Faulty ECM</li> </ul>	<p>Diagnostic flow chart B-4 See p. 6E-69 See p. 6E-77 See p. 6E-89 Diagnostic flow chart B-3 Check injector for resistance and injection condition (Refer to p. 6E-78) See p. 6E-84 or 6E-81  See p. 6E-65</p>
<p><b>NOTE:</b> If engine fails to idle only when it is cold, check air valve.</p>		

SYMPTOM	POSSIBLE CAUSE	INSPECTION
<b>Improper engine idle speed</b>	<ul style="list-style-type: none"> <li>● Maladjusted accelerator cable play</li> <li>● Clogged pressure sensor vacuum passage</li> <li>● Faulty ISC solenoid valve control system</li> <li>● Faulty air-conditioner VSV control system (if equipped)</li> <li>● Faulty power steering VSV (if equipped)</li> <li>● Faulty idle switch (in TPS)</li> <li>● Maladjusted idle speed adjusting screw</li> <li>● Faulty air valve</li> <li>● Fuel pressure out of specification</li> <li>● Poor performance of ATS, WTS or pressure sensor</li> <li>● Faulty ECM</li> </ul>	<p>See p. 6E-69</p> <p>Check vacuum hose and filter</p> <p>Diagnostic flow chart B-4</p> <p>See section 1B</p> <p>See p. 6E-93</p> <p>See p. 6E-82</p> <p>See p. 6E-69</p> <p>See p. 6E-77</p> <p>Diagnostic flow chart B-3</p> <p>See p. 6E-84 or 6E-81</p> <p>See p. 6E-65</p>
<p><b>NOTE:</b></p> <p>If engine idle speed lowers below specification only when electric load is applied (e.g. headlight ON), check ISC solenoid valve control system first.</p>		
<b>Engine has no or poor</b>	<ul style="list-style-type: none"> <li>● Maladjusted accelerator cable play</li> <li>● Faulty EGR system</li> <li>● Fuel pressure out of specification (Low fuel pressure)</li> <li>● Poor performance of TPS, ATS, WTS or pressure sensor</li> <li>● Faulty ECM</li> </ul>	<p>See p. 6E-69</p> <p>See p. 6E-89</p> <p>Diagnostic flow chart B-3</p> <p>See p. 6E-82, 6E-84 or 6E-81</p> <p>See p. 6E-65</p>
<b>Engine hesitates when accelerating</b>	<ul style="list-style-type: none"> <li>● Clogged pressure sensor vacuum passage</li> <li>● Faulty EGR system</li> <li>● Fuel pressure out of specification (Low fuel pressure)</li> <li>● Poor performance of TPS, ATS or WTS pressure sensor</li> <li>● Faulty ECM</li> </ul>	<p>Check vacuum hose and filter</p> <p>See p. 6E-89</p> <p>Diagnostic flow chart B-3</p> <p>See p. 6E-82, 6E-84 or 6E-81</p> <p>See p. 6E-65</p>
<b>Surges (Variation in car speed is felt although accelerator pedal is not operated)</b>	<ul style="list-style-type: none"> <li>● Variable fuel pressure (Clogged fuel filter, faulty fuel pressure regulator, etc.)</li> <li>● Poor performance of pressure sensor</li> <li>● Faulty ECM</li> </ul>	<p>Diagnostic flow chart B-3</p> <p>See p. 6E-81</p> <p>See p. 6E-65</p>

SYMPTOM	POSSIBLE CAUSE	INSPECTION
<b>Poor gasoline mileage</b>	<ul style="list-style-type: none"> <li>● High idle speed</li> <li>● Fuel pressure out of specification or fuel leakage</li> <li>● Poor performance of TPS, ATS or WTS</li> <li>● Faulty ECM</li> </ul>	<p>Refer to item "Improper engine idle speed" previously outlined</p> <p>Diagnostic flow chart B-3</p> <p>See p. 6E-82 or 6E-84</p> <p>See p. 6E-65</p>
<b>Excessive hydrocarbon (HC) emission</b>	<ul style="list-style-type: none"> <li>● Engine not at normal operating temperature</li> <li>● Clogged air cleaner</li> <li>● Faulty ignition system</li> <li>● Vacuum leaks</li> <li>● Low compression</li> <li>● Lead contamination of catalytic converter</li> <li>● Fuel pressure out of specification</li> <li>● A/F feed back compensation fails               <ul style="list-style-type: none"> <li>– Faulty TPS</li> <li>– Poor performance of WTS or pressure sensor</li> </ul> </li> <li>● Poor performance of ATS</li> <li>● Faulty injector</li> <li>● Faulty ECM</li> </ul>	<p>See section 6F1</p> <p>See section 6</p> <p>Check for absence of filler neck restrictor</p> <p>Diagnostic flow chart B-3</p> <p>See p. 6E-82</p> <p>See p. 6E-84 or 6E-81</p> <p>See p. 6E-84</p> <p>See p. 6E-78</p> <p>See p. 6E-65</p>
<b>Excessive carbon monoxide (CO)</b>	<ul style="list-style-type: none"> <li>● Engine not at normal operating temperature</li> <li>● Clogged air cleaner</li> <li>● Faulty ignition system</li> <li>● Low compression</li> <li>● Lead contamination of catalytic converter</li> <li>● Fuel pressure out of specification</li> <li>● A/F feed back compensation fails               <ul style="list-style-type: none"> <li>– Faulty TPS</li> <li>– Poor performance of WTS or pressure sensor</li> </ul> </li> <li>● Poor performance of ATS</li> <li>● Faulty injector</li> <li>● Faulty ECM</li> </ul>	<p>See section 6F1</p> <p>See section 6</p> <p>Check for absence of filler neck restrictor</p> <p>Diagnostic flow chart B-3</p> <p>See p. 6E-82</p> <p>See p. 6E-84 or 6E-81</p> <p>See p. 6E-84</p> <p>See p. 6E-78</p> <p>See p. 6E-65</p>

SYMPTOM	POSSIBLE CAUSE	INSPECTION
<b>Excessive nitrogen oxides (NOx) emission</b>	<ul style="list-style-type: none"><li>● Improper ignition timing</li><li>● Lead contamination of catalytic converter</li> <li>● Faulty EGR system</li><li>● Fuel pressure out of specification</li><li>● A/F feed back compensation fails<ul style="list-style-type: none"><li>– Faulty TPS</li><li>– Poor performance of WTS or pressure sensor</li></ul></li><li>● Poor performance of ATS</li><li>● Faulty injector</li><li>● Faulty ECM</li></ul>	See section 6F1 Check for absence of filler neck restrictor See p. 6E-89 Diagnostic flow chart B-3  See p. 6E-82 See p. 6E-84 or 6E-81  See p. 6E-84 See p. 6E-78 See p. 6E-65

**B-1 FUEL INJECTOR AND ITS CIRCUIT CHECK (ENGINE NOT STARTING)**





Fig. 6E-76 Injector Circuit



To be continued






Fig. 6E-77 Diagnostic Flow Chart B-1 for Injector and Its Circuit

**B-2 FUEL PUMP AND ITS CIRCUIT CHECK**




Fig. 6E-78 Fuel Pump Circuit





Fig. 6E-79 Diagnostic Flow Chart B-2 for Fuel Pump and Its Circuit Check

B-3 FUEL PRESSURE CHECK



- 1. Fuel pump
- 2. Fuel filter
- 3. Throttle body
- 4. Fuel injector
- 5. Fuel pressure regulator
- 6. Special tool (Fuel pressure gauge & 3-way joint)
- 7. Fuel feed line
- 8. Fuel return line

Fig. 6E-80 Fuel Pressure Check




Fig. 6E-81 Diagnostic Flow Chart B-3 for Fuel Pressure (1)

B-3 FUEL PRESSURE CHECK (continued)




Fig. 6E-81-1 Diagnostic Flow Chart B-3 for Fuel Pressure (2)

B-4 ISC SOLENOID VALVE CONTROL SYSTEM CHECK




Fig. 6E-82 ISC Solenoid Valve Circuit




Fig. 6E-82-1 Diagnostic Flow Chart B-4 for ISC Solenoid Valve Control System (1)

**B-4 ISC SOLENOID VALVE CONTROL SYSTEM CHECK (Continued)**




Fig. 6E-82-2 Diagnostic Flow Chart B-4 for ISC Solenoid Valve Control System (2)

**B-5 ENGINE START SIGNAL CHECK**




Fig. 6E-84 Engine Start Signal Circuit




Fig. 6E-85 Engine Start Signal Check

**B-6 "R", "D", "2" OR "L" RANGE SIGNAL CHECK (A/T MODEL ONLY)**




Fig. 6E-86 "R", "D", "2" or "L" Range Signal Circuit




Fig. 6E-87 "R", "D", "2" or "L" Range Signal Check (A/T Model Only)

**INSPECTION OF ECM AND ITS CIRCUITS**

ECM and its circuits can be checked at ECM wiring couplers by measuring voltage and resistance.

**CAUTION:**  
ECM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ECM with couplers disconnected from it.

**Voltage Check**

1. Remove ECM from body referring to p. 6E-80.
2. Connect ECM couplers to ECM.
3. Using service wire, ground ECM case.
4. Check voltage at each terminal of couplers connected.

**NOTE:**

As each terminal voltage is affected by the battery voltage, confirm that it is 11V or more when ignition switch is ON.




Fig. 6E-88 Checking Voltage




Fig. 6E-89 ECM Coupler Terminals



**6E-66 ELECTRONIC FUEL INJECTION SYSTEM**

TERMINAL	CIRCUIT	NORMAL VOLTAGE	CONDITION
A1	Ignition trigger signal	—	—
A2	Injector	10 – 14V	Ignition switch ON
A3	Blank	—	—
A4	ISC solenoid valve	0.9 – 1.5V	Ignition switch ON
A5	EGR VSV	10 – 14V	Ignition switch ON
A6	"CHECK ENGINE" light	1.1 – 2.0V	Ignition switch ON
		10 – 14V	When engine running
A7	Blank	—	—
A8	Shift-up indicator light	1 – 2V	Ignition switch ON
		10 – 14V	When engine running
A9 (A/T model only)	A/T control module (Throttle valve opening signal)	10 – 14V ↑ ↓ 0.2 – 0.4V	Ignition switch ON Voltage varies as specified at the left while throttle valve is opened gradually. (Refer to Fig. 6E-157 for relations between opening and voltage)
A10	Engine start switch (Engine start signal)	6 – 12V	While engine cranking
		0V	Other than above
A11	Test switch terminal	10 – 14V	Ignition switch ON
A12	Ground	0V	Ignition switch ON
A13	Power source	10 – 14V	Ignition switch ON
A14	Ignition fail safe signal	—	—
A15	Ground	0V	Ignition switch ON
A16	Blank	—	—
A17	Fuel pump relay	0.5 – 1.8V	For 2 seconds after ignition switch ON
		10 – 14V	After the above time
A18	P/S VSV (if equipped)	10 – 14V	Ignition switch ON
A19	Duty output terminal	0V	Ignition switch ON
A20	Blank	—	—
A21, A22 (A/T model only)	A/T control module (Throttle valve opening signal)	10 – 14V ↑ ↓ 0.2 – 0.4V	Ignition switch ON Voltage varies as specified at the left while throttle valve is opened gradually. (Refer to Fig. 6E-157 for relations between opening and voltage)
A23	Power steering pressure switch (if equipped)	10 – 14V	Ignition switch ON
		0 – 1V	With engine running at idle speed, turning steering wheel to the right and left as far as it stops, repeating it a few times.
A24	Diagnosis switch terminal	10 – 14V	Ignition switch ON
A25	Ground for sensors	0V	Ignition switch ON
A26	Power source for back-up circuit	10 – 14V	Ignition switch ON and OFF

TER-MINAL	CIRCUIT	NORMAL VOLTAGE	CONDITION
B1	Power source of sensor (PS and TPS)	4.75–4.25V	Ignition switch ON
B2	Pressure sensor	3.5 – 4.1V	Ignition switch ON Barometric pressure: 760 mmHg
B3	Oxygen sensor	Indicator deflection repeated between over and under 0.45V	While engine running at 2,000 r/min for 1 minute or longer after warmed up
B4	Blank	—	—
B5	A/C circuit (if equipped)	10 – 14V	Ignition switch ON
		0 – 0.6V	While engine running at idle speed and A/C ON
B6	Electric load signal	0V	Ignition switch ON Headlight, small light, heater fan, radiator fan, stop light and rear window defogger all turned OFF
		10 – 14V	Ignition switch ON Headlight, small light, heater fan, radiator fan, stop light or rear window defogger turned ON
B7	Idle switch (in TPS)	0V	Ignition switch ON Throttle valve at idle position
		10 – 14V	Ignition switch ON Throttle valve opens larger than idle position
B8	Crank angle sensor (positive)	0.4 – 0.8V	Ignition switch ON
B9	Air temp. sensor	2.0 – 2.7V	Ignition switch ON Sensor ambient temp. (Intake air temp.): 20°C (68°F)
B10	Water temp. sensor	0.45–0.85V	Ignition switch ON Engine cooling water temp.: 80°C (176°F)
B11	Throttle position sensor	0.18–1.03V	Ignition switch ON Throttle valve at idle position
		3.27–4.58V	Ignition switch ON Throttle valve at full open position
B12	Blank	—	—
B13	Serial data terminal	4 – 5V	Ignition switch ON
B14 (A/T model only)	A/T control module ("R", "D", "2" or "L" range signal)	0V	Ignition switch ON, Selector lever in "P" or "N" range position
		10 – 14V	Ignition switch ON, Selector lever in "R", "D", "2" or "L" range position
B15	Vehicle speed sensor	Indicator deflection repeated 0V and 10 – 14V	Ignition switch ON Front left tire turned slowly with front right tire locked
B16	Crank angle sensor (negative)	0.4 – 0.8V	Ignition switch ON

**Resistance Check**

1. Disconnect ECM couplers from ECM with ignition switch OFF.

**CAUTION:**  
 Never touch terminals of ECM itself or connect voltmeter or ohmmeter.

2. Check resistance between each terminal of couplers disconnected.

**CAUTION:**

- Be sure to connect ohmmeter probe from wire harness side of coupler.
- Be sure to turn OFF ignition switch for this check.
- Resistance in below table represents that when parts temperature is 20°C (68°F).




Fig. 6E-90 Checking Resistance

TERMINALS	CIRCUIT	NORMAL RESISTANCE	CONDITION	
A2 – A13	Injector and resistor	2.4 – 3.6 Ω	—	
A4 – A13	ISC solenoid valve	30 – 33 Ω	—	
A5 – A13	EGR VSV	33 – 39 Ω	—	
A11 – Body ground	Test switch terminal	Continuity	Test switch terminal grounded	
		∞ (Infinity)	Test switch terminal ungrounded	
A15 – Body ground	ECM ground	Continuity	—	
A17 – A18	Fuel pump relay and power steering VSV (if equipped)	89 – 123 Ω	—	
A24 – Body ground	Dia. switch terminal	Continuity	Diag. switch terminal grounded	
		∞ (Infinity)	Diag. switch terminal ungrounded	
B7 – A25	Idle switch in TPS	Continuity	Throttle valve at idle position	
		∞ (Infinity)	Throttle valve opens larger than idle position	
B8 – B16	Crank angle sensor	140 – 180 Ω	—	
B9 – A25	ATS	2.21 – 2.69 kΩ	Intake air temp. 20°C (68°F)	
B10 – A25	WTS	290 – 354 Ω	Engine cooling water temp. 80°C (176°F)	
B11 – A25	TPS	0.20–11.42 kΩ	Throttle valve at idle position	With pressure sensor sensor coupler disconnected
		3.03–17.08 kΩ	Throttle valve at full open position	
B15 – Body ground	Vehicle speed sensor	Ohmmeter indicator deflects between 0 and ∞	Front left tire turned slowly with front right tire locked	

## ON CAR SERVICE

### GENERAL

When hoses have been disconnected and system's component removed for service, be sure to reinstall component properly, and route and connect hose correctly after service. Refer to Emission Control Information Label for proper connection of hoses.

### ACCELERATOR CABLE ADJUSTMENT

Check accelerator cable for play and adjust if necessary.

Cable play should be within specification. If out of specification, loosen accelerator cable lock nut and adjust by turning adjusting nut. Be sure to tighten lock nut securely after adjustment.

Accelerator cable play	3 – 5 mm (0.12 – 0.20 in.)
------------------------	-------------------------------




Fig. 6E-91 Accelerator Cable Play

### IDLE SPEED/ISC DUTY ADJUSTMENT (INCLUDING AIR-CONDITIONER VSV ADJUSTMENT)

Before idle speed/ISC duty and adjustment, make sure to the following.

- Lead wires and hoses of Electronic Fuel Injection and engine emission control systems are connected securely.
- Accelerator cable has some play, that is, it is not tight.
- Ignition timing is within specification.

- All of electrical loads except ignition are switched off.
  - Air-conditioner is OFF, if equipped.
- After above items are all confirmed, check idle speed and ISC duty as follows.

### NOTE:

Before starting engine, place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake and block drive wheels.

1. Warm up engine to normal operating temperature.
2. Set tachometer
3. Using service wire, ground "Diagnosis switch terminal" in monitor coupler so that ECM outputs ISC duty through "Duty output terminal" and make sure that "CHECK ENGINE" light indicate diagnostic code No. 12.




Fig. 6E-92 Grounding Diag. Switch Terminal

- Connect duty meter between "Duty output terminal" and "Ground terminal" of monitor coupler.




Fig. 6E-92-1 Connecting Duty Meter

**NOTE:**

When using duty meter which indicates OFF duty, adjust so that it indicates 70%. Then ISC duty (ON duty) is adjusted to above specified value (30%).




Fig. 6E-93 Idle Speed Adjusting Screw

- Check to ensure that idle speed and ISC duty are specification. If ISC duty and/or idle speed is not within specified range, adjust it by turning idle speed adjusting screw.

	ENGINE IDLE SPEED	ISC DUTY AT SPECIFIED IDLE SPEED
M/T MODEL	750 ± 50 r/min	30 ± 5% (ON duty meter indication) or 4.2 ± 0.7V when battery voltage is 14V
A/T MODEL	850 ± 50 r/min	

**NOTE:**

ISC duty can be checked by using analog type voltmeter. ISC duty to voltage relation is as follows.

ON DUTY METER INDICATION (%)	OFF DUTY METER INDICATION (%)	VOLTMETER INDICATION (V)
0	100	0
25	75	0.25 × V <sub>B</sub>
35	65	0.35 × V <sub>B</sub>
100	0	V <sub>B</sub>

- "OFF DUTY METER" is such duty meter that indicates approx. 100% when terminal voltage is approx. "0V".
- "V<sub>B</sub>" represents battery voltage while engine of vehicle being checked is running.

- Upon completion of adjustment, install adjusting screw cap to throttle body.
- This step is for checking and/or adjusting engine idle speed and ISC duty when air-conditioner is working.

With cars without air conditioner, advance to steps 8. With air-conditioner equipped ones, follow procedure described below.

- Turn air-conditioner switch ON and set heater blower switch to high (max.) speed position. Then check that air-conditioner is working.
- Check to ensure that idle speed and ISC duty are specification respectively.

**NOTE:**

Specified values used for this inspection and adjustment vary depending on types of ECM as listed in tables below. Types of ECM can be identified by the last number of ECM part No.




Fig. 6E-93-1

When ECM part No. ends with "0"

	IDLE SPEED WITH A/C ON AND DIAG. SWITCH TERMINAL GROUNDED	ISC DUTY
M/T MODEL	750 ± 50 r/min	10 – 20% (ON duty meter indication) or 1.4 – 2.8V when battery voltage is 14V
A/T MODEL	850 ± 50 r/min	

When ECM part No. ends with No. other than "0"

	IDLE SPEED WITH A/C ON AND DIAG. SWITCH TERMINAL GROUNDED	ISC DUTY
ALL MODELS	900 ± 50 r/min	20% (ON duty meter indication) or 2.8V when battery voltage is 14V

3) If idle speed and/or ISC duty is not within specified range, adjust it by turning adjusting screw of air-conditioner VSV.




Fig. 6E-94 Adjusting Screw for Air-Con. VSV

8. Upon completion of adjustment, disconnect service wire from monitor coupler and install cap to monitor coupler.

9. Check that specified idle speed is obtained with A/C ON and "Diag. switch terminal" ungrounded. (Car with air conditioner only)

ALL MODELS	IDLE SPEED WITH A/C ON AND DIAG. SWITCH TERMINAL UNGROUNDED
	900 ± 50 r/min

## AIR AND FUEL DELIVERY SYSTEM

### FUEL PRESSURE INSPECTION

1. Relieve fuel pressure according to procedure described in Section 6.
2. Separate air cleaner assembly from throttle body and shift its position.
3. Disconnect fuel feed hose from throttle body.

#### CAUTION:

A small amount of fuel may be released after fuel line is disconnected.

In order to reduce chance of personal injury, cover fitting to be disconnected with a shop cloth. Place that cloth in an approved container when disconnection is completed.

4. Connect special tool (fuel pressure gauge, hose & 3-way joint) between throttle body and fuel feed hose, and clamp hoses securely to ensure no leaks occur during checking.




Fig. 6E-95 Connecting Fuel Pressure Gauge

5. Install air cleaner assembly to throttle body and cylinder head cover.
6. Start engine and warm it up to normal operating temperature.

If engine doesn't start, operate fuel pump according to following procedure.

- 1) Remove fuel pump relay from main fuse box after disconnecting its coupler and then reconnect coupler to fuel pump relay.




Fig. 6E-96 Removing Fuel Pump Relay

- 2) To operate fuel pump, connect Pink and White/Blue wire terminals by using service wire and then turn ON ignition switch.

**NOTE:**

Check that battery voltage is 11V or more before operating fuel pump.




Fig. 6E-97 Operating Fuel Pump

7. Measure fuel pressure under each of the following conditions.

CONDITION	FUEL PRESSURE
At specified idle speed	0.9 – 1.4 kg/cm <sup>2</sup> 90 – 140 kPa 12.8 – 20.0 psi
With fuel pump operating and engine at stop	1.6 – 2.1 kg/cm <sup>2</sup> 160 – 210 kPa 22.7 – 29.9 psi
Within 1 min. after engine (fuel pump) stop (Pressure reduces as time passes)	Over 0.9 kg/cm <sup>2</sup> 90 kPa 12.8 psi

If measured pressure doesn't satisfy specification, refer to "Diagnostic Flow Chart B-3" and check each possibly defective part. Replace if found defective.

8. Relieve fuel pressure according to procedure described in Section 6.
9. Remove fuel pressure gauge, hose & 3-way joint after removing air cleaner assembly.
10. Connect fuel feed hose to throttle body and clamp it securely.
11. Install air cleaner assembly.
12. With engine "OFF" and ignition switch "ON", check for fuel leaks.

**FUEL PUMP****Fuel Pump On-Car Inspection****WARNING:**

When fuel filler cap is removed in any procedure, work must be done with no smoking, in a well-ventilated area and away from any open flames.

1. Remove filler cap and turn ON ignition switch. Then fuel pump operating sound should be heard from fuel filler for about 2 seconds and stop. Be sure to reinstall fuel filler cap after checking.




Fig. 6E-98 Checking Fuel Pump

If above check result is not satisfactory, advance to "Diagnostic Flow Chart B-2".

**Removal**

1. Remove fuel tank from body according to procedure described in section 6C and remove fuel pump & level gauge from fuel tank.




Fig. 6E-99 Removing Fuel Pump & Level Gauge

2. Remove fuel pump from its bracket.

**Inspection**

Check fuel pump filter for evidence of dirt and contamination. If present, clean and check for presence of dirt in fuel tank.

**Installation**

1. Install fuel pump to its bracket.
2. Install fuel pump & level gauge to fuel tank and then install fuel tank to body according to procedure described in section 6C.



THROTTLE BODY




Fig. 6E-100 Throttle Body Parts Identification

**On-Car Inspection**

- Check that throttle valve lever moves smoothly.
- Vacuum passage inspection.  
 With fingers placed against vacuum nozzles (2 pcs), increase engine speed a little and check that vacuum is applied.




Fig. 6E-101 Checking Vacuum Passage

**Removal**

1. Relieve fuel pressure according to procedure described in Section 6.
2. Disconnect battery negative cable at battery.
3. Remove air cleaner assembly referring to section 6A.
4. Drain cooling system.
5. Disconnect following wire harness couplers:
  - TPS
  - Fuel injector
  - WTS
6. Disconnect following hoses from throttle body.
  - Fuel feed and return hoses
  - Engine cooling water hoses
  - Vacuum hoses
7. Disconnect accelerator cable from throttle valve lever and cable bracket.




Fig. 6E-102 Disconnecting Couplers and Hoses

8. Remove throttle body from intake manifold.

### Disassembly

#### NOTE:

- Be sure not to remove either fuel pressure regulator or air valve from throttle body. They are factory adjusted precisely.
- Be sure to replace gaskets and O rings as well as worn or damaged parts.
- While disassembling and assembling throttle body, use special care not to deform levers on throttle valve shaft or cause damage to any other parts.

1. Remove fuel injector from throttle body according to procedure described on p. 6E-79.
2. Remove TPS.
3. Remove WTS.
4. After removing screws, separate upper and lower bodies.




Fig. 6E-103 Disassembling Throttle Body

### Cleaning

Clean below passages and fuel injector chamber by blowing compressed air.

#### NOTE:

- TPS, fuel pressure regulator, fuel injector, air valve, WTS, other components containing rubber (resin) or throttle valve shaft seal must not be placed in a solvent or cleaner bath. Chemical reaction will cause these parts to swell, harden or get distorted.
- Don't put drills or wires into passages for cleaning. It causes damage in passages.




Fig. 6E-104 Cleaning Passage

**Assembly**

1. Install new gasket to lower body.




Fig. 6E-105 Installing Gasket

2. Install upper body on gasket, using care not to cause gasket to slip out of place.
3. Tighten screws indicated by "5" in Fig. 6E-103 to specified torque.

Tightening torque of screw	N-m	kg-m	lb-ft
	2.9-4.1	0.29-0.41	2.1-2.9

4. Install WTS according to procedure described on p. 6E-84.
5. Install TPS according to procedure described on p. 6E-82.
6. Install fuel injector according to procedure described on p. 6E-79.
7. Install injector subwire to throttle body.  
 Use new O ring.  
 Tighten subwire coupler screw to specified torque.

Tightening torque of screw	N-m	kg-m	lb-ft
	1.6-2.4	0.16-0.24	1.2-1.7

Connect injector coupler to injector securely, cover injector coupler with coupler cover and with wire tube pushed against injector coupler, clamp sub wire.




Fig. 6E-106 Clamping Sub Wire

**Installation**

1. Clean mating surfaces and install throttle body gasket to intake manifold. Use new gasket.




Fig. 6E-107 Gasket Installation

2. Install throttle body to intake manifold and tighten bolts and nuts to specified torque.

Tightening torque for throttle body bolts & nuts	N·m	kg·m	lb·ft
	18 - 28	1.8 - 2.8	13.0 - 20.0

3. Install accelerator cable to throttle valve lever and cable bracket.  
Adjust cable play to specification according to procedure described on p. 6E-69.
4. Connect fuel, cooling water and vacuum hoses to throttle body, and clamp securely.
5. Connect TPS injector and WTS coupler securely.
6. Refill cooling system referring to section 6B.
7. Connect negative cable at battery.
8. With engine "OFF" and ignition switch "ON", check for fuel leaks around fuel line connection.
9. Install air cleaner assembly referring to section 6A.
10. Upon completion of installation, start engine and check for fuel leaks and engine cooling water leaks.

**AIR VALVE****Inspection**

1. Remove throttle body assembly from intake manifold as previously outlined.
2. Separate upper and lower bodies.
3. Remove WTS from lower body.
4. Immerse air valve of throttle body in water as shown below. Check visually that air valve closes gradually as water temperature rises and closes fully at higher than about 80°C, 176°F.

**NOTE:**

- Be very careful to prevent water from entering throttle body bore.
- Be very careful never to put throttle body parts except air valve thermo wax in water or expose them to water splash.




Fig. 6E-108 Inspection Air Valve

If check result is not satisfactory, replace.

5. Install WTS according to procedure described on p. 6E-84.
6. Put upper and lower bodies together and tighten its screws to specified torque.  
Use new gasket between lower and upper bodies.
7. Install throttle body assembly to intake manifold as previously outlined.

**FUEL INJECTOR**

**On-Car Inspection**

1. With battery negative cable disconnected, disconnect injector coupler.
2. Connect ohmmeter to each injector terminal and measure resistance.

Resistance of injector	0.5 – 1.5 Ω at 20° C (68° F)
------------------------	---------------------------------

If resistance is out of specification, replace fuel injector.




Fig. 6E-109 Checking Resistance of Fuel Injector

3. Connect injector coupler.
4. Remove air cleaner assembly without disconnecting ATS coupler.
5. Check that fuel is injected out in conical shape from fuel injector when cranking or running engine.




Fig. 6E-110 Checking Fuel Injection

If no fuel is injected, check wiring harness for continuity and couplers for proper connection referring to "Diagnostic Flow Chart B-1".

If fuel is not injected out in conical shape, replace injector.

6. Check injector for fuel leakage after injection is stopped (i.e., after cranking or engine stop). Replace if leakage exists.

Fuel leakage	Less than 1 drop/min.
--------------	-----------------------

7. Install air cleaner assembly.

## Removal

### NOTE:

Use care when handling fuel injector especially not to damage filter and its needle.

Also, because injector is an electrical component, it should not be immersed in any type of liquid solvent or cleaner, or it may get damaged.

1. Relieve fuel pressure according to procedure described in Section 6.
2. Disconnect battery negative cable at battery.
3. Remove air cleaner assembly referring to section 6A.
4. Remove air cleaner mounting stay for throttle body.
5. Remove injector cover and upper insulator. Then open claws of injector after removing coupler cover and disconnect coupler from it.

### NOTE:

Use care not to break claws by opening them too far outward.




Fig. 6E-111 Disconnecting Coupler

6. Remove injector from throttle body.




Fig. 6E-112 Removing Injector

## Inspection

Check fuel injector filter for evidence of dirt and contamination. If present, clean and check for presence of dirt in fuel lines and fuel tank.

## Installation

1. Apply thin coat of spindle oil or gasoline to new upper and lower O-rings, install lower O-ring to injector cavity and upper O-ring to injector.
2. Install new lower insulator to injector cavity.




Fig. 6E-113 Installing O-rings and Insulator

3. Install injector by pushing it straight into fuel injector cavity.  
Never turn injector while pushing it.

4. Install new upper insulator and new injector cover, and tighten cover screw to specified torque.

Tightening torque for injector cover screw	N-m	kg-m	lb-ft
	2.9 - 4.1	0.29-0.41	2.1 - 2.9

5. Connect injector coupler to injector, facing its lug side upward and cover its coupler with coupler cover, and with wire tube pushed against injector coupler, clamp sub wire.




Fig. 6E-114 Clamping Sub Wire

6. Connect battery negative cable at battery.  
7. With engine "OFF" and ignition switch "ON", check for fuel leaks.

8. Install air cleaner mounting stay as shown below.




Fig. 6E-115 Installing Stay

9. Install air cleaner assembly referring to section 6A.

## ELECTRONIC CONTROL SYSTEM

### ELECTRONIC CONTROL MODULE (ECM)

**CAUTION:**

As ECM consists of precision parts, be careful not to expose it to excessive shock.

**Removal**

1. Disconnect battery negative cable at battery.
2. Lower junction/fuse block after removing its bolts.
3. Disconnect couplers from ECM while releasing coupler lock.
4. Remove ECM from body.




Fig. 6E-116 Removing ECM

**Installation**

1. Install ECM to body.
2. Connect couplers to ECM securely.
3. Fix junction/fuse block with bolts.
4. Connect battery negative cable at battery.

**PRESSURE SENSOR (PS)**

**Output Voltage Check**

1. Remove ECM according to previously outlined.
2. Connect couplers to ECM securely.
3. With coupler connected to ECM, connect digital type voltmeter as shown below and check that ECM supply voltage 4.75 – 5.25V is applied to coupler terminal B1.
4. Check output voltage at coupler terminal B2. Note that it varies with atmospheric pressure and altitude. Also, start engine, if it can, and check if output voltage varies.




Fig. 6E-117 Checking PS and Its Circuit

**Output voltage (ECM supply voltage 4.75 – 5.25V, ambient temp. 10 – 40°C, 50 – 104°F)**

ALTITUDE (Reference)		BAROMETRIC PRESSURE	OUTPUT VOLTAGE
(ft)	(m)	(mmHg)	(V)
0	0	760	3.5 – 4.1
1 000	305	733	3.4 – 4.0
2 000	610	707	3.2 – 3.8
3 000	914	682	3.1 – 3.7
4 000	1 219	658	3.0 – 3.6
5 000	1 524	634	2.9 – 3.5
6 000	1 829	611	2.8 – 3.3
7 000	2 133	589	2.7 – 3.2
8 000	2 438	567	2.6 – 3.1
9 000	2 743	546	2.5 – 3.0
10 000	3 048	526	2.4 – 2.9

**NOTE:**

Note that atmospheric pressure varies depending on weather conditions as well as altitude.

Take that into consideration when performing above check.

If check result is not satisfactory in previous step 3 or 4, check PS and its circuit according to Diagnostic Flow Chart for Code No. 31.

**NOTE:**

If output voltage does not vary when engine is started, it is possible that vacuum hose and/or filter are clogged. Clean them.

Another possibility is that filter in PS is clogged from freezing. If it is suspected, leave it at room temperature (20°C, 68°F) for a while and re-check.

5. Upon completion of checking, install ECM and connect ECM coupler securely.

**PS Individual Check**

1. Disconnect PS vacuum hose from filter.
2. Disconnect coupler from PS.
3. Remove PS.
4. Arrange 3 new 1.5V batteries in series (check that total voltage is 4.5 – 5.0V) and connect its positive terminal to "Vin" terminal of sensor and negative terminal to "Ground" terminal. Then check voltage between "Vout" and "Ground".

Also, check if voltage reduces when vacuum is applied up to 40 cmHg by using vacuum pump.




Fig. 6E-118 Checking PS



Output voltage (Vin voltage 4.5 – 5.0V, ambient temp. 20 – 30°C, 68 – 86°F)

ALTITUDE (Reference)		BAROMETRIC PRESSURE	OUTPUT VOLTAGE
(ft)	(m)	(mmHg)	(V)
0   2 000	0   610	760   707	2.9 – 4.2
2 001   5 000	611   1 524	Under 707 over 634	2.7 – 4.0
5 001   8 000	1 525   2 438	Under 634 over 567	2.5 – 3.8
8 001   10 000	2 439   3 048	Under 567 over 526	2.0 – 3.3

If check result is not satisfactory, replace PS.

5. Install PS and connect vacuum hose securely.
6. Connect PS coupler securely.

### THROTTLE POSITION SENSOR (TPS)

#### Inspection

1. Disconnect negative cable at battery.
2. Remove air cleaner assembly referring to section 6A.
3. Disconnect coupler from TPS.
4. Using ohmmeter, check resistance between terminals under each condition given in below table.




Fig. 6E-126 Checking TPS

TERMINALS	CONDITION	RESISTANCE
Between A and B terminals (Idle switch)	When throttle lever-to-stop screw clearance is 0.3 mm (0.012 in.)	0 – 5KΩ
	When throttle lever-to-stop screw clearance is 0.9 mm (0.035 in.)	∞
Between A and D terminals	—	4.37 – 8.13 kΩ
Between A and C terminals	Throttle valve is at idle position	0.20 – 11.42 kΩ
	Throttle valve is fully opened	3.03 – 17.08 kΩ

The resistance between A and C should increase as throttle valve opens larger.

If idle switch check result is not satisfactory, adjust installation angle of TPS and if found defective in the other check, replace TPS.

5. Connect TPS coupler securely.
6. Install air cleaner assembly referring to section 6A.
7. Connect battery negative cable to battery.

#### Adjustment

1. Disconnect battery negative cable, remove air cleaner assembly and disconnect TPS coupler.
2. Insert 0.6 mm (0.024 in) thickness gauge between throttle stop screw and throttle lever.




Fig. 6E-127 Inserting Thickness Gauge

3. Loosen TPS screws.
4. Connect ohmmeter between A and B terminals.
5. First, turn TPS counterclockwise fully and then clockwise gradually to find position where ohmmeter reading changes from 0 (zero, continuity) to  $\infty$  (no continuity). Then fix TPS at that position by tightening screws to specified torque.

Tightening torque of TPS screw	N-m	kg-m	lb-ft
	1.6-2.4	0.16-0.24	1.2-1.7




Fig. 6E-128 Adjusting Installation Angle

6. Check that there is no continuity between terminals A and B when 0.9 mm (0.035 in) thickness gauge is inserted.
7. Check that there is continuity between terminals A and B when 0.3 mm (0.012 in) thickness gauge is inserted.

If check result is unsatisfactory in steps 6 and 7, it means that installation angle of TPS is not adjusted properly. Therefore, start all over again from step 1.

**CAUTION:**

As throttle stop screw is factory adjusted precisely, don't remove or adjust it.

8. Connect coupler to TPS securely, install air cleaner assembly and connect battery negative cable.

**Removal**

1. Disconnect battery negative cable at battery.
2. Remove air cleaner assembly referring to section 6A.
3. Disconnect coupler from TPS.
4. Remove TPS from throttle body.

**Installation**

1. Install TPS to throttle body.

Fit TPS to throttle body in such way that its adjusting holes are a little away from TPS screw holes as shown in Fig. 6E-129 and turn TPS clockwise so that those holes align.

Then hand-tighten TPS screws.




Fig. 6E-129 Installing TPS

2. Adjust installation angle of TPS according to procedure described in item "Adjustment".
3. Connect coupler to TPS securely.
4. Install air cleaner assembly referring to section 6A.
5. Connect battery negative cable to battery.

### AIR TEMPERATURE SENSOR (ATS)

#### Removal

1. Disconnect battery negative cable at battery.
2. Disconnect coupler from ATS.
3. Remove ATS and gasket from air cleaner case.

#### Inspection

Immerse temperature sensing part of ATS in water (or ice) and measure resistance between sensor terminals while heating water gradually. If measured resistance doesn't show such characteristic as shown in Fig. 6E-131, replace ATS.




Fig. 6E-130 Checking ATS

#### Installation

Reverse removal procedure noting the following.

- Clean mating surfaces of ATS and air cleaner case.
- Tighten ATS to specified torque.

Tightening torque for ATS	N-m	kg-m	lb-ft
	13 - 17	1.3 - 1.7	9.5 - 12.0

- Connect ATS coupler securely.

### WATER TEMPERATURE SENSOR (WTS)

#### Removal

1. Disconnect battery negative cable at battery.
2. Remove air cleaner assembly referring to section 6A.
3. Remove radiator cap to relieve engine cooling water pressure and install it.

#### WARNING:

To help avoid danger of being burned, do not remove radiator cap while engine and radiator are still hot. Scalding fluid and steam can be blown out under pressure if cap is taken off too soon.

4. Disconnect coupler from WTS.
5. Remove WTS and gasket from throttle body.

#### NOTE:

Cooling water, although small amount, may be released then. Cover WTS with shop cloth so that released water is absorbed on it.

#### Inspection

Check resistance of WTS variable with temperature by using the same checking method as ATS. For WTS characteristic, refer to Fig. 6E-131. If found defective, replace.

#### Installation

Reverse removal procedure noting the following.

- Clean mating surfaces of WTS and throttle body.
- Check gasket for damage and replace if necessary.




Fig. 6E-131 ATS and WTS Characteristic

- Tighten WTS to specified torque.

Tightening torque for WTS	N·m	kg·m	lb·ft
	20 – 30	2.0 – 3.0	14.5 – 21.5

- Connect coupler to WTS securely.

## OXYGEN SENSOR

### Removal

#### WARNING:

To avoid danger of being burned, do not touch exhaust system when system is hot. Oxygen sensor removal should be performed when system is cool.

1. Disconnect negative cable from battery.
2. Disconnect coupler of oxygen sensor and release its wire harness from clamps.
3. Remove oxygen sensor from exhaust manifold.




Fig. 6E-132 Removing Oxygen Sensor

### Installation

Reverse removal procedure noting the following.

- Tighten oxygen sensor to specified torque.

Tightening torque for oxygen sensor	N·m	kg·m	lb·ft
	45 – 55	4.5 – 5.5	33.0 – 39.5

- Connect coupler of oxygen sensor and clamp wire harness securely.
- After installing oxygen sensor, start engine and check that no exhaust gas leakage exists.

## VEHICLE SPEED SENSOR

### Inspection

1. Disconnect negative cable at battery.
2. Remove combination meter from instrument panel.
3. Connect ohmmeter between "VSS" terminal and "GND" terminal of combination meter and turn cable joint of speedometer with a screwdriver. Ohmmeter indicator should move back and forth between 0 (zero) and  $\infty$  (infinity) 4 times while cable joint is turned one full revolution.




Fig. 6E-133 Checking Speed Sensor

Replace speedometer if check result is not satisfactory.

4. Install combination meter to instrument panel.
5. Connect negative cable to battery.

**MAIN RELAY**




Fig. 6E-134 Main Relay Circuit

3. Check resistance between each two terminals as in table below.

If check results are as specified, proceed to next operation check. If not, replace.




Fig. 6E-136 Checking Main Relay Resistance

**Inspection**

1. Disconnect negative cable at battery.
2. Remove main relay from main fuse box after disconnecting its coupler.




Fig. 6E-135 Removing Main Relay

TERMINALS	RESISTANCE
Between A and B	$\infty$ (infinity)
Between C and D	56 – 84 $\Omega$

4. Check that there is continuity between terminals "A" and "B" when battery is connected to terminals "C" and "D".

If found defective, replace.




Fig. 6E-137 Checking Main Relay Operation

**FUEL PUMP RELAY**




Fig. 6E-138 Fuel Pump Circuit

**Inspection**

1. Remove fuel pump relay in the same way as main relay.
2. Structure of fuel pump relay is the same as that of main relay. Check its resistance and operation using the same procedure as that for main relay.  
 If found defective, replace.

**FUEL INJECTOR RESISTOR**

**Inspection**

1. With ignition switch OFF, disconnect resistor coupler.
2. Check resistor for resistance.

Resistance of fuel injector resistor	1.9 – 2.1 Ω
--------------------------------------	-------------

If check result is not satisfied, replace.




Fig. 6E-139 Checking Resistor

**FUEL CUT OPERATION**

**Inspection**

**NOTE:**

Before inspection, check to make sure that gear shift lever is in neutral position (with A/T model, selector lever in "P" range), A/C is OFF and that parking brake lever is pulled all the way up.

1. Warm up engine to normal operating temperature.
2. While listening to sound of injector by using sound scope or such, increase engine speed to higher than 3,000 r/min.
3. Check to make sure that sound to indicate operation of injector stops when throttle valve is closed instantly and it is heard again when engine speed is reduced to less than about 2,000 r/min.




Fig. 6E-140 Checking Fuel Cut

**ISC SOLENOID VALVE**

**Inspection**

1. With ignition switch "OFF", disconnect ISC solenoid valve coupler.
2. Check resistance between each two terminals of ISC solenoid valve.

Resistance of ISC solenoid valve	30 – 33 Ω
----------------------------------	-----------

If it is within specification, proceed to next operation check. If not, replace.




Fig. 6E-141 Checking Resistance

3. Warm up engine to normal operating temperature.
4. With engine running and ISC solenoid valve coupler disconnected, disconnect ISC solenoid valve hose of underside as shown below. In this state, check that air is not drawn into the ISC solenoid valve.




Fig. 6E-142 Checking ISC Solenoid Valve (1)

5. Under above condition, connect 12V battery to ISC solenoid valve terminals and check that air is drawn into the ISC solenoid valve.




Fig. 6E-143 Checking ISC Solenoid Valve (2)

If check result is not satisfactory, replace ISC solenoid valve.

6. Connect hose and coupler securely.

## EGR CONTROL SYSTEM

### System Inspection

#### NOTE:

Before inspection, check to make sure that gear shift lever is in neutral position (with A/T model, selector lever in "P" range) and that parking brake lever is pulled all the way up.

1. When engine is cool (cooling water temperature is below 40°C, 104°F), start engine and race it, and check that EGR valve diaphragm is not operating in this state.




Fig. 6E-144 Checking EGR Valve Diaphragm

2. Warm up engine to normal operating temperature and race it after warming up. Then check to be sure that diaphragm moves toward 1 in Fig. 6E-145 during acceleration and toward 2 during deceleration.




Fig. 6E-145 Movement of EGR Valve Diaphragm

If EGR valve fails to operate properly, check vacuum hoses, EGR valve, EGR modulator and VSV.

3. Keep engine running at idle speed and open EGR valve by hand, and engine should either stop or reduce its speed. If neither occurs, EGR passage is clogged. Clean it.

### Vacuum Hose Inspection

Check hoses for connection, leakage, clog and deterioration. Replace as necessary.

### EGR Valve Inspection

1. Disconnect vacuum hose from EGR modulator.
2. Connect vacuum pump gauge to its hose.
3. Check that EGR valve diaphragm moves smoothly and that it is held at the same position when 20 cmHg vacuum is applied to EGR valve.

If diaphragm doesn't move smoothly, or it isn't held at the same position, replace EGR valve.




Fig. 6E-146 Checking EGR Valve

4. After checking, be sure to connect vacuum hose.



**EGR Modulator Inspection**

1. Check filter for contamination and damage.  
Using compressed air, clean filter.




Fig. 6E-147 Filter of EGR Modulator

2. Remove EGR modulator and plug nozzle with finger. Blow air into another nozzle and check that air passes through to air filter side freely.




Fig. 6E-148 Checking EGR Modulator (1)

3. Connect vacuum pump gauge to nozzle "P" and plug nozzle "Q" with finger. While blowing air into nozzle "A", operate vacuum pump gauge and check that vacuum is applied to modulator. Then stop blowing nozzle "A" and check that vacuum pump gauge indicates "0" (zero). If check result is not satisfactory, replace EGR modulator.




Fig. 6E-149 Checking EGR Modulator (2)

4. After checking, install modulator and connect hoses securely. Refer to emission control information label for connection.

**VSV (Vacuum Switching Valve) Inspection**

1. With ignition switch OFF, disconnect coupler from VSV.
2. Check resistance between two terminals of VSV.

Resistance of EGR VSV	33 – 39 Ω
-----------------------	-----------

If resistance is as specified, proceed to next operation check. If not, replace.




Fig. 6E-150 Checking Resistance

3. Disconnect vacuum hoses from EGR modulator and throttle body.
4. Blow into nozzle "A". Air should come out of filter and not out of nozzle "B".




Fig. 6E-151 Checking VSV (1)

5. Connect 12V-battery to VSV terminals. In this state, blow nozzle "A". Air should come out of nozzle "B" and not out of filter.




Fig. 6E-152 Checking VSV (2)

If check result is not as described above, replace VSV.

6. Connect VSV coupler securely.
7. Connect vacuum hose securely.

### SHIFT-UP INDICATOR LIGHT CONTROL SYSTEM (If equipped)




Fig. 6E-153 System Circuit

### System Inspection

#### CAUTION:

This check requires test drive. Use special care for safety when driving.

1. Turn ignition switch ON, and shift-up indicator light should light.  
If not, cause may be burned bulb, open wire, poor connection or faulty ECM. Proceed to "Shift up indicator light and its circuit inspection".
2. Start engine, and shift-up indicator light should go off.  
If not, cause may be shorted wire to ground or faulty ECM.
3. Warm up engine to normal operating temperature.
4. With gear shift lever in low gear position, increase engine speed. When it exceeds 1,600 r/min. shift-up indicator light should light for 5 seconds at the longest.  
If it doesn't light, check speed sensor, WTS and pressure sensor. If they are all in good condition, substitute a known good ECM for existing one.

**Shift up Indicator Light and Its Circuit**

**Inspection**

1. With ignition switch OFF, disconnect ECM coupler from ECM.
2. Turn ignition switch ON, and shift-up indicator light should not light. If it light, wire is shorted to ground.
3. Ground A8 terminal of disconnected ECM coupler by using service wire.




Fig. 6E-154 Checking Indicator Light

And then shift up indicator light should light. If not, cause may be burned bulb, open wire or poor connection. Repair or replace as necessary.

4. Connect coupler to ECM securely.

**OUTPUT SIGNAL OF THROTTLE VALVE OPENING (A/T model only)**




Fig. 6E-155 Signal Output Circuit

**Inspection**

1. Check voltage at each terminal for "Br/Y", "Br/B" and "Br/R" wires of A/T control module.




Fig. 6E-156 Checking Output Signal

Voltage at each terminal should vary as shown in following ON/OFF signal diagram.




Fig. 6E-157 ON/OFF Signal Diagram

If check result is not satisfactory, check each wire harness, circuit connections and TPS.

**POWER STEERING VSV (If equipped)****Inspection**

1. With ignition switch OFF, disconnect coupler from VSV.
2. Check resistance between two terminals of VSV.

Resistance of power steering VSV	33 – 39 $\Omega$
----------------------------------	------------------

If resistance is as specified, proceed to next operation check. If not, replace.




Fig. 6E-158 Checking Resistance

3. Disconnect vacuum hoses from 3-way joints.
4. With coupler disconnected, blow into hose "A". Air should not come out of hose "B".




Fig. 6E-159 Checking VSV (1)

5. Connect 12V-battery to VSV terminals. In this state, below hose "A".  
Air should come out of hose "B".





Fig. 6E-160 Checking VSV (2)

If check result is not as described, replace VSV.

6. Install vacuum hoses to 3-way joints.
7. Connect VSV coupler securely.

## SPECIAL TOOLS



## RECOMMENDED TORQUE SPECIFICATIONS

Fastening parts	Tightening torque		
	N·m	kg-m	lb-ft
Throttle body mounting bolt and nut	18 – 28	1.8 – 2.8	13.5 – 20.0
Throttle upper and lower body screw	2.9 – 4.1	0.29 – 0.41	2.1 – 2.9
Fuel injector sub wire coupler screw	1.6 – 2.4	0.16 – 0.24	1.2 – 1.7
Fuel injector cover screw	2.9 – 4.1	0.29 – 0.41	2.1 – 2.9
TPS mounting screw	1.6 – 2.4	0.16 – 0.24	1.2 – 1.7
ATS	13 – 17	1.3 – 1.7	9.5 – 12.0
WTS	20 – 30	2.0 – 3.0	14.5 – 21.5
Oxygen sensor	45 – 55	4.5 – 5.5	33.0 – 39.5

SECTION 6F

**IGNITION SYSTEM  
(For Carburetor Car)**

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

<b>ON-CAR SERVICE</b> .....	6F-1
Power Supply Check .....	6F-1
Ignition Coil .....	6F-1

**ON-CAR SERVICE**

**POWER SUPPLY CHECK**

**For ignition coil**

1. With coupler disconnected from noise suppressor and ignition switch turned ON, check that battery voltage is obtained at "Br/W" wire terminal of disconnected coupler.
2. If no voltage or low voltage is found, check fuse, couplers and wiring harness.

**For distributor**

Refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**IGNITION COIL**

1. Pull out high tension cord by gripping its cap.
2. Disconnect ignition coil coupler.
3. Measure primary and secondary coil resistance.

Ignition coil resistance (at 20°C, 68°F)	Primary	1.08 – 1.32 Ω
	Secondary	22.1 – 29.9 kΩ




Fig. 6F-2 Measuring Ignition Coil Resistance

4. If resistance is out of specification, replace coil with new one.

## SECTION 6F1

# IGNITION SYSTEM

### (For Car with Fuel Injection System)

#### CONTENTS

<b>GENERAL DESCRIPTION</b> ..... 6F1-1 ESA System ..... 6F1-2 <b>DIAGNOSIS</b> ..... 6F1-3 <b>ON CAR SERVICE</b> ..... 6F1-4 Ignition Spark Test ..... 6F1-4 Power Supply Check ..... 6F1-4 High Tension Cords ..... 6F1-5 Spark Plugs ..... 6F1-6 Ignition Coil ..... 6F1-6	Distributor ..... 6F1- 7 Ignitor (Power Unit) and its Circuit ..... 6F1- 7 Ignition Timing ..... 6F1- 8 <b>DISTRIBUTOR UNIT</b> ..... 6F1-10 Dismounting ..... 6F1-10 Remounting ..... 6F1-10 <b>SPECIAL TOOLS</b> ..... 6F1-11
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## GENERAL DESCRIPTION

The ignition system used for this car has an ESA (Electronic Spark Advance) system and consists of the following parts.

- **ECM**  
It detects the engine condition through the signals from the sensors, determines the most suitable ignition timing and time for electricity to flow to the primary coil and sends a signal to the power unit.
- **Power unit**  
It turns ON and OFF the primary current of the ignition coil according to the signal from ECM.
- **Ignition coil**  
When the ignition coil primary current is turned OFF, a high voltage is induced in the secondary winding.
- **Distributor**  
It distributes a high voltage current to each plug.
- **High-tension cords and spark plugs**

- **CAS (Crank Angle Sensor)**  
Located in the distributor, it converts the crank angle into voltage variation and sends it to ECM. For its details, refer to Section 6E.
- **TPS, WTS and pressure sensor**  
For their details, refer to Section 6E.

In ESA system, the ECM is programmed for the best ignition timing under every engine condition. Receiving signals which indicate the engine condition from the sensors, e.g., engine revolution, intake air pressure, coolant temperature, etc., it selects the most suitable ignition timing from its memory and operates the power unit.

Thus ignition timing is controlled to yield the best engine performance.

For more information, refer to Section 6E and following description.




Fig. 6F1-1 Ignition Circuit Diagram

## ESA SYSTEM

This system has two functions as follows.

- Ignition timing control
- Electric current flow to ignition primary coil control

These controls are performed by the Electronic (Engine) Control Module (ECM). ECM judges the engine condition by using signals from various sensors, selects the most suitable electric current flow time and ignition timing for that engine condition from among those prestored in its memory and sends an ignition signal to the igniter (power unit).

### Ignition Timing Control

To obtain better starting performance of the engine at the engine start (when the engine speed is lower than 500 r/min.) ESA system sets the ignition timing to the initial ignition timing (5° BTDC).

The ignition timing after the engine start is determined as follows so that the spark occurs at the most suitable timing for each engine condition.

$$\boxed{\text{Ignition timing}} = \boxed{\text{Initial ignition timing}} + \boxed{\text{Basic ignition advance}} + \boxed{\text{Various compensating advance}}$$

### Electric Current Flow to Ignition Primary Coil Control

To stabilize the secondary voltage generated in the ignition coil to a proper level, ESA system controls the time of primary current flow to the ignition coil.



## DIAGNOSIS

Condition	Possible cause	Correction
<b>Engine cranks, but will not start or hard to start</b>	No spark <ul style="list-style-type: none"> <li>● Blown fuse for ignition coil</li> <li>● Loose connection or disconnection of lead wire or high-tension cord(s)</li> <li>● Faulty high-tension cord(s)</li> <li>● Faulty spark plug(s)</li> <li>● Cracked rotor or cap</li> <li>● Maladjusted signal rotor air gap</li> <li>● Faulty ignition coil</li> <li>● Faulty noise suppressor</li> <li>● Faulty CAS</li> <li>● Faulty igniter</li> <li>● Faulty ECM</li> </ul> Maladjusted ignition timing	Replace Connect securely  Replace Adjust, clean or replace Replace Adjust Replace Replace Replace Replace Replace Adjust
<b>Poor fuel economy or engine performance</b>	<ul style="list-style-type: none"> <li>● Incorrect ignition timing</li> <li>● Faulty spark plug(s)</li> <li>● Faulty ECM</li> </ul>	Adjust Adjust, clean or replace Replace

### SELF-DIAGNOSIS

1. To insure correct diagnosis, check to confirm that battery voltage is within standard value when engine is standstill.
2. Turn ON ignition switch and make sure that "CHECK ENGINE" light lights.
3. If engine will not start but cranking is possible, crank it for more than 3 seconds.
4. While ignition switch is ON, ground diagnosis switch terminal (or turn diagnosis switch ON) and then read diagnostic code (observe "CHECK ENGINE" light).

### DIAGNOSTIC CODE NO. 41



ECM indicates that no ignition fail safe signal is inputted while engine is running or being cranked. Diagnose trouble according to "Diagnostic Flow Chart for Code No. 41" in Section 6E.

### DIAGNOSTIC CODE NO. 42



ECM indicates that no CAS signal is inputted for more than 2 seconds while engine is being cranked.

Diagnose trouble according to "Diagnostic Flow Chart for Code No. 42" in Section 6E.

## ON CAR SERVICE

### IGNITION SPARK TEST

1. Disconnect injector coupler at throttle body side.

#### WARNING:

Without disconnection of injector coupler, combustible gas may come out from spark plug holes during this test and may get ignited in engine room.




Fig. 6F1-2 Disconnecting Injector Coupler

2. Remove spark plugs and connect them to high tension cords, and then ground spark plugs.
3. Crank engine and check if each spark plug sparks.
4. If no spark is emitted, inspect high tension cords, spark plugs, ignition coil, distributor, etc.

### POWER SUPPLY CHECK

#### For Ignition Coil

1. Remove ignition coil cap.
2. Check to make sure that coil terminals have battery voltage with ignition switch ON.
3. If no voltage or low voltage is found, check fuse, couplers and wiring harness.




Fig. 6F1-3 Checking Power Supply to Ignition Coil

#### For Ingiter (power unit)

1. Disconnect igniter coupler, turn on ignition switch and check to make sure that coupler terminals IG+ and IG- have battery voltage.
2. If no voltage or low voltage is found, check fuse, wiring harness and coupler.




Fig. 6F1-4 Checking Power Supply to Igniter

## HIGH TENSION CORDS

1. Remove high tension cord at ignition coil while gripping its cap.
2. Remove distributor cap installed with high tension cords.
3. Remove high tension cord clamp from cylinder head cover.
4. Pull out high tension cords from spark plugs while gripping each cap.

### CAUTION:

- Removal of high tension cords together with clamps will be recommended so as not to damage their inside wire (resistive conductor).
- For the same reason, pull out each connection by gripping cap portion.




Fig. 6F1-5 Removing High Tension Cord

5. Measure resistance of high tension cord by using ohmmeter.

High tension cord resistance	10 – 22 k $\Omega$ /m 3.0 – 6.7 k $\Omega$ /ft
------------------------------	---------------------------------------------------




Fig. 6F1-6 Measuring High Tension Cord Resistance

6. If resistance exceeds specification, inspect distributor terminal and replace high tension cord(s) and/or distributor cap as required.

### CAUTION:

- Never attempt to use metal conductor high tension cords as replacing parts.
- Insert each cap portion fully when installing high tension cords.

## SPARK PLUGS

1. Pull out high tension cords by gripping their caps and then remove spark plugs.
2. Inspect them for:
  - Electrode wear
  - Carbon deposits
  - Insulator damage
3. If any abnormality is found, adjust air gap, clean with spark plug cleaner or replace them with specified new plugs.

NGK	BPR6ES
NIPPONDENSO	W20EPR-U
Air gap A	0.7–0.8 mm (0.028–0.031 in.)




Fig. 6F1-7 Checking Spark Plug Gap

4. Install spark plugs and torque them to specification.

Spark plug tightening torque	N·m	kg·m	lb·ft
	25 – 30	2.5 – 3.0	18.0 – 21.5

5. Install high tension cords securely by gripping their caps.

## IGNITION COIL

1. Pull out high tension cord by gripping its cap.
2. Disconnect ignition coil coupler.
3. Measure primary and secondary coil resistances.

Ignition coil resistance (at 20°C, 68°F)	
Primary	1.33 – 1.63 Ω
Secondary	10.7 – 14.5 kΩ

4. If resistance is out of specification, replace coil with new one.




Fig. 6F1-8 Measuring Ignition Coil Resistance

## DISTRIBUTOR

### Distributor Cap and Rotor

Check cap and rotor for crack and their terminals for corrosion and wear. Replace as necessary.

### Signal Rotor Air Gap

1. Remove distributor cap and rotor.
2. Using thickness gauge, measure air gap, between signal rotor tooth and generator.

Signal rotor air gap	about 0.2 mm (about 0.008 in.)
----------------------	-----------------------------------




Fig. 6F1-9 Checking Air Gap

3. If gap is out of specification, loose signal generator securing screws, Using blade (-) screw driver, move generator and adjust gap to specification. After adjustment, tighten securing screws and recheck gap.

#### NOTE:

Check to make sure that signal generator tooth is free from any metal particles.

4. Install distributor cap.

### Pickup Coil Resistance

1. Disconnect distributor lead coupler.
2. Measure resistance of pickup coil by using ohmmeter.
3. If resistance is out of specification, replace signal generator as follows.

Pickup coil resistance (at 20°C/68°F)	160 ± 20 Ω
------------------------------------------	------------




Fig. 6F1-10 Measuring Pickup Coil Resistance

4. Remove distributor cap and rotor.
5. Remove signal generator securing screws and lead wire clamp screws.
6. Replace signal generator.
7. Adjust signal rotor air gap to specification as previously outlined.
8. Install rotor, distributor cap seal and cap.

## IGNITOR (POWER UNIT) AND ITS CIRCUIT

Ignitor cannot be checked by itself. Check ignitor and its circuits as follows.




Fig. 6F1-11 Ignition Circuit

1. Disconnect igniter coupler.
2. Turn on ignition switch and check to make sure that IG+ and IG- terminals have battery voltage. If no voltage or low voltage is found, check fuse, wiring harness, ignition coil and coupler.




Fig. 6F1-12 Checking Voltage of Igniter Coupler

3. Disconnect injector coupler (Fig. 6F1-2). Check IGt terminal voltage of igniter coupler as follows.
  - 1) Disconnect igniter coupler.
  - 2) Connect analog type voltmeter between "IGt" terminal of igniter coupler and ground.
  - 3) There must be voltage pulse output within 0 – 5V obtained while engine cranking. If there is incorrect voltage, "Or" wire open, short circuit to ground or poor ECM B6 connection. If wire and connection are OK, substitute a known-good ECM and recheck.
4. With igniter coupler connected. Check IGf voltage of ECM A14 terminal as follows.
  - 1) Connect analog type voltmeter between "IGf" (ECM A14) terminal and ground.
  - 2) There must be 0 – 2V or 4 – 5V obtained when ignition switch is ON. Also, voltage at engine cranking must vary from that at ignition switch ON.

If there is incorrect voltage, "Y/R" wire open, short circuit to ground or poor igniter IGf terminal connection. If wire and connection are OK, substitute a known-good igniter and recheck.

## IGNITION TIMING

### NOTE:

Before starting engine, place transmission gear shift lever in "Neutral" (shift selector lever to "P" range for A/T model), and set parking brake.

### INSPECTION AND ADJUSTMENT

1. Start engine and warm it up to normal operating temperature.
2. Make sure that all of electrical loads except ignition are switched off.
3. Check to be sure that idle speed is within specification.

M/T model	750 rpm (r/min)
A/T model	850 rpm (r/min)

4. Set timing light to No. 1 high tension code.
5. Remove monitor coupler cap beside ignition coil.
6. Connect D and E terminals of monitor coupler or E to body by using service wire so that ignition timing is fixed on initial one.




Fig. 6F1-13 Fixing Ignition Timing

7. Using timing light, check that timing is within specification.

Initial Ignition Timing (Test switch terminal grounded)	$5 \pm 1^\circ$ BTDC (at idle speed)
------------------------------------------------------------	-----------------------------------------

Ignition order	1 - 3 - 4 - 2
----------------	---------------




Fig. 6F1-14 Checking Ignition Timing

8. If ignition timing is out of specification, loosen flange bolts, adjust timing by turning distributor assembly while engine is running, and then tighten bolts.

Tightening torque for distributor flange bolts	N-m	kg-m	lb-ft
	12 - 18	1.2 - 1.8	8.6 - 12.9




Fig. 6F1-15 Adjusting Ignition Timing

9. After tightening distributor flange bolts, recheck that ignition timing is within specification.

10. After checking and/or adjusting Initial Ignition Timing, disconnect service wire from monitor coupler.

11. With engine idling (test switch terminal ungrounded, idle switch ON and car stopped), check that ignition timing is about  $12^\circ$  BTDC. (Constant variation within a few degrees from  $12^\circ$  indicates no abnormality but proves operation of electronic timing control system.) Also, check that increasing engine speed advances ignition timing.

If above check results are not satisfactory, check TPS (Idle switch), test switch terminal circuit and ECM.

## DISTRIBUTOR UNIT




Fig. 6F1-16 Distributor Components

### DISMOUNTING

1. Disconnect distributor lead coupler.
2. Remove distributor cap screws and cap.
3. Remove distributor flange bolts.
4. Pull out distributor housing assembly.

### REMountING

#### NOTE:

- Before installing distributor, check to make sure that its O ring is in good condition.
- If new O ring is installed, apply oil.

1. Install distributor without cap to camshaft. Fit the dogs of distributor coupling into the slots of camshaft, when installing. The dogs of distributor coupling are offset. Therefore, if the dogs can not be fitted into the slots, turn the distributor shaft by 180 degree and try again.
2. Lightly install flange bolts and prepare for ignition timing adjustment.
3. Check to make sure that rotor is in good condition.
4. Inspect distributor cap and clean or replace as required.

5. Make sure that distributor cap seal is placed properly and install cap, and then fasten it with screws.
6. Connect distributor lead coupler.







Fig. 6F1-17 Installing Distributor



## SPECIAL TOOLS

 <p>09900-25002 Pocket tester</p>	 <p>09900-27301 Timing light (DC 12V)</p>	 <p>09930-76420 Timing light (Dry cell type)</p>	
------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------	--

# SECTION 6G1 CRANKING SYSTEM

(1.2 kW and 1.4 kW type)

**NOTE:**

Two types of starting motors are used for this model. They are, 1.2 and 1.4 kW types. Which one is used depends on specifications. For its identification, a label in one of following colors indicative of each type is attached to starting motor itself.

LABEL COLOR	White	Red
OUT PUT (kW)	1.2	1.4

## CONTENTS

<p><b>GENERAL DESCRIPTION</b> ..... 6G1- 1</p> <p style="padding-left: 20px;">Cranking Circuit ..... 6G1- 1</p> <p style="padding-left: 20px;">Starting Motor ..... 6G1- 2</p> <p><b>DIAGNOSIS</b> ..... 6G1- 3</p> <p><b>ON VEHICLE SERVICE</b> ..... 6G1- 4</p> <p style="padding-left: 20px;">Remove and Install Starting Motor .. 6G1- 4</p>	<p><b>STARTING MOTOR REPAIR</b> ..... 6G1- 5</p> <p style="padding-left: 20px;">Remove and Install Magnetic Switch ..... 6G1- 5</p> <p style="padding-left: 20px;">Remove and Install Motor Brush... 6G1- 6</p> <p style="padding-left: 20px;">Remove and Install Armature/Yoke . 6G1- 7</p> <p style="padding-left: 20px;">Remove and Install Over-Running Clutch ..... 6G1- 8</p> <p><b>STARTING MOTOR INSPECTION</b> ... 6G1-11</p> <p><b>SPECIFICATIONS</b> ..... 6G1-16</p>
--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## GENERAL DESCRIPTION

### CRANKING CIRCUIT

The cranking circuit consists of the battery, starting motor, ignition switch, and related electrical wiring. These components are connected electrically as shown in Fig. 6G1-1. Only the starting motor will be covered in this portion.

critical wiring. These components are connected electrically as shown in Fig. 6G1-1. Only the starting motor will be covered in this portion.




Fig. 6G1-1 Cranking Circuit

## STARTING MOTOR

The starting motor consists of parts shown in Fig. 6G1-2 and has permanent magnets mounted in starting motor yoke (frame).

The magnetic switch assembly and parts in the starting motor are enclosed in the housings so that they will be protected against possible dirt and water splash.

In the circuit shown in Fig. 6G1-1, the magnetic (motor) switch coils are magnetized when the ignition switch is closed. The resulting plunger and pinion drive lever movement causes the pinion to engage the engine flywheel gear and the magnetic switch main contacts to close, and cranking takes place. When the engine starts, the pinion over-running clutch protects the armature from excessive speed until the switch is opened, at which time the return spring causes the pinion to disengage.

### NOTE:

- Make sure to apply grease before assembly where so indicated in the figure below.
- The two types of starting motors are different only in length, weight of the armature/yoke and their output but the same description of structure, procedures of disassembly, assembly and inspection is applicable. For specifications, refer to the last page of this section.




Fig. 6G1-2

## DIAGNOSIS

Possible symptoms due to starting system trouble are:

- Starting motor does not run (or runs slowly),
- Starting motor runs but fails to crank engine, or
- Abnormal noise is heard.

Proper diagnosis must be made to determine exactly where the cause of each trouble lies . . . . in battery, wiring harness, (including starting motor switch), starting motor or engine.

Don't remove motor just because starting motor does not run. Check following items and narrow down scope of possible causes.

- 1) Condition of trouble
- 2) Tightness of battery terminals (including ground cable connection on engine side) and starting motor terminals.
- 3) Discharge of battery
- 4) Mounting of starting motor

Condition	Possible Cause	Correction
<b>Motor not running.</b>	<b>No operating sound of magnetic switch</b> <ol style="list-style-type: none"> <li>1. Battery run down.</li> <li>2. Battery voltage too low due to battery deterioration.</li> <li>3. Poor contact in battery terminal connection.</li> <li>4. Loose grounding cable connection.</li> <li>5. Fuse set loose or blown off.</li> <li>6. Poor contacting action of ignition switch.</li> <li>7. Lead wire socket loose in place.</li> <li>8. Open-circuit between ignition switch and magnetic switch.</li> <li>9. Open-circuit in pull-in coil.</li> <li>10. Poor sliding of plunger and/or pinion.</li> </ol>	Recharge battery. Replace battery.  Retighten or replace.  Retighten. Tighten or replace. Replace.  Retighten. Repair.  Replace magnetic switch. Repair.
	<b>Operating sound of magnetic switch heard.</b> <ol style="list-style-type: none"> <li>1. Battery run down.</li> <li>2. Battery voltage too low due to battery deterioration.</li> <li>3. Loose battery cable connections.</li> <li>4. Burnt main contact point, or poor contacting action of magnetic switch.</li> <li>5. Brushes are seating poorly or worn down.</li> <li>6. Weakened brush spring.</li> <li>7. Burnt commutator.</li> <li>8. Layer short-circuit of armature.</li> </ol>	Recharge battery. Replace battery.  Retighten. Replace magnetic switch.  Repair or replace.  Replace. Replace. Replace.

Condition	Possible Cause	Correction
Starting motor running but too slow (small torque).	If battery and wiring are satisfactory, inspect starting motor. 1. Insufficient contact of magnetic switch main contacts. 2. Layer short-circuit of armature. 3. Disconnected, burnt or worn commutator. 4. Worn brushes. 5. Weakened brush springs. 6. Burnt or abnormally worn end bushings.	Replace.  Replace. Repair or replace.  Replace brush. Replace spring. Replace bushing.
Starting motor running, but not cranking engine.	1. Worn pinion tip. 2. Poor sliding of over-running clutch. 3. Clutch slipping (idling). 4. Worn teeth of ring gear.	Replace over-running clutch. Repair. Replace over-running clutch. Replace flywheel.
Noise	1. Abnormally worn bush. 2. Worn pinion or worn teeth of ring gear. 3. Poor sliding of pinion (failure in return movement). 4. Worn internal or idle gear teeth. 5. Lock of oil in each part.	Replace bush. Replace pinion or flywheel. Repair or replace.  Replace. Lubricate.
Starting motor does not stop running.	1. Fused contact points of magnetic switch. 2. Short-circuit between turns of magnetic switch coil (layer short-circuit). 3. Failure of returning action in ignition switch.	Repair or replace.  Replace.  Replace.

## ON VEHICLE SERVICE

Starting motors do not require lubrication except during overhaul. When the motor is disassembled for any reason, lubricate as shown in Fig. 6G1-2.

### REMOVAL AND INSTALLATION

#### STARTING MOTOR

Use following procedure to remove starter:

- 1) Disconnect negative battery lead at battery.
- 2) Disconnect magnetic switch lead wire and battery cable from starting motor terminals.
- 3) Remove two starting motor mount bolts.
- 4) Remove starting motor.
- 5) To install, reverse the above procedure.




Fig. 6G1-3 Starting Motor Mounting

# STARTING MOTOR REPAIR

## MAGNETIC SWITCH

### REMOVAL

#### NOTE:

Before disassembling starting motor, be sure to put match mark as shown in the figure below so that any possible mistake can be avoided.




Fig. 6G1-4

- 1) Disconnect wire (switch to motor) from magnetic switch terminal.




Fig. 6G1-5

- 2) Remove magnetic switch assembly.




Fig. 6G1-6

#### NOTE:

Don't disassemble this switch. If defective, replace as a complete assembly.




Fig. 6G1-7

### INSTALLATION

Before installation, inspect plunger joint for wear and replace defective parts.

- 1) Apply grease. (Refer to Fig. 6G1-2)
- 2) Install switch assembly into front housing, referring to below figure especially for its vertical direction. And then tighten screws.




Fig. 6G1-8

- 3) Connect wire from motor to magnetic switch terminal.
- 4) Check switch for operation. (See page 6G1-15)

## MOTOR BRUSH

### REMOVAL

- 1) Remove rear bracket.




Fig. 6G1-9

- 2) Remove brush holder and brushes.




Fig. 6G1-10

### INSTALLATION

Install in reverse order of REMOVAL, noting the following.

- 1) Apply grease. (Refer to Fig. 6G1-2.)
- 2) Install brush holder to armature while pushing 4 brushes outward.




Fig. 6G1-11

- 3) Install rear bracket.

- 4) Check motor for operation. (See page 6G1-15.)

## REAR BUSH (BEARING)

### REMOVAL

- 1) Remove rear bracket.
- 2) Remove rear bracket cap, and then remove rear bush.




Fig. 6G1-12

### INSTALLATION

- 1) Install rear bush as shown below.




Fig. 6G1-13

- 2) Install rear bracket cap as shown above.

- 3) Apply grease. (Refer to Fig. 6G1-2.)

- 4) Install rear bracket.

## ARMATURE/YOKE

### REMOVAL

#### NOTE:

Before disassembling starting motor, be sure to put match marks at two locations (A & B) as shown in figure below so that any possible mistake can be avoided.




Fig. 6G1-14

- 1) Remove magnetic switch. (Refer to page 6G1-5.)
- 2) Remove brush holder. (Refer to page 6G1-6.)
- 3) Remove armature and yoke.




Fig. 6G1-15

### INSTALLATION

Install in reverse order of REMOVAL, noting the following.

- 1) Apply grease. (Refer to Fig. 6G1-2.)

#### NOTE:

If ball of armature shaft came out when removed, be sure to apply grease to ball and put it back in.




Fig. 6G1-16

- 2) Install armature into yoke.




Fig. 6G1-17

- 3) Install yoke and armature into front housing while aligning match mark "B" provided before disassembly.
- 4) Install brush holder. (Refer to page 6G1-6.)
- 5) Install magnetic switch. (Refer to page 6G1-5.)
- 6) Carry out PERFORMANCE TEST referring to page 6G1-15 in this section.



## OVER-RUNNING CLUTCH

### REMOVAL

#### NOTE:

Before disassembling starting motor, be sure to put match marks at two locations (A & B) as shown in figure below so that any possible mistake can be avoided.




Fig. 6G1-18

- 1) Remove magnetic switch assembly. (For details, refer to steps 1) and 2) of MAGNETIC SWITCH REMOVAL described on page 6G1-5.)
- 2) Remove rear bracket.
- 3) Remove brush holder and brushes.




Fig. 6G1-19

- 4) Remove yoke and armature.

- 5) Remove packing and idle gears.




Fig. 6G1-20

- 6) Remove seal rubber and plate.




Fig. 6G1-21

- 7) Remove shaft assembly with lever.




Fig. 6G1-22

8) Remove over-running clutch by removing rings.




Fig. 6G1-23

**INSTALLATION**

Install in reverse order of REMOVAL, noting the following.

- 1) Apply grease. (Refer to Fig. 6G1-2.)
- 2) Install over-running clutch assembly to gear shaft, using care for installing direction of gear shaft stop ring.




Fig. 6G1-24

3) Insert shaft ass'y into front housing with lever positioned as shown below.




Fig. 6G1-25

4) Install packing so that cuts in packing align with holes for through bolt in front housing.




Fig. 6G1-26

5) Install plate and seal rubber to front housing.




Fig. 6G1-27

6) Apply grease to ball and install ball into shaft hole.




Fig. 6G1-28

7) Install yoke and armature to front housing by aligning match marks provided before removal.




Fig. 6G1-29

8) Install brushes and brush holder. (For details, refer to steps 1) to 4) of BRUSH INSTALLATION on page 6G1-6.)

9) Tighten rear bracket bolts and brush holder screws.

10) Install magnetic switch assembly and connect wire (switch to motor) to switch terminal. (For details, refer to steps 1) to 3) of MAGNETIC SWITCH INSTALLATION on page 6G1-5.)




Fig. 6G1-30

11) Upon completion of assembly, carry out PERFORMANCE TEST referring to page 6G1-15 in this section.

# STARTING MOTOR INSPECTION

## 1. INSPECT ARMATURE

Inspect commutator for dirt or burn. Correct with sandpaper or lathe, if necessary.




Fig. 6G1-31

Check commutator for uneven wear. If deflection of dial gauge pointer exceeds limit, repair or replace.

**NOTE:**

Below specification presupposes that armature is free from bend. Bent shaft must be replaced.

	Standard	Limit
Commutator out of round	0.05 mm (0.0019 in.) or less	0.4 mm (0.015 in.)




Fig. 6G1-32

Inspect commutator for wear. If below limit, replace armature.

	Standard	Limit
Commutator outside diameter	29.4 mm (1.16 in.)	28.8 mm (1.13 in.)




Fig. 6G1-33

Inspect commutator for insulator depth. Correct or replace if below limit.

	Standard	Limit
Commutator insulator depth	0.5 – 0.8 mm (0.0196 – 0.0314 in.)	0.2 mm (0.0078 in.)




Fig. 6G1-34

**Ground Test**

Check commutator and armature core. If there is continuity, armature is grounded and must be replaced.




Fig. 6G1-35

**Open Circuit Test**

Check for continuity between segments. If there is no continuity at any test point, there is an open circuit and armature must be replaced.




Fig. 6G1-36

**2. INSPECT PLUNGER**

Inspect plunger for wear. Replace if necessary.




Fig. 6G1-37

**3. INSPECT BRUSH**

- Check brushes for wear. If below limit, replace brush.

	Standard	Limit
Brush length	17.5 mm (0.69 in.)	12 mm (0.47 in.)




Fig. 6G1-38

- Install brushes to each brush holder and check for smooth movement.

#### 4. INSPECT BRUSH HOLDER AND SPRING

Check movement of brush in brush holder. If brush movement within brush holder is sluggish, check brush holder for distortion and sliding faces for contamination.

Clean or correct as necessary.

Check for continuity across insulated brush holder (positive side) and grounded brush holder (negative side).

If continuity exists, brush holder is grounded due to defective insulation and should be replaced.




Fig. 6G1-39

Inspect brush springs for wear, damage or other abnormal conditions. Replace if necessary.

Brush spring tension (with brush holder removed from commutator.)	Standard	Limit
	2.1 kg (4.63 lb)	0.7 kg (1.54 lb)




Fig. 6G1-40

#### 5. INSPECT PINION AND OVER-RUNNING CLUTCH

Inspect pinion for wear, damage or other abnormal conditions. Check that clutch locks up when turned in direction of drive and rotates smoothly in reverse direction. Replace if necessary.




Fig. 6G1-41

Inspect spline teeth for wear or damage. Replace if necessary. Inspect pinion for smooth movement.




Fig. 6G1-42

#### 6. INSPECT ARMATURE SHAFT BUSHES

Inspect bushes for wear or damage. Replace if necessary.




Fig. 6G1-43

### 7. INSPECT MAGNETIC SWITCH

Push in plunger and release it. The plunger should return quickly to its original position. Replace if necessary.




Fig. 6G1-44

### Hold In Coil Open Circuit Test

Check for continuity across magnetic switch 'S' terminal and coil case. If no continuity exists, coil is open and should be replaced.




Fig. 6G1-46

### Pull-In Coil Open Circuit Test

Check for continuity across magnetic switch 'S' terminal and 'M' terminal. If no continuity exists, coil is open and should be replaced.




Fig. 6G1-45

### 8. INSPECT GEARS

Inspect internal gear and idle gears for wear, damage or other abnormal conditions. Replace if necessary.




Fig. 6G1-47

## 9. PERFORMANCE TEST

### CAUTION:

These test must be performed within 3 – 5 seconds to avoid burned coil.

### 1) Pull-In Test

Connect battery to magnetic switch as shown. Check that plunger and pinion move outward. If plunger and pinion don't move, replace magnetic switch.




Fig. 6G1-48

### 2) Hold-In Test

While connected as above with plunger out, disconnect negative lead from terminal 'M'. Check that plunger and pinion remain out. If plunger and pinion return inward, replace magnetic switch.




Fig. 6G1-49

### 3) Check Plunger and Pinion Return

Disconnect negative lead from switch body. Check that plunger and pinion return inward. If plunger and pinion don't return, replace magnetic switch.




Fig. 6G1-50

### 4) No-Load Performance Test

- Connect battery and ammeter to starter as shown.
- Check that starter rotates smoothly and steadily with pinion moving out. Check that ammeter indicates specified current.

Specified current
50 – 75A at 11V




Fig. 6G1-51



## SPECIFICATIONS

Voltage	12 volts
Output	1.2 kW
	*1.4 kW
Rating	30 seconds
Direction of rotation	Clockwise as viewed from pinion side
Brush length	17.5 mm (0.69 in.)
Number of pinion teeth	8
No-load characteristic	50 – 75A maximum at 11.0 volts, 3,000 r/min (rpm) minimum
	*50 – 75A maximum at 11.0 volts, 2,900 r/min (rpm) minimum
Load characteristic	300A maximum at 7.7 volts, 0.93 kg-m torque, 850 r/min (rpm) minimum
	*300A at 7.7 volts, 1.06 kg-m torque, 930 r/min (rpm) minimum
Locked rotor current	780A maximum at 4.0 volts, 1.9 kg-m minimum
	*980A maximum at 4.0volts,2.6kg-m minimum
Magnetic switch operating voltage	8 volts maximum

**NOTE:**

Data marked with asterisk (\*) is applicable to power steering system equipped car.

## SECTION 6K

## EXHAUST SYSTEM

## NOTE:

- There are two types of exhaust No. 2 pipe, one with catalytic converter and the other without it. Their use depends on regulations of each country.
- For the descriptions (items) not found in this section of this manual, refer to the same section of Service Manual mentioned in the FOREWORD of this manual.

## GENERAL DESCRIPTION

The exhaust system consists of an exhaust manifold, an exhaust No. 1 pipe, an exhaust No. 2 pipe, and seals and gaskets etc.

The catalytic converter is an emission control device added to the exhaust system to lower

the levels of Hydrocarbon (HC), Carbon Monoxide (CO) and Oxides of Nitrogen (NO<sub>x</sub>) pollutants in the exhaust gas.

**THE CATALYTIC CONVERTER REQUIRES USE OF UNLEADED FUEL ONLY.**




Fig. 6K-1 Exhaust System

# 6K-2 EXHAUST SYSTEM

Sedan model




Fig. 6K-2 Exhaust System

## SECTION 7A

# MANUAL TRANSMISSION

**NOTE:**

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## ON-CAR SERVICE

### GEAR SHIFT CONTROL

#### REMOVAL AND INSTALLATION

For removal and installation of gear shift control other than its lever adjustment after installation, use the same procedures as those described in Service Manual mentioned in the FOREWORD of this manual. Shift control lever adjustment is as follows.

For positioning control lever, loosely install 4 guide plate bolts and 4 control lever housing nuts first, adjust position and then tighten those nuts and bolts.

Control lever position distance "A"	215 mm (8.5 in.)
-------------------------------------	---------------------




Fig. 7A-1

**SECTION 7B****AUTOMATIC TRANSMISSION****NOTE:**

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

<b>DIAGNOSIS</b> .....	7B-2
Electric Shift Control System .....	7B-2
Shift lever switch checking procedure .....	7B-3
<b>ON-CAR SERVICE</b> .....	7B-7
Maintenance Service .....	7B-7
Manual Selector .....	7B-7

# DIAGNOSIS

## ELECTRIC SHIFT CONTROL SYSTEM

Process trouble shooting for electric control

system by using SELF-DIAGNOSIS and SYSTEMATIC TROUBLE SHOOTING and find a defective area reasonably.




Fig. 7B-1 Gear Shift Control System Wiring Diagram

### SHIFT LEVER SWITCH CHECKING PROCEDURE

1. Turn OFF ignition switch.
2. Disconnect couplers from A/T control module.
3. For each check, bring tester probes in touch with coupler terminals from harness side.

#### A-1 Check Procedure





Fig. 7B-2 A-1 Check

**A-2** Check Procedure





Fig. 7B-3 **A-2** Check

**A-3** Check Procedure





Fig. 7B-4 **A-3** Check



**A-4** Check Procedure





Fig. 7B-5 **A-4** Check

**N P** Check Procedure





Fig. 7B-6 **N P** Check

**7B-6 AUTOMATIC TRANSMISSION**

Separately from the above inspection, shift lever switch itself can be checked on continuity

in each shift position. Refer to following table for connection and lead wire color.

Position	Shift lever switch lead wire color									
	Black	Blue/White	Blue	Green	Green/Red	Green/Blue	Red	Yellow	Black/Red	Black/Yellow
P	○	○							○	○
R							○	○		
N	○	○	○						○	○
D	○	○	○	○						
2	○	○	○	○	○					
L	○	○	○	○	○	○				

## ON CAR SERVICE

### MAINTENANCE SERVICE

#### MANUAL SELECTOR

##### REMOVAL

1. Selector knob screws and then selector knob.
2. Console box, if equipped.
3. Select indicator assembly.
4. Illumination lamp coupler.
5. Select cable from selector lever.
6. Raise car.
7. 4 housing nuts.
8. Lever housing with selector lever from floor.

##### NOTE:

- Knob and push button must not be disassembled.
- Do not drive out detent pin.

##### INSTALLATION

Assemble selector by reversing removal procedure, replacing parts with new ones as necessary. Apply grease to portions indicated as A in figure.

##### NOTE:

- When installing knob, make sure that there is a slight clearance between detent pin and cam bottom when knob bottom is pushed in all the way.
- Check selector for proper operation as follows.
  1. With knob button pushed half way, N to R and D to 2 shifts are available (but not any other shift).
  2. With knob button pushed all the way in, 2 to L and R to P shifts are available.
- For adjustment of interlock cable, refer to the Service Manual mentioned in the FOREWORD of this manual.
- Check that illumination lamp lights when light switch is turned ON.

Tightening torque	N·m	kg·m	lb·ft
Selector lever shaft nut	18 – 22	1.8 – 2.2	13.0 – 15.5
Housing nuts	10 – 16	1.0 – 1.6	7.5 – 11.5




Fig. 7B-7 Manual Selector Components

# SECTION 8

## BODY ELECTRICAL SYSTEM

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

### CONTENTS

<b>BODY ELECTRICAL SYSTEM</b> .....	8-2
Fuses .....	8-2
<b>INSTRUMENTS AND GAUGES</b> .....	8-3
Combination Meter Wiring .....	8-3
Fuel Level Meter and Gauge Unit .....	8-4
<b>ON CAR SERVICE</b> .....	8-5
Lighting Systems .....	8-5
Central Door Locking System (If equipped) .....	8-6
Power Window Control System (If equipped) .....	8-7
Wiring Harness Routing .....	8-8

# BODY ELECTRICAL SYSTEM

## FUSES

The main fuse block is located on the fender apron panel in the engine room and junction/fuse block is installed to underside of instrument cover panel.

The designation and location of each fuse, refer to Service Manual mentioned in the FOREWORD of this manual.

### CAUTION:

- When replacing a fuse, be sure to use one having a correct rated amperage.
- Before replacing a fuse, turn OFF every switch of electric equipments including main switch.

## MAIN FUSE BLOCK CIRCUIT




Fig. 8-1 Main Fuse Block Circuit



## FUEL LEVEL METER AND GAUGE UNIT (FOR 4WD MODEL)

### DESCRIPTION OF CIRCUIT

The fuel level meter circuit consists of the fuel level meter installed inside the combination meter and the fuel level gauges installed to the fuel tank.




Fig. 8-3

### INSPECTION

#### GAUGE UNIT

Use an ohmmeter to confirm that resistance of level gauge unit changes with change of float position. Float position-to-resistance relationship can be plotted in a graph as shown below.




Fig. 8-4 Resistance-Fuel Level Relationship




Fig. 8-5 Checking Fuel Gauge Unit

#### • Fuel level gauge No. 1

Position	Resistance
E	47.5 – 53.5 Ω
F	1.0 – 2.5 Ω

#### • Fuel level gauge No. 2

Position	Resistance
E	66.5 – 72.5 Ω
F	1.0 – 2.5 Ω



# ON CAR SERVICE

## LIGHTING SYSTEMS

### BACK-UP LIGHTS

#### WIRING CIRCUIT




Fig. 8-6 Back-up Light Circuit (For M/T model)




Fig. 8-7 Back-up Light Circuit (For A/T model)

### TROUBLE DIAGNOSIS

Trouble	Possible cause	Correction
Back-up lights do not light.	Fuse blown Back-up light switch or shift lever switch faulty Wiring or grounding faulty	Replace fuse to check for short. Check switch. Repair as necessary.

# CENTRAL DOOR LOCKING SYSTEM (If equipped)

## WIRING DIAGRAM




Fig. 8-7-1

### Trouble diagnosis

Condition	Possible cause	Correction
All power door locks do not operate.	<ul style="list-style-type: none"> <li>• Main fuse and/or fuses blown</li> <li>• Wiring or grounding faulty</li> <li>• Power door lock switch, door lock switch or knob switch faulty</li> <li>• Controller faulty</li> </ul>	Replace main fuse and/or fuses to check for short. Repair as necessary. Replace. Replace.
Only one power door lock does not operate.	<ul style="list-style-type: none"> <li>• Wiring or socket faulty</li> <li>• Actuator (door lock motor) faulty</li> </ul>	Repair as necessary. Replace.

# POWER WINDOW CONTROL SYSTEM (If equipped)

## WIRING DIAGRAM




Fig. 8-7-2

### Trouble Diagnosis

Condition	Possible cause	Correction
All power window motors do not operate.	<ul style="list-style-type: none"> <li>Main fuse and/or fuses blown</li> <li>Wiring or grounding faulty</li> </ul>	Replace main fuse and/or fuses to check for short. Repair as necessary.
Some switches do not operate.	<ul style="list-style-type: none"> <li>Wiring or socket faulty</li> <li>Window lock switch faulty</li> </ul>	Repair as necessary. Replace.
Only one actuator does not faulty.	<ul style="list-style-type: none"> <li>Wiring or socket faulty</li> <li>Actuator faulty</li> </ul>	Repair as necessary. Replace.

# WIRING HARNESS ROUTING

For the wirings not found in this section, refer to the Service Manual mentioned in the FOREWORD of this manual.

## COWL TOP PANEL WIRING





Fig. 8-8 Cowl Top Panel Wiring

**ENGINE WIRING** (For Fuel Injection Model)



- |                                 |                                              |
|---------------------------------|----------------------------------------------|
| 1. To pressure sensor           | 10. Engine wiring harness No. 5              |
| 2. To injector                  | 11. Starting motor cable                     |
| 3. To throttle position sensor  | 12. ISC solenoid valve                       |
| 4. To water temperature sensor  | 13. To starting motor                        |
| 5. To air temperature sensor    | 14. Ground                                   |
| 6. To EGR V.S.V.                | 15. To generator                             |
| 7. To water temperature gauge   | 16. To oil pressure switch and oxygen sensor |
| 8. To radiator fan motor switch |                                              |
| 9. To distributor (CAS)         |                                              |

Fig. 8-9 Engine Wiring

## AUTOMATIC TRANSMISSION WIRING





Fig. 8-10 Automatic Transmission Wiring

# INSTRUMENT PANEL WIRING

(Left hand steering car)



- |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                   |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <ul style="list-style-type: none"> <li>1. To front speaker (Optional)</li> <li>2. To blower resistor</li> <li>3. To blower motor</li> <li>4. To heater fan switch</li> <li>5. To cigar lighter (Optional)</li> <li>6. Ground</li> <li>7. To rear wiper/washer switch (If equipped)</li> <li>8. To illumination controller (If equipped)</li> <li>9. To floor wiring harness No. 3 (Except West German market)</li> <li>10. To junction block (or main wiring harness No. 1)</li> <li>11. To main wiring harness No. 1</li> <li>12. To front fog light switch (If equipped)</li> <li>13. To combination meter</li> </ul> | <ul style="list-style-type: none"> <li>14. To rear defogger and front fog light switch (If equipped)</li> <li>15. To radio (Optional)</li> <li>16. To seat heater switch (R) (Optional)</li> <li>17. To head light washer switch (If equipped) or to head light leveling switch (If equipped)</li> <li>18. To seat heater switch (L) (Optional)</li> <li>19. To rear fog light switch (If equipped)</li> <li>20. To mirror switch (Optional)</li> <li>21. To mirror motor (Optional)</li> <li>22. ALDL connector</li> <li>23. To clock</li> <li>24. To warning controller/buzzer</li> <li>25. To ash tray illumination</li> </ul> |
|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

(Right hand steering car)





Fig. 8-11 Instrument Panel Wiring

**FLOOR WIRING (For Sedan model)**

(Left hand steering car)



- |                                                         |                                        |
|---------------------------------------------------------|----------------------------------------|
| 1. To instrument panel wiring harness No. 2             | 9. To seat heater (if equipped)        |
| 2. To junction block                                    | 10. To fuel level gauge unit           |
| 3. To main wiring harness No. 1                         | 11. To fuel pump                       |
| 4. To A/T shift illumination light (For A/T model only) | 12. To trunk room wiring harness No. 4 |
| 5. To A/T shift lock solenoid (If equipped)             | 13. To right side front door           |
| 6. Floor wiring harness No. 3                           | 14. To left side front door            |
| 7. To seat belt switch (If equipped)                    | 15. To right side rear door            |
| 8. To parking brake switch                              | 16. To left side rear door             |

(Right hand steering car)





Fig. 8-12 Floor Wiring



### TRUNK ROOM WIRING (For Sedan Model)

(Left hand steering car)



- |                                           |                                     |
|-------------------------------------------|-------------------------------------|
| 1. Floor wiring harness No. 3             | 8. To rear combination light (Left) |
| 2. Trunk room wiring harness No. 4        | 9. Trunk lid wiring harness No. 7   |
| 3. To rear speaker                        | 10. To rear door switch             |
| 4. Trunk room light                       | 11. To rear defogger (-)            |
| 5. To high mount stop light (If equipped) | 12. To rear defogger (+)            |
| 6. To trunk room light switch             | 13. To back-up light                |
| 7. To rear combination light (Right)      | 14. To license light                |
|                                           | 15. To rear fog light (If equipped) |

(Right hand steering car)




Fig. 8-13 Trunk Room Wiring

# SECTION 9

## BODY SERVICE

**NOTE:**

- For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.
- Illustrations in this section may somewhat differ from actual vehicles depending on specifications or countries.

### CONTENTS

<p><b>ON CAR SERVICE</b> ..... 9- 2</p> <p><b>FRONT DOOR</b> ..... 9- 2</p> <p style="padding-left: 20px;">Door Glass ..... 9- 2</p> <p style="padding-left: 20px;">Door Window Regulator ..... 9- 4</p> <p style="padding-left: 20px;">Front Door Lock ..... 9- 5</p> <p style="padding-left: 20px;">Front Door Assembly: ..... 9- 7</p> <p><b>REAR DOOR</b> ..... 9- 8</p> <p style="padding-left: 20px;">Door Glass ..... 9- 8</p>	<p><b>WINDOW SHIELD</b> ..... 9- 9</p> <p><b>SEAT BELTS</b> ..... 9-14</p> <p><b>BODY DIMENSIONS</b> ..... 9-15</p> <p style="padding-left: 20px;">For Sedan Model ..... 9-15</p>
---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

## ON CAR SERVICE

### FRONT DOOR




Fig. 9-1 Front Door Assembly

### DOOR GLASS REMOVAL

Remove following parts.

- 1) Inside handle bezel.
- 2) Door armrest. (or trim mounting screw)
- 3) Window regulator handle. (if equipped)

For its removal, pull off snap by using a cloth as shown below.




Fig. 9-2

- 4) Door mirror inner garnish.
- 5) Inner weatherstrip (5 door model).
- 6) Door trim, and power window switch lead wire at coupler. (if equipped)




Fig. 9-3 Removing Door Trim

- 7) Door sealing cover.
- 8) Door outside weatherstrip.
- 9) Glass bottom channel attaching screws.




Fig. 9-4

- 2) Adjust equalizer of window regulator so that measurements A and B in Fig. 9-7 are equal to each other.




Fig. 9-6 Adjusting Equalizer

- 10) Take out door glass together with bottom channel.
- 11) Detach glass from bottom channel.

**INSTALLATION**

Reverse the removal sequence to install door glass noting the following points:

- 1) When installing glass to bottom channel, coat channel with soap water and tap it with a plastic hammer.
- Glass-fitted position of bottom channel is as shown below.




Fig. 9-5




Fig. 9-7

3) Securely seal door sealing cover with adhesive.




Fig. 9-8

4) Install door window regulator handle so that it has a  $45^\circ$  angle when glass is fully closed, as illustrated below.




Fig. 9-9

## DOOR WINDOW REGULATOR

### REMOVAL

Remove following parts.

- 1) Door glass. (See previous section.)
- 2) Front door trim bracket.
- 3) Power window motor lead wire at coupler.
- 4) Door window regulator attaching screws (six pcs.) Take out regulator through hole "A".




Fig. 9-10

### INSPECTION

- a. Check gear for wear or damage.
- b. Check spring for weakened condition.

### INSTALLATION

Reverse removal sequence to install door window regulator.

- 1) Apply multi-purpose grease to sliding parts.




Fig. 9-11 Greasing Sliding Points

## FRONT DOOR LOCK




Fig. 9-12 Front Door Lock Assembly

### REMOVAL

Remove following parts.

- 1) Inside handle bezel.
- 2) Door armrest. (or trim mounting screw)
- 3) Window regulator handle. (if equipped)

For its removal, pull off snap by using a cloth as shown below.




Fig. 9-13

- 4) Inner weatherstrip (5 door model).
- 5) Door trim.




Fig. 9-14 Removing Door Trim

- 6) Door sealing cover.
- 7) Front door rear sash.
- 8) Door inside handle and door latch ass'y.  
 After disconnecting each joint of control link, remove door inside handle, door locking motor lead wire (if equipped) and door latch ass'y.




Fig. 9-15 Disconnecting Door Opening Control Link




Fig. 9-16 Disconnecting Rod

**INSTALLATION**

Reverse removal sequence for installation while using care for following items.

- 1) Door outside opening rod  
 When installing opening rod 1 to outside handle 2, turn joint 3 to adjust distance "A" to 0 to 2 mm (0 to 0.08 in.) as shown below.

**NOTE:**

Do not push down opening link 6 when adjusting and installing opening rod.




Fig. 9-17

- 2) Door latch striker  
 Move door latch striker up and down so that its shaft 3 approximately aligns with the center of groove "C" of door latch.

**NOTE:**

Striker should be placed level and moved vertically. Do not adjust door latch.




Fig. 9-18

Move door latch striker sideways to adjust to 0 mm (0 in.) the door surface-to-body surface difference with door closed.




Fig. 9-19

In order to correctly obtain door striker position in fore-and-aft direction, increase or decrease number of spacers inserted between body and striker to adjust it. Dimension "D" should be adjusted to 12.6 to 14.6 mm (0.50 to 0.57 in.).




Fig. 9-20

**NOTE:**  
Apply oil or grease to striker joints periodically.

## FRONT DOOR ASSEMBLY




Fig. 9-21

### REMOVAL

1) Remove stopper pin upward by tapping it with hammer.




Fig. 9-22

2) Using a jack, support door panel with a piece of wood placed between jack and panel.  
3) Remove door ass'y by loosening hinge mounting bolts.






Fig. 9-23

### INSTALLATION

Reverse removal sequence to install front door.

- When weatherstrip is hardened, water leak may develop. In such case, replace it with new one.
- After installing, adjust door latch striker position by referring to FRONT DOOR LOCK INSTALLATION section so that door is positioned correctly.

## REAR DOOR

### DOOR GLASS

#### REMOVAL AND INSTALLATION

For removal and installation of door glass other than its bottom channel position adjustment, use the same procedures as those described in the Service Manual mentioned in the FOREWORD of this manual. When installing glass to bottom channel, coat channel with soap water and tap it with a plastic hammer. Glass-fitted position of bottom channel is as shown below.




Fig. 9-24

# WINDSHIELD

The Windshield is installed by using a special type of adhesive (that is, one component urethane adhesive used with primer). For window glass replacement, it is important to use an adhesive which provides sufficient adhesion strength and to follow the proper procedure.

**CAUTION:**  
 Described here is the glass replacement by using one component urethane adhesive to be used with primer in combination. Each adhesive has its own drying and setting time and must be handled and used in a certain specific procedure. Negligence in following such procedure or misuse of the adhesive in any way hinders its inherent adhesive property. Therefore, before the work, make sure to read carefully the instruction and description given by the maker of the adhesive to be used and be sure to follow the procedure and observe each precaution throughout the work.

Use an adhesive of above mentioned type which has following property.

Shearing strength	40 kg/cm <sup>2</sup> or more (569 lb/in <sup>2</sup> )
-------------------	------------------------------------------------------------

Adhesive materials and tools required for removal and installation

- One component urethane adhesive and primers used in combination (For one sheet of window glass).  
 Adhesive (600 g (21.2 oz.))  
 Primer for glass (20 g (0.7 oz.))  
 Primer for body (20 g (0.7 oz.))  
 Primer for urethane (moulding) (20g (0.7 oz))
- Eyeleteer
- Piano string
- Brush for primer application (3 pcs)
- Knife
- Rubber sucker grip
- Sealant gun (for filling adhesive)
- Putty spatula (for correcting adhered parts)




Fig. 9-24 Windshield

**REMOVAL**

- 1) Clean both inside and outside of glass and around it.
- 2) Remove wiper arms, garnish and stopper.
- 3) Remove moulding and moulding joints by cutting with knife.
- 4) Using tape, cover body surface around glass to prevent any damage.
- 5) Remove room mirror, sunshades, and front pillar trims (right & left).
- 6) (For Hatch-Back model only)

Warm up front part of roof lining. Then, remove front side rib of roof lining from between front glass and body.




Fig. 9-27




Fig. 9-25




Fig. 9-28

- 7) Drill hole with eyeleteer through adhesive and let piano string through it.

- 9) Using knife, smooth adhesive remaining on body side so that it is 1 – 2 mm thick all around.

**NOTE:**

Before using knife, clean it with alcohol or the like to remove oil from it.




Fig. 9-26

- 8) Cut adhesive all around glass with piano string.




Fig. 9-29

**NOTE:**

Use piano string as close to glass as possible so as to prevent damage to body.

- 10) When re-using glass, remove adhesive from glass, using care not to damage primer coated surface.




Fig. 9-30

**INSTALLATION**

- 1) Using cleaning solvent, clean window frame (body) where glass is to be adhered. (Let it dry for more than 10 minutes.)
- 2) Install stopper (2 pcs) to lower side of window frame (body).
- 3) Peel paper from one side of new glass spacer and attach that lower side to windshield glass.




Fig. 9-31

- 4) Install new upper moulding to glass. Warming moulding for over half an hour at 35° C (95°F) temperature will facilitate work.

- 5) To determine installing position of glass to body, position glass against body so that clearance between upper end of glass and body is about 6 mm (0.236 in) and clearances between each side end (right & left) of glass and body are even. Then mark mating marks on glass and body as shown below. Upper clearance can be adjusted by moving stoppers position.




Fig. 9-32

- 6) Using new brush, apply sufficient amount of primer for body along body surface where window is to be adhered.

**NOTE:**

Be sure to refer to maker's instruction for proper handling and drying time.




Fig. 9-33

- 7) Clean glass surface to be adhered to window with clean cloth. If cleaning solvent is used, let it dry for more than 10 minutes.
- 8) Clean moulding surface "A" with clean cloth. (Refer to below figure.)




Fig. 9-34

- 9) Using new brush, apply sufficient amount of primer for glass along glass surface to be adhered to window.

**NOTE:**

- Be sure to refer to maker's instruction for proper handling and drying time.
- Do not touch primer coated surface.




Fig. 9-35

- 10) Using new brush, apply sufficient amount of primer for moulding (Urethane) to surface "A" as shown in Fig. 9-34.

**NOTE:**

- Be sure to refer to maker's instruction for proper handling and drying time.
- Do not touch primer coated surface.

- 11) Apply adhesive referring to Fig. 9-36.

**NOTE:**

- Start from bottom side of glass.
- Be careful not to damage primer.
- Height of adhesive applied to lower side should be higher than that of other three sides.
- Press glass against body quickly after adhesive is applied.
- Use of rubber sucker grip is helpful to hold and carry glass after adhesive is applied.




Fig. 9-36 Application of Adhesive

- 12) Peel remaining paper from moulding and glass spacer.
- 13) Holding rubber sucker grips, place glass onto body by aligning mating marks marked in step 4) and press it.




Fig. 9-37

- 14) Check for water leakage by pouring water over window through hose. If leakage is found, dry window and fill leaky point with adhesive. If water still leaks even after that, remove glass and start installation procedure all over again.

**NOTE:**

- Do not use high pressure water.
- Do not blow compressed air directly at adhesive applied part when drying.
- Do not use infrared lamp or the like for drying.




Fig. 9-38

## SEAT BELTS (If equipped)

### WARNING:

If replacing seat belt is necessary, replace buckle and ELR (or webbing) together as a set. This is for the reason of ensuring locking of tongue plate with buckle.


If these parts are replaced individually, such a locking condition may become unreliable. For this reason, Suzuki will supply only the spare buckle and ELR (or webbing) in a set part.

### CAUTION:


Upon completion of installation, note the following.

- Sudden closing of door before adhesive is completely set may cause glass to become loose or to come off. Therefore, if door is opened or closed before adhesive is completely set, make sure to open all door glasses and use proper care.
- If moulding is not securely in place, hold it down with a tape until adhesive is completely set.
- Each adhesive has its own setting time. Be sure to refer to maker's instruction, check setting time of adhesive to be used and observe precautions to be taken before adhesive is set.
- Refrain from driving till adhesive is completely set so as to ensure proper and sufficient adhesion.

# BODY DIMENSIONS (For Sedan model)



MEASUREMENT POSITION	HOLE DIAMETER mm (in)
k, l, o, p, t	φ 8 (φ 0.315)
m, n, q, s	φ 6.5 (φ 0.256)
r	φ 5.2 (φ 0.205)



Above figure shows where parking brake is installed.

MEASUREMENT POSITION	LENGTH mm (in)	MEASUREMENT POSITION	LENGTH mm (in)
k - m	1 167 (45.94)	n - t	1 090 (42.91)
k - o	1 053 (41.46)	o - q	708 (27.87)
k - u	978 (38.50)	o - r	981 (38.62)
l - u	954 (37.56)	o - s	649 (25.55)
l - p	1 043 (41.06)	p - r	1 131 (44.53)
m - t	1 046 (41.18)	p - s	637 (25.08)
m - u	814 (32.05)	t - u	647 (25.47)
n - o	826 (32.52)		

Fig. 9-39 Body Dimensions



# WIRING DIAGRAM

## CONTENTS

### 1. WIRING DIAGRAM FOR HATCH-BACK MODEL


VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND M/T .....	1- 1
VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND A/T .....	1- 2
VEHICLE WITH DIM-DIP SYSTEM AND M/T .....	1- 3
VEHICLE WITH DIM-DIP SYSTEM AND A/T .....	1- 4
GERMAN SPEC. VEHICLE WITH M/T .....	1- 5
GERMAN SPEC. VEHICLE WITH A/T .....	1- 6
OTHER SPEC. VEHICLE WITH FUEL INJECTION SYSTEM AND M/T .....	1- 7
OTHER SPEC. VEHICLE WITH FUEL INJECTION SYSTEM AND A/T .....	1- 8
CARBURETOR VEHICLE WITH M/T .....	1- 9
CARBURETOR VEHICLE WITH A/T .....	1-10

### 2. WIRING DIAGRAM FOR SEDAN MODEL

VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND M/T .....	2- 1
VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND A/T .....	2- 2
VEHICLE WITH DIM-DIP SYSTEM AND M/T .....	2- 3
VEHICLE WITH DIM-DIP SYSTEM AND A/T .....	2- 4
GERMAN SPEC. VEHICLE WITH M/T .....	2- 5
GERMAN SPEC. VEHICLE WITH A/T .....	2- 6
OTHER SPEC. VEHICLE WITH FUEL INJECTION SYSTEM AND M/T .....	2- 7
OTHER SPEC. VEHICLE WITH FUEL INJECTION SYSTEM AND A/T .....	2- 8
CARBURETOR VEHICLE WITH M/T .....	2- 9
CARBURETOR VEHICLE WITH A/T .....	2-10

**1-1 HARLEM-BAK (M107)  
VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND M/T**

NOTE: The parts with (\*) are provided or not depending on specifications.  
 \* Fuel gauge and fuel pump wiring for 4WD model refer to the WIRING DIAGRAM of the Service Manual in the FRONTSIDE of this manual.






**1-3 HATCH-BACK MODEL  
VEHICLE WITH DIM DIP SYSTEM AND MT**

NOTE: \* The parts with (\*) are provided or not depending on specifications.  
 \* For design and the wiring diagram for DIM model refer to the WIRING DIAGRAM of the Service Manual mentioned in the FOREWORD of this manual.

Wiring Diagram	Part No.	Description	Quantity
Wiring Diagram	81	Wiring Diagram	1
	82	Wiring Diagram	1
	83	Wiring Diagram	1
	84	Wiring Diagram	1
	85	Wiring Diagram	1
	86	Wiring Diagram	1
	87	Wiring Diagram	1
	88	Wiring Diagram	1
	89	Wiring Diagram	1
	90	Wiring Diagram	1
	91	Wiring Diagram	1
	92	Wiring Diagram	1
	93	Wiring Diagram	1
	94	Wiring Diagram	1
	95	Wiring Diagram	1
Wiring Diagram	96	Wiring Diagram	1
	97	Wiring Diagram	1
	98	Wiring Diagram	1
	99	Wiring Diagram	1
	100	Wiring Diagram	1
	101	Wiring Diagram	1
	102	Wiring Diagram	1
	103	Wiring Diagram	1
	104	Wiring Diagram	1
	105	Wiring Diagram	1
	106	Wiring Diagram	1
	107	Wiring Diagram	1
	108	Wiring Diagram	1
	109	Wiring Diagram	1






**1-5 HATCH-BACK MODEL  
GERMAN MP4: VPH131 WITH MET**

**Wiring Diagram**


100	100	100	100
101	101	101	101
102	102	102	102
103	103	103	103
104	104	104	104
105	105	105	105
106	106	106	106
107	107	107	107
108	108	108	108
109	109	109	109
110	110	110	110
111	111	111	111
112	112	112	112
113	113	113	113
114	114	114	114
115	115	115	115
116	116	116	116
117	117	117	117
118	118	118	118
119	119	119	119
120	120	120	120
121	121	121	121
122	122	122	122
123	123	123	123
124	124	124	124
125	125	125	125
126	126	126	126
127	127	127	127
128	128	128	128
129	129	129	129
130	130	130	130
131	131	131	131
132	132	132	132
133	133	133	133
134	134	134	134
135	135	135	135
136	136	136	136
137	137	137	137
138	138	138	138
139	139	139	139
140	140	140	140
141	141	141	141
142	142	142	142
143	143	143	143
144	144	144	144
145	145	145	145
146	146	146	146
147	147	147	147
148	148	148	148
149	149	149	149
150	150	150	150
151	151	151	151
152	152	152	152
153	153	153	153
154	154	154	154
155	155	155	155
156	156	156	156
157	157	157	157
158	158	158	158
159	159	159	159
160	160	160	160
161	161	161	161
162	162	162	162
163	163	163	163
164	164	164	164
165	165	165	165
166	166	166	166
167	167	167	167
168	168	168	168
169	169	169	169
170	170	170	170
171	171	171	171
172	172	172	172
173	173	173	173
174	174	174	174
175	175	175	175
176	176	176	176
177	177	177	177
178	178	178	178
179	179	179	179
180	180	180	180
181	181	181	181
182	182	182	182
183	183	183	183
184	184	184	184
185	185	185	185
186	186	186	186
187	187	187	187
188	188	188	188
189	189	189	189
190	190	190	190
191	191	191	191
192	192	192	192
193	193	193	193
194	194	194	194
195	195	195	195
196	196	196	196
197	197	197	197
198	198	198	198
199	199	199	199
200	200	200	200

**NOTE:** The items with (\*) are provided or not depending on specifications.  
 (\*) Part shown are that are using the same model code as the standard part.  
 OIAW of the Service Manual mentioned in the FOREWORD of this manual.




1-6 HATCH-BACK MODEL  
GERMAN SPEC. VEHICLE WITH A/T

NOTE - The parts with (\*) are provided or not depending on specifications.



**1-7 HATCHBACK MODIFI  
OTHER SPEC. VEHICLE WITH FUEL INJECTION SYSTEM AND M/T**

**NOTE** • The parts with \*\* are provided or not depending on specifications.  
 • Fuel gases and fuel pump wiring for TWC should refer to the WIRING DIA.  
 • SM of the Service Manual mentioned in the REFERENCE of this manual.  
 • The parts or wiring with T (2) are provided for left (RH) hand steering car.








**1-9 MATCH BACK MODEL  
CARBURETOR VEHICLE WITH NIT**


1	250	250	250
2	250	250	250
3	250	250	250
4	250	250	250
5	250	250	250
6	250	250	250
7	250	250	250
8	250	250	250
9	250	250	250
10	250	250	250
11	250	250	250
12	250	250	250
13	250	250	250
14	250	250	250
15	250	250	250
16	250	250	250
17	250	250	250
18	250	250	250
19	250	250	250
20	250	250	250
21	250	250	250
22	250	250	250
23	250	250	250
24	250	250	250
25	250	250	250
26	250	250	250
27	250	250	250
28	250	250	250
29	250	250	250
30	250	250	250
31	250	250	250
32	250	250	250
33	250	250	250
34	250	250	250
35	250	250	250
36	250	250	250
37	250	250	250
38	250	250	250
39	250	250	250
40	250	250	250
41	250	250	250
42	250	250	250
43	250	250	250
44	250	250	250
45	250	250	250
46	250	250	250
47	250	250	250
48	250	250	250
49	250	250	250
50	250	250	250
51	250	250	250
52	250	250	250
53	250	250	250
54	250	250	250
55	250	250	250
56	250	250	250
57	250	250	250
58	250	250	250
59	250	250	250
60	250	250	250
61	250	250	250
62	250	250	250
63	250	250	250
64	250	250	250
65	250	250	250
66	250	250	250
67	250	250	250
68	250	250	250
69	250	250	250
70	250	250	250
71	250	250	250
72	250	250	250
73	250	250	250
74	250	250	250
75	250	250	250
76	250	250	250
77	250	250	250
78	250	250	250
79	250	250	250
80	250	250	250
81	250	250	250
82	250	250	250
83	250	250	250
84	250	250	250
85	250	250	250
86	250	250	250
87	250	250	250
88	250	250	250
89	250	250	250
90	250	250	250
91	250	250	250
92	250	250	250
93	250	250	250
94	250	250	250
95	250	250	250
96	250	250	250
97	250	250	250
98	250	250	250
99	250	250	250
100	250	250	250



NOTE • The parts with (1) are provided or not depending on specification.  
 • Fuel gauge and fuel gauge wiring for AEC model refer to the WIRING DIAG. OF THE SERVICE MANUAL mentioned in the FOREWORD of this manual.  
 • The parts or wiring with (2) are provided for left hand driving car.


1-10 MATCH-BOOK MITSUBISHI  
CARBURETOR VEHICLE WITH A/T

NOTE - The parts with (\*) are provided or not depending on specifications.  
- The parts in wiring with (1) are provided for left (right) hand steering car.




**2-1 SEDAN MODEL  
VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND M/T**

NOTE • The parts with (\*) are provided as per accessories or specification.




2-2 SEDAN MODEL  
VEHICLE WITH DRL (DAY TIME RUNNING LIGHT) SYSTEM AND A/T

NOTE - The parts with (\*) are provided or not depending on specifications.




**2-3** SEDAN MODEL  
VEHICLE WITH DIM-DIP SYSTEM AND MT

NOTE: \* 14 PARTS WITH (\*) ARE PROVIDED OR NOT DEPENDS ON CONFIGURATION.




2-4 SEDAN MODEL  
VEHICLE WITH DIM DIP SYSTEM AND A/T

NOTE - The parts with (\*) are provided as per depending on specification.



2-5 SKODA MODEL  
GERMAN SPEC. VEHICLE WITH M/T


NOTE - The parts with (\*) are provided as not depending on specifications.






2.6 SEDAN MODEL  
GERMAN SPEC. VEHICLE WITH A/T

NOTE - The parts with (\*) are provided or not depending on specifications




**2-7 SEDAN MODEL**  
**(OTHER NPPL VEHICLES WITH HIGH INJECTION SYSTEM AND MI)**

**NOTE** - The parts with (\*) are provided or not depending on specifications.  
 - The parts in white with (\*) are provided for left hand drive car.




**2-8 SEDAN MODEL  
OTHER SPEC. VEHICLE WITH FUEL INJECTION SYSTEM AND A/T**

**NOTE** - The parts with (\*) are omitted in case depending on specifications.  
 \* The parts on wiring with 1 (2) are provided for left (right) hand driving car.



2-9 SEDAN MODEL  
CARBURETOR VEHICLE WITH W/I

NOTE • The parts with (\*) are provided as not depending on specifications.  
• The parts are wiring with 1/22 are provided for left hand driving car.



WIRE NO.	WIRE COLOR	WIRE NO.	WIRE COLOR
1	B	101	B
2	W	102	B
3	W	103	B
4	W	104	B
5	W	105	B
6	W	106	B
7	W	107	B
8	W	108	B
9	W	109	B
10	W	110	B
11	W	111	B
12	W	112	B
13	W	113	B
14	W	114	B
15	W	115	B
16	W	116	B
17	W	117	B
18	W	118	B
19	W	119	B
20	W	120	B
21	W	121	B
22	W	122	B
23	W	123	B
24	W	124	B
25	W	125	B
26	W	126	B
27	W	127	B
28	W	128	B
29	W	129	B
30	W	130	B
31	W	131	B
32	W	132	B
33	W	133	B
34	W	134	B
35	W	135	B
36	W	136	B
37	W	137	B
38	W	138	B
39	W	139	B
40	W	140	B
41	W	141	B
42	W	142	B
43	W	143	B
44	W	144	B
45	W	145	B
46	W	146	B
47	W	147	B
48	W	148	B
49	W	149	B
50	W	150	B
51	W	151	B
52	W	152	B
53	W	153	B
54	W	154	B
55	W	155	B
56	W	156	B
57	W	157	B
58	W	158	B
59	W	159	B
60	W	160	B
61	W	161	B
62	W	162	B
63	W	163	B
64	W	164	B
65	W	165	B
66	W	166	B
67	W	167	B
68	W	168	B
69	W	169	B
70	W	170	B
71	W	171	B
72	W	172	B
73	W	173	B
74	W	174	B
75	W	175	B
76	W	176	B
77	W	177	B
78	W	178	B
79	W	179	B
80	W	180	B
81	W	181	B
82	W	182	B
83	W	183	B
84	W	184	B
85	W	185	B
86	W	186	B
87	W	187	B
88	W	188	B
89	W	189	B
90	W	190	B
91	W	191	B
92	W	192	B
93	W	193	B
94	W	194	B
95	W	195	B
96	W	196	B
97	W	197	B
98	W	198	B
99	W	199	B
100	W	200	B



Prepared by

**SUZUKI MOTOR CORPORATION**

TECHNICAL DEPARTMENT  
AUTOMOBILE SERVICE DIVISION

1st Ed. August, 1991

Printed in Japan

Printing: July, 1992

244

EDIT Date: 17.10.2003

**SUZUKI MOTOR CORPORATION**



Printed in Japan (TM)