

**SUZUKI**

TECHNICAL DEPT.

**SF413**

**SUPPLEMENTARY SERVICE MANUAL**

**GTi**

USE THIS SUPPLEMENTARY SERVICE MANUAL  
WITH SF413GTI SERVICE MANUAL (99500-64B01)

**SUZUKI**  
Caring for Customers

99501-64B00-01E

(英)

# IMPORTANT

## WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the words **WARNING**, **CAUTION**, and **NOTE** have, special meanings. Pay special attention to the messages highlighted by these signal words.

### **WARNING:**

Indicates a potential hazard that could result in death or injury.

### **CAUTION:**

Indicates a potential hazard that could result in vehicle damage.

### **NOTE:**

Indicates special information to make maintenance easier or instructions clearer.

## FOREWORD

This SUPPLEMENTARY SERVICE MANUAL contains those items on the structure, service procedures, etc. that were modified for the FACE-LIFT model produced in and after June 1991.

Applicable model:  
SF413 GTi of and after following body No. or vehicle identification number.

For European/ Australian markets	For other markets
(X) JSAEAA34S00140001 (X) ~	AA34S-200001 ~

When servicing a car with a body number after the above listed numbers, refer to this Supplementary Service Manual first. And then, for any section, item or description not found in this supplement, refer to "SF413GTi SERVICE MANUAL".

**RELATED SERVICE MANUAL:**  
SF413GTi Service Manual (99500-64B01)

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others. Therefore, note that illustrations may differ from the vehicle being actually serviced. The right is reserved to make changes at any time without notice.

TABLE OF CONTENTS	SECTION
<b>GENERAL INFORMATION</b> Maintenance and Lubrication	<b>0B</b>
<b>HEATING AND AIR CONDITIONING</b> Heating and Ventilation	<b>1A</b>
<b>BUMPER AND SHEET METAL</b>	<b>2</b>
<b>STEERING, SUSPENSION WHEEL AND TIRES</b> Power Steering (P/S) System (If equipped)	<b>3</b> <b>3B1</b>
Steering Wheel and Column	<b>3C</b>
<b>BRAKES</b>	<b>5</b>
<b>ENGINE</b> Engine Mechanical	<b>6</b> <b>6A</b>
Electronic Fuel Injection System	<b>6E</b>
Ignition System	<b>6F</b>
Cranking System (1.2 kW and 1.4 kW Type)	<b>6G1</b>
Emission Controls	<b>6J</b>
Engine Exhaust	<b>6K</b>
<b>TRANS.</b> Manual Transmission	<b>7A</b>
<b>BODY ELECTRICAL SYSTEM</b>	<b>8</b>
<b>BODY SERVICE</b>	<b>9</b>

WIRING DIAGRAM

**SUZUKI MOTOR CORPORATION**

TECHNICAL DEPARTMENT  
AUTOMOBILE SERVICE DIVISION





## SECTION 0B

# MAINTENANCE AND LUBRICATION

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

### CONTENTS

MAINTENANCE SCHEDULE ..... 0B-1  
 MAINTENANCE SERVICE ..... 0B-1  
 RECOMMENDED FLUIDS AND LUBRICANTS ..... 0B-1

## MAINTENANCE SCHEDULE

Interval: This interval should be judged by odometer reading or months, whichever comes first.	This table includes services as scheduled up to 48,000 miles (80,000 km) mileage. Beyond 48,000 miles (80,000 km), carry out the same services at the same intervals respectively.								
	Km (x 1,000)	10	20	30	40	50	60	70	80
	Miles (x 1,000)	6	12	18	24	30	36	42	48
	Months	6	12	18	24	30	36	42	48
<b>CHASSIS AND BODY</b>									
Power steering (P/S) system									

**NOTE:**

"|": Inspect and correct or replace if necessary

## MAINTENANCE SERVICE

### POWER STEERING (P/S) SYSTEM INSPECTION

- 1) Visually check power steering system for leaks or damage.
- 2) Remove oil tank cap and check fluid level indicated on level gauge, which should be between MAX and MIN marks. If it is lower than MIN, fill fluid up to MAX mark.


**NOTE:**

Fluid level should be checked when fluid is cool.

- 3) Make sure that power steering belt deflects 8 – 10 mm (0.31 – 0.39 in.) with 10 kg (22 lb) thumb pressure applied on the midway point between the pulleys.  
Also, visually check the belt for damage. If necessary, have the belt adjusted or replaced.

## RECOMMENDED FLUIDS AND LUBRICANTS

Power steering fluid	Automatic transmission fluid DEXRON-II
----------------------	--



**SECTION 1A****HEATER AND VENTILATION****NOTE:**

- For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.
- The blower motor installing position is different between the right-hand side steering car and the left-hand steering car. In either car, the motor is installed on assistant seat side. The illustration in this manuals shows the left hand steering car.

**CONTENTS**

<b>GENERAL DESCRIPTION</b> .....	1A-2	<b>ON-CAR SERVICE</b> .....	1A-4
Heater .....	1A-2	Heater Control Cables .....	1A-4
Heater Control Operation .....	1A-3	Heater Unit .....	1A-5

## GENERAL DESCRIPTION

### HEATER

The heater and ventilation of this car consist of following parts.




Fig. 1A-1

# HEATER CONTROL OPERATION

Heater control panel is as shown below.




Fig. 1A-2

## ON-CAR SERVICE

### HEATER CONTROL CABLES




Fig. 1A-3

#### REMOVAL

- 1) Remove console box.
- 2) Remove ashtray and ashtray upper plate.
- 3) Remove cigarette lighter.
- 4) Remove radio. (If equipped)
- 5) Remove control lever knobs and control panel garnish.
- 6) Remove control panel.
- 7) Disconnect lead wire from blower motor switch at coupler.
- 8) Disconnect control cables from blower motor unit and heater unit.
- 9) Remove control lever ass'y.
- 10) Disconnect control cables from control lever.




Fig. 1A-4

#### INSTALLATION

Install control cables by reversing removal procedure, noting the following point. After installing control cables to control levers, move control levers to such position as to pull cables fully, then connect and clamp control cables to heater unit and blower motor unit levers as shown.




Fig. 1A-5

#### NOTE:

After installing control cables, be sure that control knobs move smoothly and stop at proper position.

## HEATER UNIT

### REMOVAL

1. Disconnect battery (-) leadwire, drain coolant and disconnect 2 water hoses from heater unit.
2. Remove instrument panel as follows.
  - 1) Remove console box.
  - 2) Disconnect wires and cables from heater and blower unit.
  - 3) Remove steering wheel, steering column unit and steering joint upper bolt. (Refer to SECTION 3C.)
  - 4) Remove front speaker covers and front speakers (if equipped).
  - 5) Disconnect speedometer cable and remove speedometer ass'y.
  - 6) Remove engine hood opener.
  - 7) Remove instrument panel member mounting bolts.




Fig. 1A-6

- 8) Remove instrument panel together with instrument panel member.




Fig. 1A-7

3. Remove heater unit.




Fig. 1A-8

4. Remove heater unit clips and screws to separate heater unit.




Fig. 1A-9

5. Pull out heater core from unit.




Fig. 1A-10

### INSTALLATION

Install heater unit by reversing removal procedure, noting the following items.

- 1) Adjust control cables. (Refer to p. 1A-4)
- 2) Fill coolant to radiator.

### NOTE:

- When installing each part, be careful not to catch any cable or wiring harness.
- When installing steering shaft to steering shaft joint, set front wheels (right and left) in the straight ahead state and check to make sure that steering wheel is also in that state.
- When fastening steering column ass'y to car body, start with lower nuts on column and then upper nuts. Be sure to tighten them to specified torque. (Refer to SECTION 3C.)



**SECTION 2**

**BUMPERS AND SHEET METAL**

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

**BUMPERS** ..... 2-1

**BUMPERS**

**NOTE:**

Fasteners are important attaching parts in that they could affect the performance of vital components and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary.

Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of these parts.

## FRONT BUMPER




Fig. 2-1

### REMOVAL

- 1) Remove front fender lining.
- 2) Remove front turn signal lamps.
- 3) Remove bumper fitting bolts and nuts shown in Fig. 2-2.




Fig. 2-2

### INSTALLATION

- 1) Slide bumper onto bumper side attachments on both fenders.
- 2) Use five bolts and four nuts to fix bumper in position.

- 4) Slide bumper (with bumper member) forward to remove it.

## REAR BUMPER




Fig. 2-3

### REMOVAL

- 1) Remove rear garnish and then detach rear combination lights (R & L) from body without disconnecting coupler of combination rights.




Fig. 2-4

- 2) Disconnect coupler of licence plate light.




Fig. 2-5

- 3) Remove rear bumper bolts and nuts shown in figure below.

To remove nut "A", removal of back panel inner trim is prerequisite.




Fig. 2-6

- 4) Temporarily install rear combination lights in position with screws.
- 5) Slide bumper (with bumper member) backward to remove it.




Fig. 2-7

### INSTALLATION

- 1) Insert side sliders (R & L) of fenders and tighten bumper bolts and nuts.
- 2) Connect coupler of licence plate light securely.
- 3) Install combination lights (R & L) and then rear garnish.

**SECTION 3B1****POWER STEERING (P/S) SYSTEM****(If equipped)****NOTE:**

- All steering gear fasteners are important attaching parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during re-assembly to assure proper retention of these parts.
- For items related to the rack and pinion, if not included in this section, refer to **SECTION 3B MANUAL RACK AND PINION** of the Service Manual mentioned in the **FOREWORD** of this manual.

**CONTENTS**

<b>GENERAL DESCRIPTION</b> .....	3B1- 2
<b>CONSTRUCTION AND OPERATION</b> .....	3B1- 4
Steering Gear Box .....	3B1- 4
Power Steering (P/S) Pump .....	3B1- 8
<b>DIAGNOSIS</b> .....	3B1-10
<b>ON CAR SERVICE</b> .....	3B1-12
Inspection .....	3B1-12
Steering wheel play .....	3B1-12
Steering force .....	3B1-12
Power steering fluid level .....	3B1-13
Power steering belt tension .....	3B1-13
Power steering belt tension adjustment .....	3B1-13
Idle up system .....	3B1-13
Fluid leakage .....	3B1-14
Hydraulic pressure in P/S circuit .....	3B1-15
Steering rack boot .....	3B1-16
Tie rod end boot .....	3B1-17
Steering shaft joint .....	3B1-17
Air Breeding Procedure .....	3B1-17
Remove and Install Tie Rod End .....	3B1-17
Remove and Install Power Steering Gear Box .....	3B1-19
Remove and Install Power Steering Pump .....	3B1-26
<b>SPECIAL TOOLS</b> .....	3B1-32

## GENERAL DESCRIPTION

The power steering (P/S) system in this car reduces the driver's effort needed in turning the steering wheel by utilizing the hydraulic pressure generated by the power steering (P/S) pump which is driven by the engine.

It is an integral type with the rack and pinion gears and the control valve unit, hydraulic pressure cylinder unit all built in the steering gear box.

There are two types of this system: one for the RH steering model and the other for the LH steering model.

### For LH-steering model




Fig. 3B1-1-1 Power Steering System Layout




Fig. 3B1-1-2 Hydraulic Pressure Circuit

For RH-steering model




Fig. 3B1-2-1 Power Steering System Layout




Fig. 3B1-2-2 Hydraulic Pressure Circuit

## CONSTRUCTION AND OPERATION

### STEERING GEAR BOX

- For LH steering model

The steering gear box consists of two sections: one including a cylinder and the other a valve. Main components of the cylinder section are a gear box, a rack and a tube and those of the valve section are a valve case, a sleeve and a stub shaft. The sleeve is linked with the pinion through a pin and the valve and stub shaft are integrated into one unit. Then the pinion and the stub shaft are linked to each other by means of the torsion bar.

Thus, when the stub shaft moves, the valve changes its position, thereby switching the hydraulic passage from the pump to the cylinder to help steering operation.

When turning the steering wheel feels heavy due to P/S fluid leakage or for some other reason (i.e., when in the manual steering mode), the stub shaft and pinion are in direct linkage and the force is output directly through the pinion and rack.




Fig. 3B1-3-1 Steering Gear and Valve Unit



**WHEN STEERING WHEEL HELD AT STRAIGHT POSITION**

When the steering wheel is not turned, the valve is held at the neutral position by the torsion bar and the fluid from the pump flows through the valve back to the tank.




Fig. 3B1-4 Hydraulic Pressure Circuit When Steering Wheel at Straight

**WHEN STEERING WHEEL TURNED (to the right)**

Turning the steering wheel clockwise will cause the stub shaft to turn clockwise, twisting the torsion bar. Then the valve is switched to allow the fluid pressure to be applied to the cylinder which then pushes the rack.

As the rack moves, the pinion turns clockwise to actuate the torsion bar which then causes the valve to return to the neutral position. This is called the feed back operation of the power steering system.




Fig. 3B1-5 Operation When Steering Wheel Turned to the Right

• For RH steering model

The steering gear box contains a gear, valve and cylinder sections. The gear and valve section consist of a valve case, spool valve, lever, pinion and other parts. There are two bearings to support the pinion in the gear case whose section is an oblong hole so that the bearing and pinion shaft can move to the right and left. And as the pinion shaft moves, the spool valve moves in the same direction, for they are connected. Such valve movement opens and closes the hydraulic pressure passage from the pump to either right or left cylinder port to assist the steering operation.




Fig. 3B1-3-2 Steering Gear and Valve Unit

**WHEN STEERING WHEEL HELD AT STRAIGHT POSITION**

When the steering wheel is not turned in either way, the spool valve is kept at its neutral position by the spring force and the hydraulic pressure from the pump passes through the short circuit.




Fig. 3B1-4 Hydraulic Pressure Circuit When Steering Wheel at Straight Position

**WHEN STEERING WHEEL TURNED (to the right)**

Turning the steering wheel to the right causes the pinion shaft to move to the right by the amount equal to the play in the oblong hole provided in the periphery of the bearing. At the same time, the spool valve moves to the right through the lever, allowing hydraulic pressure to flow into the cylinder and push the rack shaft. When the force in the rotation direction of the pinion is released, the spool valve is returned to its neutral position by the reaction of the spring, thus shutting off the hydraulic pressure to the cylinder.




Fig. 3B1-5 Operation When Steering Wheel Turned to the Right

## POWER STEERING (P/S) PUMP

The power steering pump is a vane type and is driven by the V-ribbed belt from the crankshaft.




Fig. 3B1-6 Components of P/S Pump

Model		Vane type
Discharge rate		5.1 cm <sup>3</sup> /rev
Hydraulic pressure control	Hydraulic pressure	4900 kPa 50 kg/cm <sup>2</sup> 711 psi
	Control device	Flow control valve Relief valve
Specified fluid		DEXRON-II A/T fluid
Capacity		600 – 650 cm <sup>3</sup> (1.27/1.06 – 1.37/1.14 US/Imp. pt)
Idle-up system		Idle-up function performed when hydraulic pressure in P/S pump rises higher than following value. 1470 – 1960 kPa 15 – 20 kg/cm <sup>2</sup> 213 – 284 psi




Fig. 3B1-7 P/S Pump Layout (Vehicle with A/C)

### FLOW CONTROL VALVE

As the discharge rate of the P/S pump increases in proportion to the pump revolution speed, a flow control valve is added to control it so that the optimum amount of fluid for steering operation is supplied according to the engine speed (driving condition).

Described below is its operation at different engine speed.

#### When Idling

The fluid discharged from the pump is supplied through the clearance around the rod in orifice A<sub>1</sub> to the gear box.




Fig. 3B1-8 Operation of Flow Control Valve (When Idling)

#### When Running at Low Speed

As the engine speed rises, the pump discharge rate increases and causes a pressure difference to occur between both ends of the orifice ( $P_1 - P_2$ ). Thus the pressure exceeding the flow control spring force pushes the flow control valve to the right in the below figure, making the opening in the orifice narrower through which only a necessary amount of fluid is fed to the gear box and the excess fluid is returned to the pump.




Fig. 3B1-9 Operation of Flow Control Valve (When Running at Low Speed)

#### When Running at High Speed

As the engine speed rises higher, opening in the orifice is made narrower and fluid flow to the gear box reduces. As a result, hydraulic pressure application is slow at the start of the steering wheel turn. This provides straight-ahead stability to suit the driving condition with the steering wheel operated near its neutral position.




Fig. 3B1-10 Operation of Flow Control Valve (When Running at High Speed)

### RELIEF VALVE

The relief valve located in the flow control valve controls the maximum hydraulic pressure.

The steel ball in the relief valve is under the hydraulic pressure in the circuit coming through orifice A<sub>2</sub>. When the steering wheel is turned and the hydraulic pressure increases higher than 4900 kPa (50 kg/cm<sup>2</sup>, 711 psi), it compresses the relief spring to push the steel ball which then allows the fluid to flow to the P/S pump.

Such relief valve operation causes a pressure difference to occur between chambers A and B. Then the flow control valve moves to the right to make opening in orifice A<sub>1</sub> narrower, maintaining the hydraulic pressure constant.




Fig. 3B1-11 Operation of Relief Valve

## DIAGNOSIS

Condition	Possible Cause	Correction
<b>Steering wheel feels heavy (at low speed)</b>	<ol style="list-style-type: none"> <li>1. Fluid deteriorated, low viscosity, different type of fluid mixed</li> <li>2. Pipes or hoses deformed, air entering through joint</li> <li>3. Insufficient air purging from P/S circuit</li> <li>4. P/S belt worn, lacking in tension</li> <li>5. Tire inflation pressure excessively low</li> <li>6. Front end alignment maladjusted</li> <li>7. Steering wheel installed improperly (twisted)</li> <li>8. Bind in tie rod or tie rod end ball joint</li> <li>9. P/S pump hydraulic pressure fails to increase</li> <li>10. P/S pump hydraulic pressure increases but slowly</li> </ol> <p><b>NOTE:</b> Make sure to warm up engine fully before measuring hydraulic pressure from pump.</p>	<p>Replace fluid.</p> <p>Replace defective part.</p> <p>Purge air.</p> <p>Adjust belt tension or replace belt as necessary.</p> <p>Inflate tire.</p> <p>Check and adjust front end alignment.</p> <p>Install steering wheel correctly.</p> <p>Replace defective part.</p> <p>Replace P/S pump.</p> <p>Replace P/S pump.</p>
<b>Steering wheel feels heavy momentarily when turning it to the left (right)</b>	<ol style="list-style-type: none"> <li>1. Air drawn in due to insufficient amount of fluid</li> <li>2. Slipping P/S belt</li> <li>3. Refer to check items 9 and 10 in above section</li> </ol>	<p>Add fluid and purge air.</p> <p>Adjust belt tension or replace belt as necessary.</p>
<b>No idle-up</b>	<ol style="list-style-type: none"> <li>1. P/S pump pressure switch defective</li> </ol>	<p>Replace P/S pump pressure switch.</p>
<b>Poor recovery from turns</b>	<p><b>NOTE:</b> To check steering wheel for recovery, with car running at 22 mile/h (35 km/h), turn it 90° and let it free. It should return more than 60°.</p> <ol style="list-style-type: none"> <li>1. Deformed pipes or hoses</li> <li>2. Steering column installed improperly</li> <li>3. Front end alignment maladjusted</li> <li>4. Ball joints binding</li> <li>5. Refer to items 9 and 10 in above section</li> </ol>	<p>Replace defective part.</p> <p>Install steering column correctly.</p> <p>Check and adjust front end alignment.</p> <p>Replace defective part.</p>

Condition	Possible Cause	Correction
<b>Vehicle pulls to one side during straight driving</b>	<ol style="list-style-type: none"> <li>1. Low or uneven tire inflation pressure</li> <li>2. Front end alignment maladjusted</li> <li>3. Malfunction of control valve in gear box</li> <li>4. Refer to check items 9 and 10 in previous page</li> </ol>	<p>Inflate tires to proper pressure or adjust right &amp; left tires inflation pressure.</p> <p>Check and adjust front end alignment.</p> <p>Replace gear box.</p>
<b>Steering wheel play is large and vehicle wanders</b>	<ol style="list-style-type: none"> <li>1. Loose steering shaft nut</li> <li>2. Loose linkage or joints</li> <li>3. Loose gear box fastening bolt</li> <li>4. Front wheel bearing worn</li> </ol>	<p>Retighten.</p> <p>Retighten.</p> <p>Retighten.</p> <p>Replace wheel bearing.</p>
<b>Oil leakage</b>	<ol style="list-style-type: none"> <li>1. Loose joints of (hydraulic pressure) pipes and hoses</li> <li>2. Deformed or damaged pipes or hoses</li> </ol>	<p>Retighten.</p> <p>Replace defective part.</p>
<b>Abnormal noise</b>	<p><b>NOTE: (For RH steering model)</b>  <b>Some sound may be heard through steering column when turning steering wheel with vehicle at a stop but it is not an abnormal noise but operating sound of valve in gear box.</b></p> <ol style="list-style-type: none"> <li>1. Air drawn in due to insufficient amount of fluid</li> <li>2. Air mixed into fluid from pipes or hoses</li> <li>3. Slipping (loose) P/S belt</li> <li>4. Worn P/S belt</li> <li>5. Loose gear box fastening bolt</li> <li>6. Loose pitman arm nut</li> <li>7. Loose linkage or joints</li> <li>8. Pipes or hoses in contact with part of vehicle body</li> <li>9. Vanes of P/S pump defective</li> <li>10. Malfunction of control valve in gear box</li> <li>11. Bearing of P/S pump shaft defective</li> </ol>	<p>Add fluid and purge air.</p> <p>Replace pipes or hoses.</p> <p>Adjust belt tension.</p> <p>Replace belt.</p> <p>Retighten bolts.</p> <p>Retighten nut.</p> <p>Retighten.</p> <p>Install pipes and hoses correctly.</p> <p>Replace pump.</p> <p>Replace gear box.</p> <p>Replace pump.</p>

## ON CAR SERVICE

### INSPECTION

#### STEERING WHEEL PLAY

- With engine stopped, check steering wheel play as follows. Move steering wheel from its straight-ahead position lightly in both directions and measure distance along its circumference it must be turned before wheels start to move. It should be within below specification.

Steering wheel play	Less than 30 mm (1.2 in.)
---------------------	------------------------------

- Check steering wheel for looseness or rattle by trying to move it in its shaft direction and lateral direction.




Fig. 3B1-12 Steering Wheel Play

#### STEERING FORCE

- 1) Place vehicle on level road and set steering wheel at straight-ahead position.
- 2) Check that tire inflation pressure is as specified. (Refer to tire placard).
- 3) Start engine and keep it running till power steering fluid is warmed to 50 to 60°C (122 to 140°F).




Fig. 3B1-13 Checking Fluid Temperature

- 4) With engine idling, measure steering force by pulling spring balancer hooked on steering wheel in tangential direction.

Steering force	Less than 4.0 kg (8.8 lb)
----------------	------------------------------




Fig. 3B1-14 Checking Steering Force



### POWER STEERING FLUID LEVEL

With engine stopped, remove oil tank cap and check fluid level indicated on level gauge, which should be between MAX and MIN marks. If it is lower than MIN, fill fluid up to MAX mark.

**NOTE:**

- Be sure to use A/T fluid DEXRON-II.
- Fluid level should be checked when fluid is cool.




Fig. 3B1-15 Checking P/S Fluid Level

### POWER STEERING BELT TENSION

- Check that belt is free from any damage and properly fitted in pulley groove.
- Check belt tension by measuring how much it deflects when pushed at intermediate point between P/S pump pulley and crank pulley with about 10 kg (22 lb) force.

Deflection of P/S belt (A)	8 – 10 mm (0.31 – 0.39 in.)
----------------------------	--------------------------------




Fig. 3B1-16 Checking P/S Belt Tension

### POWER STEERING BELT TENSION ADJUSTMENT

1. Remove splash cover and loosen tension nut.
2. Adjust belt tension. With A/C equipped vehicles, turning tension bolt counterclockwise causes pulley to rise, increasing belt tension. With A/C non-equipped vehicles, turning tension bolt clockwise causes pulley to lower, increasing belt tension. In both cases, turning tension bolt in the other way decreases belt tension.

Be sure to tighten tension nut after adjusting belt tension.




Fig. 3B1-17 Adjusting P/S Belt Tension

### IDLE UP SYSTEM


With air conditioner turned OFF (if equipped, turn steering wheel and check that engine idling speed is not slowed down even when load is imposed on engine by P/S pump.

### FLUID LEAKAGE


Start engine and turn steering wheel fully to the right and left so that maximum hydraulic pressure is provided. Then visually check gear box, P/S pump and oil tank themselves and each joint of their connecting pipes for leakage.

**CAUTION: Never keep steering wheel turned fully for longer than 10 seconds.**

For LH steering model



For RH steering model



- 1. Steering gear box
- 2. P/S pump
- 3. Oil tank

Fig. 3B1-18 Check for Fluid Leakage

**HYDRAULIC PRESSURE IN P/S CIRCUIT**

1. After cleaning joint of high pressure hose and oil pump thoroughly, disconnect it and install oil pressure gauge, oil pressure gauge attachment and hose (Spare part).

**CAUTION:**

Take care not to cause damage to air conditioner condenser during service operation.




Fig. 3B1-19 Setting Oil Pressure Gauge

2. Bleed air. (Refer to AIR BLEEDING PROCEDURE.)
3. With engine idling, turn steering wheel and warm up engine till temperature of fluid in tank rises to 50 – 60°C (122 – 140°F).




Fig. 3B1-20 Checking Fluid Temperature

**4. Back pressure check**

Check back pressure by measuring hydraulic pressure with engine idling and hands off steering wheel.

Back pressure	Lower than 980 kPa (10 kg/cm <sup>2</sup> , 142 psi)
---------------	--

When back pressure is higher than 980 kPa (10 kg/cm<sup>2</sup>, 142 psi), check control valve and piping for clogging.




Fig. 3B1-21 Checking Back Pressure

5. Relief pressure check

- Increase engine speed to about 1,500 r/min (rpm). Close gauge valve gradually while watching pressure increase indicated by gauge and take reading of relief pressure (maximum hydraulic pressure).

Relief pressure	4400 – 6400 kPa (45 – 65 kg/cm <sup>2</sup> ) (640 – 924 psi)
-----------------	---

- When it is higher than 6400 kPa (65 kg/cm<sup>2</sup>, 924 psi), possible cause is malfunction of relief valve. Replace steering gear box comp.
- When it is lower than 4400 kPa (45 kg/cm<sup>2</sup>, 640 psi), possible cause is either failure of P/S pump or settling of relief valve spring.

**CAUTION:**  
Be sure not to close gauge valve for longer than 10 seconds.




Fig. 3B1-22 Relief Pressure Check

Next, open gauge valve fully and increase engine speed to about 1,500 r/min. Then turn steering wheel to the left or right fully and take reading of relief pressure.

Relief pressure	4400 – 6400 kPa (45 – 65 kg/cm <sup>2</sup> ) (640 – 924 psi)
-----------------	---

- When it is lower than 4400 kPa (45 kg/cm<sup>2</sup>, 640 psi), possible cause is failure in steering gear box. Replace gear box.

**CAUTION:**  
Be sure not to hold steering wheel at fully turned position for longer than 10 seconds.




Fig. 3B1-23 Relief Pressure Check

**STEERING RACK BOOT**

Check boot for crack and damage which, if any, means possibility of rusty gear, entry of dust or lack of grease. Also, check if any of such faulty conditions exists.




Fig. 3B1-24

**TIE ROD END BOOT**

Check boot for crack and damage and if any, replace it with a new one.




Fig. 3B1-25

**STEERING SHAFT JOINT**

Check each shaft joint for wear, breakage and any other damage and if any, replace it with a new one.




Fig. 3B1-26

**AIR BLEEDING PROCEDURE**

1. Jack up the front end of car and apply rigid rack.
2. Fill oil tank with fluid up to specified level. Then turn steering wheel to the right and left for 3 or 4 times.
3. After running engine at idling speed for 3 to 5 seconds, stop it and add fluid to satisfy specification.
4. With engine stopped, turn steering wheel to the right and left as far as it stops, repeat it a few times and fill fluid to specified level.

5. With engine running at idling speed, repeat stop-to-stop turn of steering wheel till all foams in oil tank are gone.

**NOTE:**

Make sure to bleed air completely. If air remains in fluid, P/S pump may make humming noise or steering wheel may feel heavy.

6. Finally check to make sure that fluid is filled to specified level.

**REMOVE AND INSTALL TIE ROD END****REMOVAL**

1. Jack up vehicle and remove wheel.
2. Remove split pin and tie rod end castle nut.




Fig. 3B1-27 Tie Rod End

3. Using special tool, remove tie rod end from knuckle.




Fig. 3B1-28 Removing Tie Rod End

4. To facilitate adjustment after installation, put a mark on tie rod thread indicating position of tie rod end lock nut. Then loosen lock nut and remove tie rod end from tie rod.




Fig. 3B1-29

**INSPECTION**

**Tie-rod End Ball Joint**

Inspect for play in tie-rod end ball joint. If found defective, replace.




Fig. 3B1-30 Inspection of Ball Joint

**INSTALLATION**




Fig. 3B1-31

1. Install tie rod end lock nut and tie rod end to tie rod. Tighten lock nut to mark on tie rod thread.

2. Install tie rod end to knuckle. Tighten castle nut till holes for split pin are aligned but within specified torque range.

Tightening torque	N·m	kg·m	lb·ft
	30 - 55	3.0 - 5.5	22.0 - 39.5

3. Bend split pin as shown in figure.




Fig. 3B1-32 Tightening Castle Nut

4. Check that proper amount of toe-in is obtained. (Refer to FRONT WHEEL ALIGNMENT.)

5. After confirming proper amount of toe-in, tighten tie rod end lock nut to specified torque.

Tightening torque	N·m	kg·m	lb·ft
	35 - 55	3.5 - 5.5	25.5 - 39.5




Fig. 3B1-33 Tightening Lock Nut

6. After installing wheels, lower car and tighten wheel nuts to specified torque.

# REMOVE AND INSTALL POWER STEERING GEAR BOX

## POWER STEERING GEAR BOX COMPONENTS

For LH steering model




Fig. 3B1-34 Exploded View of Power Steering Gear Box

## STEERING GEAR BOX

### Removal

1. Loosen steering shaft upper joint bolt (but it must not be removed).
2. Remove lower joint bolt and separate pinion and lower joint.




Fig. 3B1-35 Removing Joint Bolt

3. Jack up vehicle and remove both right and left wheels.
4. Remove split pin and then remove tie rod castle nut from steering knuckle.




Fig. 3B1-36

5. Using special tool, remove tie rod end from knuckle.




Fig. 3B1-37 Removing Tie Rod End

6. Remove exhaust pipe.
7. Disconnect both gear shift control shaft and extension rod at their transmission side.
8. Remove all pipes from steering gear box.




Fig. 3B1-38 Removing Pipes

9. Remove steering gear box mounting bolts and then remove steering gear box from car.



**Installation**

Reverse removal procedure for installation of steering gear box.

	Tightening torque		
	N-m	kg-m	lb-ft
Gear box mounting bolt	20 – 30	2.0 – 3.0	14.5 – 21.5

For specific tightening torque for each part, refer to respective section as indicated in below table.

<ul style="list-style-type: none"> <li>● Rear torque rod bolt</li> <li>● Rear torque rod bracket bolts</li> </ul>	SECTION 6A
<ul style="list-style-type: none"> <li>● Gear shift control shaft bolt/nut</li> <li>● Extension rod nut</li> </ul>	SECTION 7A
<ul style="list-style-type: none"> <li>● Exhaust pipe bolts and nuts</li> </ul>	SECTION 6K
<ul style="list-style-type: none"> <li>● Castle nut</li> <li>● Steering shaft lower joint bolts</li> </ul>	SECTION 3B

- Tighten flare nuts to specified torque.

	N-m	kg-m	lb-ft
"A"	40 – 50	4.0 – 5.0	29.0 – 36.0
"B"	30 – 40	3.0 – 4.0	22.0 – 28.5
"C"	20 – 30	2.0 – 3.0	14.5 – 21.5




Fig. 3B1-38-1

**NOTE:**

After installation, be sure to fill A/T fluid (DEXRON-II) and bleed air.

**OIL SEAL**

**Removal**

1. Remove gear box from car.  
Refer to item STEERING GEAR BOX.
2. As shown below, move boot so that joint section of tie rod and steering rack is exposed.




Fig. 3B1-39

3. Remove tie rod with tie rod end from gear box as shown below.




Fig. 3B1-40

4. Using special tool, remove box.




Fig. 3B1-41

5. Remove O-ring and/or U-packing.

### Installation

Reverse removal procedure to install oil seals noting following points.

- Apply SUZUKI SUPER GREASE E to O-ring and U-packing of box and install them into groove in box.





Fig. 3B1-42

- Tighten box and tie rod to specified torque.

Tightening torque	N·m	kg-m	lb-ft
for box	40 – 50	4.0 – 5.0	29.0 – 36.0
Tightening torque for tie rod	60 – 80	6.0 – 8.0	43.5 – 57.5

- Make sure to use new tie rod lock washer and caulk it after installation.

For RH steering model



1. Right steering gear
2. Steering pinion-side mount
3. Steering rack-side mount
4. U-packing
5. O-ring
6. Oil seal
7. Pipe ass'y A
8. Pipe ass'y B
9. Ferrule
10. Power steering cover
11. Steering gear case packing
12. Pinion side bracket
13. Rack side bracket
14. Steering boot
15. Rack boot wire
16. Rack boot clip
17. Tie rod end
18. Boot set
19. Clip
20. Steering tie rod
21. Tie rod lock washer

**NOTE:**  
Component enclosed in broken line cannot be disassembled.

Fig. 3B1-34 Exploded View of Power Steering Gear Box

### STEERING GEAR BOX

#### Removal

1. Loosen steering shaft upper joint bolt (but it must not be removed).
2. Remove lower joint bolt and separate pinion and lower joint.




Fig. 3B1-35 Removing Joint Bolt

3. Jack up vehicle and remove both right and left wheels.
4. Remove split pin and then remove tie rod castle nut from steering knuckle.




Fig. 3B1-36

5. Using special tool, remove tie rod end from knuckle.




Fig. 3B1-37 Removing Tie Rod End

6. Remove high pressure pipe and low pressure pipe from steering gear box.




Fig. 3B1-38 Removing Pressure Pipe

7. Remove steering gear box mounting bolts and then remove steering gear box from vehicle.

#### Installation

Reverse removal procedure for installation of steering gear box.

	Tightening torque		
	N-m	kg-m	lb-ft
Gear box mounting bolt	20 - 30	2.0 - 3.0	14.5 - 21.7
Castle nut	30 - 55	3.0 - 5.5	21.7 - 39.8
Joint bolt	20 - 30	2.0 - 3.0	14.5 - 21.7

#### NOTE:

After installation, be sure to fill A/T fluid (DEXRON-II) and bleed air.

## OIL SEAL

### Removal

1. Remove gear box, tie rod end and tie rod.
2. Using special tool, remove box.




Fig. 3B1-39 Removing Box

3. Remove oil seal by using screwdriver or the like.




Fig. 3B1-40 Removing Oil Seal

### NOTE:

Use care not to damage pinion shaft with screwdriver.

### Installation

Reverse removal procedure, noting the following.

- Apply SUZUKI SUPER GREASE E to inside and outside of oil seal lip and press-fit it till its upper surface becomes flush with end face of steering gear case.

### NOTE:

- Cover serrated part of pinion shaft with vinyl tape or the like so as to prevent damage to oil seal lip.
- Use care not to allow oil seal lip to turn over.




Fig. 3B1-41 Press-fitting Oil Seal

- Apply SUZUKI SUPER GREASE E to O-ring and U-packing of box and install them into groove in box.





Fig. 3B1-42 Installing U-packing

## REMOVE AND INSTALL POWER STEERING PUMP

Components (For LH steering model)



- |   |                                   |
|---|-----------------------------------|
| 1. Power steering pump assembly             | 11. Belt tension pulley bolt      |
| 2. Pulley set                               | 12. Belt tension bolt             |
| 3. Connector set                            | 13. Power steering belt           |
| 4. Terminal set (Including pressure switch) | 14. High pressure pipe            |
| 5. Seal set                                 | 15. Low pressure pipe             |
| 6. Power steering bracket                   | 16. Low pressure hose No. 1 clamp |
| 7. Pump bracket                             | 17. High pressure hose            |
| 8. Power steering oil tank                  | 18. Low pressure hose No. 1       |
| 9. Low pressure hose No. 2 clamp            | 19. Low pressure hose No. 2       |
| 10. Belt tension pulley                     |                                   |

Fig. 3B1-43 P/S Pump Components



### Removal

1. Remove splash cover, loosen belt tension pulley and remove P/S V-ribbed belt.
2. Disconnect high pressure hose and low pressure hose.
3. Disconnect pressure switch lead harness.
4. Remove compressor and bracket.  
Compressor needs not be removed with A/C equipped vehicle.
5. Remove oil pump together with its bracket (and 3 fixing bolts).

### NOTE:

- Be sure to clean each joint of suction and discharge sides thoroughly before removal.
- Plug each port of removed pump to prevent dust or any other foreign matter from entering.

### Installation

Reverse removal procedure.

### NOTE:

Fill A/T fluid (DEXRON-II) after installation and bleed air without failure.

### Disassembly

1. Using special tool, remove oil pump pulley.




Fig. 3B1-44 Removing Oil Pump Pulley

2. Remove suction connector by removing its fixing bolts (M6, 2 pcs).
3. Remove terminal assembly and discharge connector.




Fig. 3B1-45 Removing Terminal Assembly and Discharge Connector

4. Remove oil pump cover by removing its fixing bolts (M8, 4 pcs).




Fig. 3B1-46 Removing Oil Pump Cover



5. Remove cam ring.




Fig. 3B1-47 Removing Cam Ring

6. Remove snap ring and pull out rotor.

**NOTE:**

When pulling rotor out of shaft, be careful not to lose vane.




Fig. 3B1-48 Removing Rotor

7. Pull out shaft.

8. Remove oil seal.




Fig. 3B1-49 Removing Oil Seal

**Assembly**

Reverse disassembly procedure for assembly, noting the following.

1. Apply DEXRON-II to shaft where bushing slides against and insert shaft from oil seal side.




Fig. 3B1-50 Installing Shaft

2. Install rotor to shaft facing its splined part chamfered side up (to cover).




Fig. 3B1-51 Installing Rotor

3. Apply DEXRON-II to each vane and install it to rotor with its R part faced outward as shown below.




Fig. 3B1-52 Installing Vane

4. Apply DEXRON-II to O-ring and install it to pump body securely.  
5. Install cam ring.




Fig. 3B1-53 Installing Cam Ring

6. Install snap ring to shaft.  
7. Tighten cover bolts to specified torque.

Tightening torque for cover bolts	N-m	kg-m	lb-ft
	18 - 22	1.8 - 2.2	13.5 - 15.5

**NOTE:**

After installing cover, check to make sure that shaft can be turned by hand.




Fig. 3B1-54 Installing Cover

8. Check that flow control valve slides smoothly and tighten discharge (delivery) connector to specified torque.

Tightening torque for discharge connector	N-m	kg-m	lb-ft
	40 - 60	4.0 - 6.0	29.0 - 43.0




Fig. 3B1-55 Installing Flow Control Valve

9. Tighten terminal ass'y (pressure switch) to specified torque.

Tightening torque for terminal ass'y	N·m	kg-m	lb-ft
	25 - 30	2.5 - 3.0	18.5 - 21.5




Fig. 3B1-56 Installing Terminal

10. Tighten suction connector bolts to specified torque.

Tightening torque for suction connector bolts	N·m	kg-m	lb-ft
	6 - 10	0.6 - 1.0	4.5 - 7.0




Fig. 3B1-57 Installing Suction Connector

### INSPECTION

#### P/S Pump Body and Shaft

- Wear and damage of pump body sliding surface.
  - Stepped wear and damage of shaft where bushing slides against.
- Replace P/S pump if any of the above is found.




Fig. 3B1-58 Inspecting Pump Body and Shaft

#### Cam Ring

Inspect vane sliding surface of cam ring for wear and damage. Replace P/S pump if either of the above is found.




Fig. 3B1-59 Inspecting Cam Ring

**Rotor and Vane**

- Wear and damage of rotor sliding surface against pump body.
- Wear and damage of vane sliding surface against cam ring.
- Vane to rotor clearance.

Standard	0.01 mm (0.0004 in.)
Limit	0.06 mm (0.0023 in.)

Replace P/S pump if any of the above is found.




Fig. 3B1-60 Inspecting Rotor and Vane

**Flow Control Valve**

- Wear and damage on outside of valve.
- Obstruction in connector orifice.
- Free length of flow control spring.

Standard	36.5 mm (1.43 in.)
Limit	33.5 mm (1.32 in.)

Replace P/S pump if any of the above is found.




Fig. 3B1-61 Inspecting Flow Control Spring

**SPECIAL TOOLS**





 <p>09915-77410 Oil pressure gauge</p>	 <p>09913-65210 Tie-rod end remover</p>	 <p>09917-23610 Ring nut wrench</p>	 <p>09930-40113 Transfer flange lock holder</p>
---	--	---	--

Fig. 3B1-62

**SECTION 3C**

**STEERING WHEEL AND COLUMN**

**NOTE:**

- All steering wheel and column fasteners are important parts in that they could affect the performance of vital parts and systems, and/or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- For the descriptions (items) not found in this section of this manual, refer to the same section of Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

**DIAGNOSIS** ..... 3-1

**GENERAL DESCRIPTION** ..... 3C-2

**ON CAR SERVICE** ..... 3C-2

Remove and Install Steering Wheel ..... 3C-2

Checking Steering Column for Accident Damage ..... 3C-4

**SPECIAL TOOLS** ..... 3C-4

# GENERAL DESCRIPTION

The steering wheel and column consist of following parts.




Fig. 3C-1 Steering Wheel and Column

## ON CAR SERVICE

### REMOVE AND INSTALL STEERING WHEEL

#### REMOVAL

- 1) Disconnect negative battery cable.
- 2) Remove steering wheel pad by turning it counterclockwise while pressing it till it stops and disconnect horn wire.




Fig. 3C-2

- 3) Pull off pad seat from steering wheel.
- 4) Remove steering shaft nut.
- 5) Make alignment marks on steering wheel and shaft for a guide during reinstallation.




Fig. 3C-3

- 6) Remove steering wheel with special tool (A).




Fig. 3C-4

### INSTALLATION

- 1) Assemble steering wheel pad and pad seat as shown below.

#### NOTE:

For their correct assembly, use special care for relation in position between contact point of horn switch on steering wheel pad and boss on pad seat.




Fig. 3C-5

- 2) Install steering wheel onto shaft, aligning alignment marks on them.
- 3) Torque steering shaft nut to specification as given below.
- 4) Connect horn wire to steering wheel pad and then, install pad with seat to steering wheel.

#### NOTE:

Boss "A" on pad seat should go into hole "B" in steering wheel.




Fig. 3C-6

## CHECKING STEERING COLUMN FOR ACCIDENT DAMAGE

### NOTE:

Cars involved in accidents resulting in body damage or where the steering column has been impacted may also have a damaged or misaligned steering column.

### CHECKING PROCEDURE

Take measurement "A" as shown. If it is shorter than specified length, replace column assembly with new one.

### NOTE:

Specified length "A" varies depending on vehicle specifications. Measure measurement "B" first and by using that data, check specified length "A" applicable to specifications and then take measurement "A".




Fig. 3C-5

### NOTE:

For any checking procedure other than the above, consult the Service Manual mentioned in the FOREWORD of this manual.

## SPECIAL TOOL




Fig. 3C-6



## SECTION 5

# BRAKES

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## CONTENTS

<b>BRAKE HOSE/PIPE R &amp; I</b> .....	5-2
1. Remove and Install Front Brake Hose/Pipe .....	5-2

# BRAKE HOSE/PIPE R & I

## 1. REMOVE AND INSTALL FRONT BRAKE HOSE/PIPE

1) Raise and suitably support car. Remove tire and wheel.

This operation is not necessary when removing pipes connecting master cylinder and P valve.

2) Clean dirt and foreign material from both hose end or pipe end fittings. Remove brake hose or pipe.

3) Reverse brake hose installation procedure.

For installation, make sure that steering wheel is in straightforward position and hose has no twist or kink. Check to make sure that hose doesn't contact any part of suspension, both in extreme right and extreme left turn conditions. If it does at any point, remove and correct. Fill and maintain brake fluid level in reservoir. Bleed brake system.




Fig. 5-1 Front Brake Hose/Pipe R & I

# SECTION 6A

## ENGINE MECHANICAL

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

### CONTENTS

<b>ON CAR SERVICE</b> .....	6A-1
Oil Pressure Check .....	6A-1
Crankshaft Pulley .....	6A-1
Flywheel .....	6A-1
Camshaft Timing Belt Pulley .....	6A-2
Valves and Valve Guides .....	6A-2
Engine Mounting .....	6A-2
<b>SPECIAL TOOL</b> .....	6A-3

## ON CAR SERVICE

### OIL PRESSURE CHECK

Check engine oil pressure according to the same procedure as that in the Service Manual mentioned in the FOREWORD of this manual.

Oil pressure specification	3.8 – 4.8 kg/cm <sup>2</sup> 54.1 – 68.2 psi at 4,000 r/min.
----------------------------	--

### CRANKSHAFT PULLEY

Following bolts are used for crankshaft pulley. Tighten them to specified torque below.

Tightening torque for pulley bolts	N·m 14 – 18	kg·m 1.4 – 1.8	lb·ft 10.5 – 13.0
------------------------------------	----------------	-------------------	----------------------




Fig. 6A-1 Crankshaft Pulley Bolt

### FLYWHEEL

Following bolts are used for flywheel. Tighten them to specified torque.

Tightening torque for flywheel	N·m 68 – 72	kg·m 6.8 – 7.2	lb·ft 49.5 – 52.0
--------------------------------	----------------	-------------------	----------------------




Fig. 6A-1-1 Flywheel

### CAMSHAFT TIMING BELT PULLEY

When loosening or tightening pulley bolt, lock camshaft pulley with special tool.




Fig. 6A-2 Loosening Pulley Bolt

### VALVES AND VALVE GUIDES

Check stem-to-guide clearance according to the same procedure as that in the Service Manual mentioned in the FOREWORD of this manual.

Item		Standard	Limit
Valve stem diameter	In	5.465 – 5.480 mm (0.2152 – 0.2157 in.)	—
	Ex	5.440 – 5.455 mm (0.2142 – 0.2148 in.)	—
Valve guide I.D.	In & Ex	5.500 – 5.512 mm (0.2165 – 0.2170 in.)	—
Stem-to-guide clearance	In	0.020 – 0.047 mm (0.0008 – 0.0018 in.)	0.07 mm (0.0027 in.)
	Ex	0.045 – 0.072 mm (0.0018 – 0.0028 in.)	0.09 mm (0.0035 in.)




Fig. 6A-3 Measuring Valve Stem Dia. and Valve Guide I.D.

### ENGINE MOUNTING

Right mounting with damper is used for this model.

When removing or installing, refer to following figure.





Fig. 6A-4 Engine Mounting

## SPECIAL TOOL

Following special tool is used to lock camshaft pulley.





## SECTION 6E

# ELECTRONIC FUEL INJECTION SYSTEM

### NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## CONTENTS

GENERAL DESCRIPTION .....	6E- 1
FUEL DELIVERY SYSTEM .....	6E- 4
Fuel Injector .....	6E- 4
ELECTRONIC CONTROL SYSTEM .....	6E- 5
Diagnosis Switch Terminal .....	6E- 8
Test Switch Terminal .....	6E- 8
DIAGNOSIS .....	6E- 9
DIAGNOSTIC FLOW CHART .....	6E- 9
Inspection of ECM and Its Circuit .....	6E- 9
Voltage check .....	6E- 9
ON CAR SERVICE .....	6E-13
Idle Speed/ISC Duty Adjustment .....	6E-13
ELECTRONIC CONTROL SYSTEM .....	6E-15
Speed Sensor (Inspection) .....	6E-15

## GENERAL DESCRIPTION

The Electronic Fuel Injection System in this car supplies the combustion chambers with air/fuel mixture of optimized ratio under widely varying driving conditions.

It uses the multi-point fuel injection system which injects fuel into each intake port of the cylinder head.

This system has 3 major sub-systems: air intake system, fuel delivery system and electronic control system.

Air intake system includes air cleaner, air flow meter, throttle body, air valve, ISC solenoid valve and intake manifold.

Fuel delivery system includes fuel pump, delivery pipe (fuel pressure regulator), etc.

Electronic control system includes ECM, various sensors and controlled devices.

This section explains the system related to the electronic fuel injection as well as such functions of ECM as listed below.

- EGR control system equipped in only California spec. model.
- Evaporative emission control system.
- ESA (Electronic Spark Advance) system.




Fig. 6E-1 Electronic Fuel Injection System



1. Fuel tank
2. Fuel pump
3. Fuel filter
4. Fuel pressure regulator
5. 2-way check valve
6. Charcoal canister (if equipped)
7. Canister purge VSV (if equipped)
8. ISC solenoid valve
9. Power steering VSV (if equipped)
- 9-1. Electric load signal
  - Radiator fan
  - Heater blower
  - Rear window defogger
  - Stop light
  - Headlight or small light
- 9-2. Power steering pressure switch (if equipped)
10. Diagnosis switch terminal

11. Test switch terminal
  12. ECM
  13. "CHECK ENGINE" light
  14. Main switch
  15. Main fuse
  16. Battery
  17. CAS (in distributor)
  18. Ignition coil
  19. Power unit
  20. Speed sensor (in speedometer)
  21. EGR VSV
  22. EGR modulator
  23. EGR valve
  24. REGTS
  25. Air valve
  26. Intake manifold
  27. PCV valve
  28. Idle speed adjusting screw
- } California spec.  
model only

29. Throttle body
30. TPS
31. Fuel injector
32. WTS
33. Exhaust manifold
34. Oxygen sensor (if equipped)
35. AFM
- 35-1. AFS
36. Air cleaner

## FUEL DELIVERY SYSTEM

### FUEL INJECTOR

There are 4 injectors (one for each cylinder), each of which is installed between the cylinder head and delivery pipe. It is an electromagnetic type injection nozzle which injects fuel into the intake port of the cylinder head according to the signal from ECM.

### Operation

When the solenoid coil of the injector is energized by ECM, it becomes an electromagnet and attracts the plunger. At the same times, the ball valve which is incorporated with the plunger opens and the injector which is under the fuel pressure injects fuel. As the lift stroke of the ball valve of the injector is set constant, the amount of fuel injected at one time is determined by the length of time during which the solenoid coil is energized (injection time).




Fig. 6E-2 Fuel Injector Cross-Section

## ELECTRONIC CONTROL SYSTEM

The electronic control system consists of 1) various sensors which detect the state of engine and driving conditions, 2) ECM which controls various devices according to the signals from the sensors and 3) various controlled devices.

Functionally, it is divided into six sub systems:

- Fuel injection control system
- ISC solenoid valve control system

- Fuel pump control system
- EGR control system (For California spec. model only)
- Evaporative emission control system
- ESA (Electronic Spark Advance) system




Fig. 6E-3 Parts Location



**NOTE:**

Whether equipped with ground circuit(s) \*a and/or

\*b or not depends on car specifications.

- 1. Fuel pump relay
- 2. Fuel pump
- 3. Ignition power unit
- 4. Fuel injector No. 1
- 5. Fuel injector No. 2
- 6. Fuel injector No. 3
- 7. Fuel injector No. 4
- 8. ISC solenoid valve
- 9. EGR VSV  
(California spec. model only)
- 10. Canister purge VSV (if equipped)
- 11. "CHECK ENGINE" light
- 12. Power steering VSV  
(if equipped)
- 13. Battery
- 14. Main fuse
- 15. Main switch
- 16. Monitor coupler
- 16-1. Duty output terminal
- 16-2. Test switch terminal
- 16-3. Diagnosis switch terminal
- 16-4. Diagnosis output terminal
- 17. Main relay
- 17-1. Power steering pressure switch  
(if equipped)

- 18. A/C amplifier  
(only for car with A/C)
- 19. A/C VSV  
(only for car with A/C)
- 20. Distributor
- 20-1. Crank angle sensor
- 21. Oxygen sensor (if equipped)
- 22. Speed sensor
- 23. REGTS  
(California spec. model only)
- 24. TPS
- 24-1. Idle switch
- 25. WTS
- 26. AFS
- 27. Ignition coil
- 28. Noise suppressor
- 29. ECM
- 30. Diodes
- 31. Radiator fan switch
- 32. Heater blower switch
- 33. Rear window defogger switch
- 34. Stop light switch
- 35. Lighting switch
- 36. Ground circuit (if equipped)
- 37. CO adjuster (if equipped)

**Wire color**

- |      |                |      |                      |
|------|----------------|------|----------------------|
| B    | : Black        | Lg/W | : Light green/White  |
| B/BI | : Black/Blue   | Lg/Y | : Light green/Yellow |
| B/G  | : Black/Green  | P    | : Pink               |
| B/R  | : Black/Red    | P/W  | : Pink/White         |
| B/W  | : Black/White  | R    | : Red                |
| B/Y  | : Black/Yellow | R/B  | : Red/Black          |
| Bl   | : Blue         | R/G  | : Red/Green          |
| Bl/B | : Blue/Black   | R/Y  | : Red/Yellow         |
| Bl/R | : Blue/Red     | R/W  | : Red/White          |
| Bl/W | : Blue/White   | Sb   | : Skyblue            |
| Br   | : Brown        | V    | : Violet             |
| Br/B | : Brown/Black  | V/G  | : Violet/Green       |
| Br/R | : Brown/Red    | V/R  | : Violet/Red         |
| Br/W | : Brown/White  | V/Y  | : Violet/Yellow      |
| Br/Y | : Brown/Yellow | W    | : White              |
| G    | : Green        | W/Bl | : White/Blue         |
| Gr   | : Gray         | W/R  | : White/Red          |
| Gr/W | : Gray/White   | Y    | : Yellow             |
| Lg   | : Light green  | Y/B  | : Yellow/Black       |

**Diagnosis Switch Terminal**

There are two diagnosis switch terminals; one included in the junction/fuse block and the other in the monitor coupler in the engine room. When either diagnosis switch terminal is grounded, a diagnosis signal is fed to ECM which then outputs self-diagnosis code and at the same time outputs ISC duty through duty output terminal.

**Test Switch Terminal**

The test switch terminal is included in the monitor coupler. When this terminal is grounded, ECM sets the ignition timing to the initial ignition timing.

When both test switch terminal and diagnosis switch terminal are grounded, ECM outputs A/F duty through the A/F duty check terminal. Also, "CHECK ENGINE" light stays ON at this time, but it is nothing abnormal.




Fig. 6E-5 Diagnosis and Test Switch Terminals

**NOTE:**

Germany specification car is not provided with a diagnosis switch terminal in the fuse box but instead a diagnosis switch is installed to the underside of the instrument panel as shown below.




Fig. 6E-5-1 Diagnosis Switch

# DIAGNOSIS

## DIAGNOSTIC FLOW CHART

### INSPECTION OF ECM AND ITS CIRCUITS

ECM and its circuits can be checked at ECM wiring couplers by measuring voltage and resistance.

**CAUTION:**  
 ECM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ECM with couplers disconnected from it.

#### Voltage Check

1. Remove ECM from body according to the same procedure as that in Service Manual mentioned in the FOREWORD of this manual.
2. Connect ECM couplers to ECM.
3. Check voltage at each terminal of couplers connected.

#### NOTE:

As each terminal voltage is affected by the battery voltage, confirm that it is 11V or more when ignition switch is ON.




Fig. 6E-6 Checking Voltage




Fig. 6E-7 ECM Coupler Terminals

**6E-10 ELECTRONIC FUEL INJECTION SYSTEM**

TERMINAL	CIRCUIT	STANDARD VOLTAGE	CONDITION
A1 A2	Power source	10 – 14V	Ignition switch ON
A3	Power source of AFS	10 – 14V	Ignition switch ON
A4	Power source of TPS	4.0 – 5.5V	Ignition switch ON
A5	Sensor ground	————	————
A6	AFS signal	0.2 – 0.8V	Ignition switch ON
A7	WTS	1.0 – 3.0V	Ignition switch ON Engine cooling water temp.: 80°C (176°F)
A8	Oxygen sensor (if equipped)	Indicator deflection repeated between over and under 0.45V	While engine running at 2000 r/min for 1 minute or longer after warmed up
A9	TPS signal	0 – 1V	Ignition switch ON Throttle valve at idle position
		3.0 – 5.0V	Ignition switch ON Throttle valve at full open position
A10	Speed sensor signal	Indicator deflection repeated between 0V and 3 – 5V	Ignition switch ON Front left tire turned slowly with front right tire locked
A12	Ignition signal	10 – 14V	Ignition switch ON
A13 A14	Ground	————	————
A15	————	————	————
A16	Power source for back up circuit	10 – 14V	Ignition switch ON and OFF
A18	Air-conditioner ON/OFF signal (if equipped)	8 – 14V	Ignition switch ON
		0 – 2V	While engine running at idle speed, Air-conditioner ON
A19	Test switch terminal	10 – 14V	Ignition switch ON
		0 – 1V	Ignition switch ON Test switch terminal grounded
A21	Idle switch (in TPS)	0 – 1V	Ignition switch ON Throttle valve at idle position
		3.0 – 5.0V	Ignition switch ON Throttle valve opens larger than idle position
A22	Diagnosis switch terminal	10 – 14V	Ignition switch ON
		0 – 1V	Ignition switch ON Diagnosis switch terminal grounded



TERMINAL	CIRCUIT	STANDARD VOLTAGE	CONDITION
A23 (California spec. model only)	REGTS	4.0 – 5.0V	Ignition switch ON Sensor ambient temp.: 20°C (68°F)
A24	_____	_____	_____
B1	CAS (positive)	_____	_____
B2	"CHECK ENGINE" light	0 – 3V	Ignition switch ON Diagnosis switch terminal ungrounded
		10 – 14V	Engine running Diagnosis switch terminal ungrounded
B3	P/S VSV (if equipped)	10 – 14V	Ignition switch ON
B5	Canister purge VSV (if equipped)	10 – 14V	Ignition switch ON
B6	_____	_____	_____
B7	Duty output terminal	0V	Ignition switch ON
B8	Main relay ground	0 – 2V	Ignition switch ON
B9	_____	_____	_____
B10	CAS (negative)	_____	_____
B11	Electric load signal	0V	Ignition switch ON Headlight, small light, heater fan, radiator fan, stop light and rear defogger all turned OFF
		10 – 14V	Ignition switch ON Headlight, small light, heater fan, radiator fan, stop light or rear defogger turned ON
B12	Power steering pressure switch (if equipped)	10 – 14V	Ignition switch ON
		0 – 1V	With engine running at idle speed, turning steering wheel to the right and left as far as it stop, repeating it a few times
B13	Fuel pump relay ground	0 – 4V	For 3 seconds after ignition switch ON
		10 – 14V	When over 3 seconds after ignition switch ON
B14 (California spec. model only)	EGR VSV	10 – 14V	Ignition switch ON
B15	_____	_____	_____

**6E-12 ELECTRONIC FUEL INJECTION SYSTEM**

TERMINAL	CIRCUIT	STANDARD VOLTAGE	CONDITION
B16	Ground	_____	_____
B17	_____	_____	_____
B18	ISC solenoid valve	10 – 14V	Ignition switch ON
C1	Engine start signal (Engine start switch)	6 – 12V	While engine cranking
		0 – 1V	Other than above
C2 C7	Power source for injector	10 – 14V	Ignition switch ON
C3 C4	Injector (positive)	_____	_____
		_____	_____
C5 C10	Ground for injector	_____	_____
C6	Ignition output signal	0V	Ignition switch ON
		1 – 3V	While engine cranking
C8 C9	Injector (negative)	_____	_____
		_____	_____

**Resistance Check**

Refer to the Service Manual mentioned in the FOREWORD of this manual.

## ON CAR SERVICE

### IDLE SPEED/ISC DUTY ADJUSTMENT (INCLUDING AIR-CONDITIONER VSV ADJUSTMENT)

Before idle speed/ISC duty check and adjustment, make sure of the following.

- Lead wires and hoses of Electronic Fuel Injection and engine emission control systems are connected securely.
- Accelerator cable has some play, that is, it is not tight.
- Ignition timing is within specification.
- All of electrical loads except ignition are switched off.
- Air-conditioner is OFF, if equipped.
- Air cleaner has been properly installed and is in good condition.

After above items are all confirmed, check idle speed and ISC duty as follows.

#### NOTE:

Before starting engine, place transmission gear shift lever in "Neutral", and set parking brake and block drive wheels.

1. Warm up engine to normal operating temperature.
2. Set tachometer
3. Using service wire, ground "Diagnosis switch terminal" in monitor coupler so that ECM output ISC duty through "Duty output terminal" and make sure that "CHECK ENGINE" light indicate diagnostic code No. 12.




Fig. 6E-8 Grounding Diag. Switch Terminal

4. Connect duty meter between "Duty output terminal" and "Ground terminal" of monitor coupler.




Fig. 6E-9 Connecting Duty Meter

5. Check to ensure that idle speed and ISC duty are as specified. If ISC duty and/or idle speed is not within specification range, adjust it by turning idle speed adjusting screw.


ENGINE IDLE SPEED	850 ± 50 r/min
ISC DUTY AT SPECIFIED IDLE SPEED	35 ± 5% (ON duty meter indication)
	4.9 ± 0.7V when battery voltage is 14V

#### NOTE:

ISC duty can be checked by using analog type voltmeter. ISC duty to voltage relation is as follows.

ON DUTY METER INDICATION (%)	OFF DUTY METER INDICATION (%)	VOLTMETER INDICATION (V)
0	100	0
30	70	0.3 × V <sub>B</sub>
40	60	0.4 × V <sub>B</sub>
100	0	V <sub>B</sub>

- "OFF DUTY METER" is such duty meter that indicates approx. 100% when terminal voltage is approx. "0V".
- "V<sub>B</sub>" represents battery voltage while engine of vehicle being checked is running.



1. Idle speed adjusting screw

Fig. 6E-10 Idle Speed Adjusting Screw

6. Upon completion of adjustment, install adjusting screw cap to throttle body.
7. This step is for checking and/or adjusting engine idle speed and ISC duty when air-conditioner is working.

With car without air-conditioner, advance to step 8. With air-conditioner equipped ones, follow procedure described below.

- 1) Turn air-conditioner switch ON and set heater blower switch to high (max.) speed position. Then check that air-conditioner is working.
- 2) Check to ensure that idle speed and ISC duty are as specified respectively.

ENGINE IDLE SPEED WITH A/C ON	900 ± 50 r/min
ISC DUTY AT SPECIFIED IDLE SPEED	35 ± 5% (ON duty meter indication)
	4.9 ± 0.7V when battery voltage is 14V


**NOTE:**

ISC duty can be checked by using analog type voltmeter. ISC duty to voltage relation is as follows.

ON DUTY METER INDICATION (%)	OFF DUTY METER INDICATION (%)	VOLTMETER INDICATION (V)
0	100	0
30	70	0.3 x V <sub>B</sub>
40	60	0.4 x V <sub>B</sub>
100	0	V <sub>B</sub>

- "OFF DUTY METER" is such duty meter that indicates approx. 100% when terminal voltage is approx. "0V".
- "V<sub>B</sub>" represents battery voltage while engine of vehicle being checked is running.

- 3) If idle speed and/or ISC duty is not within specified range, adjust it by turning adjusting screw of air conditioner VSV.



1. Air-conditioner VSV  
2. Adjusting screw

Fig. 6E-11 Adjusting Screw for Air-Con. VSV

8. Upon completion of adjustment, disconnect service wire from monitor coupler and install cap to monitor coupler.

## ELECTRONIC CONTROL SYSTEM

### SPEED SENSOR

#### Inspection

1. Disconnect negative cable at battery.
2. Remove combination meter from instrument panel.
3. Connect ohmmeter between "GND" terminal and "VSS" terminal of combination meter and turn cable joint of speedometer with a screwdriver. Ohmmeter indicator should move back and forth between 0 (zero) and  $\infty$  (infinity) 4 times while cable joint is turned one full revolution.




Fig. 6E-12 Checking Speed Sensor

Replace speedometer if check result is not satisfactory.

4. Install combination meter to instrument panel.
5. Connect negative cable to battery.



## SECTION 6F

## IGNITION SYSTEM

## NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## CONTENTS

GENERAL DESCRIPTION .....	6F-1
ON CAR SERVICE .....	6F-2
Ignition Timing .....	6F-2

## GENERAL DESCRIPTION

The ignition system used for this car has an ESA (Electronic Spark Advance) system and consists of the following parts.

- ECM
 

It detects the engine condition through the signals from the sensors, determines the most suitable ignition timing and time for electricity to flow to the primary coil and sends a signal to the power unit.
- Power unit
 

It turns ON and OFF the primary current of the ignition coil according to the signal from ECM.
- Ignition coil
 

When the ignition coil primary current is turned OFF, a high voltage is induced in the secondary winding.
- Distributor
 

It distributes a high voltage current to each plug.
- High-tension cords and spark plugs
- CAS (Crank Angle Sensor)
 

Located in the distributor, it converts the crank angle into voltage variation and sends it to ECM. For its details, refer to Section 6E.
- AFM, TPS, WTS, P/S pressure switch, electric load signal diode, A/C switch and speed sensor
 

For their details, refer to Section 6E.

In ESA system, the ECM is programmed for the best ignition timing under every engine condition. Receiving signals which indicate the engine condition from the sensors, e.g., engine revolution, intake air volume, coolant temperature, etc., it selects the most suitable ignition timing from its memory and operates the power unit.

Thus ignition timing is controlled to yield the best engine performance.

For more information, refer to Section 6E.




Fig. 6F-1 Ignition Circuit Diagram for ESA Ignition System

## IGNITION TIMING

### INSPECTION AND ADJUSTMENT

1. Start engine and warm it up to normal operating temperature.
2. Make sure that all of electrical loads except ignition are switched off.
3. Check to be sure that idle speed is within specification.
4. Set timing light to No. 1 high tension cord.
5. Remove monitor coupler cap beside ignition coil.
6. Connect D and E terminals of monitor coupler or E to body by using service wire so that ignition timing is fixed on initial one.




Fig. 6F-2 Fixing Ignition Timing

7. Using timing light, check that timing is within specification.

Initial ignition timing (Test switch terminal grounded)	$6 \pm 1^\circ$ BTDC at $850 \pm 50$ r/min.
---	--

Ignition order	1 - 3 - 4 - 2
----------------	---------------






Fig. 6F-3 Checking Ignition Timing

8. If ignition timing is out of specification, loosen flange bolts, adjust timing by turning distributor assembly while engine is running, and then tighten bolts.
9. After tightening distributor flange bolts, recheck that ignition timing is within specification.

Tightening torque for distributor flange bolts	N·m	kg·m	lb·ft
	10 – 16	1.0 – 1.6	7.0 – 11.5





Fig. 6F-4 Adjusting Ignition Timing

10. After checking and/or adjusting, disconnect service wire from monitor coupler.

**NOTE:**

In this state (test switch terminal ungrounded, idle switch ON and car stopped), ignition timing may vary more or less of initial ignition timing but it is nothing abnormal.

11. Check that increasing engine speed advances ignition timing. If not, check TPS (idle switch), test switch terminal circuit, engine start signal circuit and ECM.



# SECTION 6G1 CRANKING SYSTEM

(1.2 kW and 1.4 kW type)

**NOTE:**

Two types of starting motors are used for this model. They are, 1.2 and 1.4 kW types. Which one is used depends on specifications. For its identification, a label in one of following colors indicative of each type is attached to starting motor itself.

LABEL COLOR	White	Red
OUT PUT (kW)	1.2	1.4

## CONTENTS

<p><b>GENERAL DESCRIPTION</b> ..... 6G1- 1</p> <p style="padding-left: 20px;">Cranking Circuit ..... 6G1- 1</p> <p style="padding-left: 20px;">Starting Motor ..... 6G1- 2</p> <p><b>DIAGNOSIS</b> ..... 6G1- 3</p> <p><b>ON VEHICLE SERVICE</b> ..... 6G1- 4</p> <p style="padding-left: 20px;">Remove and Install Starting Motor ... 6G1- 4</p>	<p><b>STARTING MOTOR REPAIR</b> ..... 6G1- 5</p> <p style="padding-left: 20px;">Remove and Install Magnetic Switch ..... 6G1- 5</p> <p style="padding-left: 20px;">Remove and Install Motor Brush... 6G1- 6</p> <p style="padding-left: 20px;">Remove and Install Armature/Yoke . 6G1- 7</p> <p style="padding-left: 20px;">Remove and Install Over-Running Clutch ..... 6G1- 8</p> <p><b>STARTING MOTOR INSPECTION</b> ... 6G1-11</p> <p><b>SPECIFICATIONS</b> ..... 6G1-16</p>
---	--

## GENERAL DESCRIPTION

### CRANKING CIRCUIT

The cranking circuit consists of the battery, starting motor, ignition switch, and related electrical wiring. These components are connected electrically as shown in Fig. 6G1-1. Only the starting motor will be covered in this portion.

critical wiring. These components are connected electrically as shown in Fig. 6G1-1. Only the starting motor will be covered in this portion.




Fig. 6G1-1 Cranking Circuit

## STARTING MOTOR

The starting motor consists of parts shown in Fig. 6G1-2 and has permanent magnets mounted in starting motor yoke (frame).

The magnetic switch assembly and parts in the starting motor are enclosed in the housings so that they will be protected against possible dirt and water splash.

In the circuit shown in Fig. 6G1-1, the magnetic (motor) switch coils are magnetized when the ignition switch is closed. The resulting plunger and pinion drive lever movement causes the pinion to engage the engine flywheel gear and the magnetic switch main contacts to close, and cranking takes place. When the engine starts, the pinion over-running clutch protects the armature from excessive speed until the switch is opened, at which time the return spring causes the pinion to disengage.

### NOTE:

- Make sure to apply grease before assembly where so indicated in the figure below.
- The two types of starting motors are different only in length, weight of the armature/yoke and their output but the same description of structure, procedures of disassembly, assembly and inspection is applicable. For specifications, refer to the last page of this section.




Fig. 6G1-2

## DIAGNOSIS

Possible symptoms due to starting system trouble are:

- Starting motor does not run (or runs slowly),
- Starting motor runs but fails to crank engine, or
- Abnormal noise is heard.

Proper diagnosis must be made to determine exactly where the cause of each trouble lies . . . in battery, wiring harness, (including starting motor switch), starting motor or engine.

Don't remove motor just because starting motor does not run. Check following items and narrow down scope of possible causes.

- 1) Condition of trouble
- 2) Tightness of battery terminals (including ground cable connection on engine side) and starting motor terminals.
- 3) Discharge of battery
- 4) Mounting of starting motor

Condition	Possible Cause	Correction
<b>Motor not running.</b>	<b>No operating sound of magnetic switch</b> <ol style="list-style-type: none"> <li>1. Battery run down.</li> <li>2. Battery voltage too low due to battery deterioration.</li> <li>3. Poor contact in battery terminal connection.</li> <li>4. Loose grounding cable connection.</li> <li>5. Fuse set loose or blown off.</li> <li>6. Poor contacting action of ignition switch.</li> <li>7. Lead wire socket loose in place.</li> <li>8. Open-circuit between ignition switch and magnetic switch.</li> <li>9. Open-circuit in pull-in coil.</li> <li>10. Poor sliding of plunger and/or pinion.</li> </ol>	Recharge battery. Replace battery.  Retighten or replace.  Retighten. Tighten or replace. Replace.  Retighten. Repair.  Replace magnetic switch. Repair.
	<b>Operating sound of magnetic switch heard.</b> <ol style="list-style-type: none"> <li>1. Battery run down.</li> <li>2. Battery voltage too low due to battery deterioration.</li> <li>3. Loose battery cable connections.</li> <li>4. Burnt main contact point, or poor contacting action of magnetic switch.</li> <li>5. Brushes are seating poorly or worn down.</li> <li>6. Weakened brush spring.</li> <li>7. Burnt commutator.</li> <li>8. Layer short-circuit of armature.</li> </ol>	Recharge battery. Replace battery.  Retighten. Replace magnetic switch.  Repair or replace.  Replace. Replace. Replace.

Condition	Possible Cause	Correction
Starting motor running but too slow (small torque).	<p>If battery and wiring are satisfactory, inspect starting motor.</p> <ol style="list-style-type: none"> <li>1. Insufficient contact of magnetic switch main contacts.</li> <li>2. Layer short-circuit of armature.</li> <li>3. Disconnected, burnt or worn commutator.</li> <li>4. Worn brushes.</li> <li>5. Weakened brush springs.</li> <li>6. Burnt or abnormally worn end bushings.</li> </ol>	<p>Replace.</p> <p>Replace.</p> <p>Repair or replace.</p> <p>Replace brush.</p> <p>Replace spring.</p> <p>Replace bushing.</p>
Starting motor running, but not cranking engine.	<ol style="list-style-type: none"> <li>1. Worn pinion tip.</li> <li>2. Poor sliding of over-running clutch.</li> <li>3. Clutch slipping (idling).</li> <li>4. Worn teeth of ring gear.</li> </ol>	<p>Replace over-running clutch.</p> <p>Repair.</p> <p>Replace over-running clutch.</p> <p>Replace flywheel.</p>
Noise	<ol style="list-style-type: none"> <li>1. Abnormally worn bush.</li> <li>2. Worn pinion or worn teeth of ring gear.</li> <li>3. Poor sliding of pinion (failure in return movement).</li> <li>4. Worn internal or idle gear teeth.</li> <li>5. Lock of oil in each part.</li> </ol>	<p>Replace bush.</p> <p>Replace pinion or flywheel.</p> <p>Repair or replace.</p> <p>Replace.</p> <p>Lubricate.</p>
Starting motor does not stop running.	<ol style="list-style-type: none"> <li>1. Fused contact points of magnetic switch.</li> <li>2. Short-circuit between turns of magnetic switch coil (layer short-circuit).</li> <li>3. Failure of returning action in ignition switch.</li> </ol>	<p>Repair or replace.</p> <p>Replace.</p> <p>Replace.</p>

## ON VEHICLE SERVICE

Starting motors do not require lubrication except during overhaul. When the motor is disassembled for any reason, lubricate as shown in Fig. 6G1-2.

### REMOVAL AND INSTALLATION

#### STARTING MOTOR

Use following procedure to remove starter:

- 1) Disconnect negative battery lead at battery.
- 2) Disconnect magnetic switch lead wire and battery cable from starting motor terminals.
- 3) Remove two starting motor mount bolts.
- 4) Remove starting motor.
- 5) To install, reverse the above procedure.




Fig. 6G1-3 Starting Motor Mounting

# STARTING MOTOR REPAIR

## MAGNETIC SWITCH

### REMOVAL

#### NOTE:

Before disassembling starting motor, be sure to put match mark as shown in the figure below so that any possible mistake can be avoided.




Fig. 6G1-4

- 1) Disconnect wire (switch to motor) from magnetic switch terminal.




Fig. 6G1-5

- 2) Remove magnetic switch assembly.




Fig. 6G1-6

#### NOTE:

Don't disassemble this switch. If defective, replace as a complete assembly.




Fig. 6G1-7

### INSTALLATION

Before installation, inspect plunger joint for wear and replace defective parts.

- 1) Apply grease. (Refer to Fig. 6G1-2)
- 2) Install switch assembly into front housing, referring to below figure especially for its vertical direction. And then tighten screws.




Fig. 6G1-8

- 3) Connect wire from motor to magnetic switch terminal.
- 4) Check switch for operation. (See page 6G1-15)

## MOTOR BRUSH

### REMOVAL

- 1) Remove rear bracket.




Fig. 6G1-9

- 2) Remove brush holder and brushes.




Fig. 6G1-10

### INSTALLATION

Install in reverse order of REMOVAL, noting the following.

- 1) Apply grease. (Refer to Fig. 6G1-2.)
- 2) Install brush holder to armature while pushing 4 brushes outward.




Fig. 6G1-11

- 3) Install rear bracket.
- 4) Check motor for operation. (See page 6G1-15.)

## REAR BUSH (BEARING)

### REMOVAL

- 1) Remove rear bracket.
- 2) Remove rear bracket cap, and then remove rear bush.




Fig. 6G1-12

### INSTALLATION

- 1) Install rear bush as shown below.




Fig. 6G1-13

- 2) Install rear bracket cap as shown above.
- 3) Apply grease. (Refer to Fig. 6G1-2.)
- 4) Install rear bracket.



## ARMATURE/YOKE

### REMOVAL

#### NOTE:

Before disassembling starting motor, be sure to put match marks at two locations (A & B) as shown in figure below so that any possible mistake can be avoided.




Fig. 6G1-14

- 1) Remove magnetic switch. (Refer to page 6G1-5.)
- 2) Remove brush holder. (Refer to page 6G1-6.)
- 3) Remove armature and yoke.




Fig. 6G1-15

### INSTALLATION

Install in reverse order of REMOVAL, noting the following.

- 1) Apply grease. (Refer to Fig. 6G1-2.)

#### NOTE:

If ball of armature shaft came out when removed, be sure to apply grease to ball and put it back in.




Fig. 6G1-16

- 2) Install armature into yoke.




Fig. 6G1-17

- 3) Install yoke and armature into front housing while aligning match mark "B" provided before disassembly.
- 4) Install brush holder. (Refer to page 6G1-6.)
- 5) Install magnetic switch. (Refer to page 6G1-5.)
- 6) Carry out PERFORMANCE TEST referring to page 6G1-15 in this section.

## OVER-RUNNING CLUTCH

### REMOVAL

#### NOTE:

Before disassembling starting motor, be sure to put match marks at two locations (A & B) as shown in figure below so that any possible mistake can be avoided.




Fig. 6G1-18

- 1) Remove magnetic switch assembly. (For details, refer to steps 1) and 2) of MAGNETIC SWITCH REMOVAL described on page 6G1-5.)
- 2) Remove rear bracket.
- 3) Remove brush holder and brushes.




Fig. 6G1-19

- 4) Remove yoke and armature.

- 5) Remove packing and idle gears.




Fig. 6G1-20

- 6) Remove seal rubber and plate.




Fig. 6G1-21

- 7) Remove shaft assembly with lever.




Fig. 6G1-22

8) Remove over-running clutch by removing rings.




Fig. 6G1-23

**INSTALLATION**

Install in reverse order of REMOVAL, noting the following.

- 1) Apply grease. (Refer to Fig. 6G1-2.)
- 2) Install over-running clutch assembly to gear shaft, using care for installing direction of gear shaft stop ring.




Fig. 6G1-24

3) Insert shaft ass'y into front housing with lever positioned as shown below.




Fig. 6G1-25

4) Install packing so that cuts in packing align with holes for through bolt in front housing.




Fig. 6G1-26

5) Install plate and seal rubber to front housing.




Fig. 6G1-27

6) Apply grease to ball and install ball into shaft hole.




Fig. 6G1-28

7) Install yoke and armature to front housing by aligning match marks provided before removal.




Fig. 6G1-29

8) Install brushes and brush holder. (For details, refer to steps 1) to 4) of BRUSH INSTALLATION on page 6G1-6.)

9) Tighten rear bracket bolts and brush holder screws.

10) Install magnetic switch assembly and connect wire (switch to motor) to switch terminal. (For details, refer to steps 1) to 3) of MAGNETIC SWITCH INSTALLATION on page 6G1-5.)




Fig. 6G1-30

11) Upon completion of assembly, carry out PERFORMANCE TEST referring to page 6G1-15 in this section.

# STARTING MOTOR INSPECTION

## 1. INSPECT ARMATURE

Inspect commutator for dirt or burn. Correct with sandpaper or lathe, if necessary.




Fig. 6G1-31

Check commutator for uneven wear. If deflection of dial gauge pointer exceeds limit, repair or replace.

**NOTE:**

Below specification presupposes that armature is free from bend. Bent shaft must be replaced.

Commutator out of round	Standard	Limit
	0.05 mm (0.0019 in.) or less	0.4 mm (0.015 in.)




Fig. 6G1-32

Inspect commutator for wear. If below limit, replace armature.

Commutator outside diameter	Standard	Limit
	29.4 mm (1.16 in.)	28.8 mm (1.13 in.)




Fig. 6G1-33

Inspect commutator for insulator depth. Correct or replace if below limit.

Commutator insulator depth	Standard	Limit
	0.5 – 0.8 mm (0.0196 – 0.0314 in.)	0.2 mm (0.0078 in.)




Fig. 6G1-34

**Ground Test**

Check commutator and armature core. If there is continuity, armature is grounded and must be replaced.




Fig. 6G1-35

**Open Circuit Test**

Check for continuity between segments. If there is no continuity at any test point, there is an open circuit and armature must be replaced.




Fig. 6G1-36

**2. INSPECT PLUNGER**

Inspect plunger for wear. Replace if necessary.




Fig. 6G1-37

**3. INSPECT BRUSH**

- Check brushes for wear. If below limit, replace brush.

Brush length	Standard	Limit
	17.5 mm (0.69 in.)	12 mm (0.47 in.)




Fig. 6G1-38

- Install brushes to each brush holder and check for smooth movement.

**4. INSPECT BRUSH HOLDER AND SPRING**

Check movement of brush in brush holder. If brush movement within brush holder is sluggish, check brush holder for distortion and sliding faces for contamination.

Clean or correct as necessary.

Check for continuity across insulated brush holder (positive side) and grounded brush holder (negative side).

If continuity exists, brush holder is grounded due to defective insulation and should be replaced.




Fig. 6G1-39

Inspect brush springs for wear, damage or other abnormal conditions. Replace if necessary.

Brush spring tension (with brush holder removed from commutator.)	Standard	Limit
	2.1 kg (4.63 lb)	0.7 kg (1.54 lb)




Fig. 6G1-40

**5. INSPECT PINION AND OVER-RUNNING CLUTCH**

Inspect pinion for wear, damage or other abnormal conditions. Check that clutch locks up when turned in direction of drive and rotates smoothly in reverse direction. Replace if necessary.




Fig. 6G1-41

Inspect spline teeth for wear or damage. Replace if necessary. Inspect pinion for smooth movement.




Fig. 6G1-42

**6. INSPECT ARMATURE SHAFT BUSHES**

Inspect bushes for wear or damage. Replace if necessary.




Fig. 6G1-43

### 7. INSPECT MAGNETIC SWITCH

Push in plunger and release it. The plunger should return quickly to its original position. Replace if necessary.




Fig. 6G1-44

### Hold In Coil Open Circuit Test

Check for continuity across magnetic switch 'S' terminal and coil case. If no continuity exists, coil is open and should be replaced.




Fig. 6G1-46

### Pull-In Coil Open Circuit Test

Check for continuity across magnetic switch 'S' terminal and 'M' terminal. If no continuity exists, coil is open and should be replaced.




Fig. 6G1-45

### 8. INSPECT GEARS

Inspect internal gear and idle gears for wear, damage or other abnormal conditions. Replace if necessary.




Fig. 6G1-47



9. PERFORMANCE TEST

**CAUTION:**

These test must be performed within 3 – 5 seconds to avoid burned coil.

1) Pull-In Test

Connect battery to magnetic switch as shown. Check that plunger and pinion move outward. If plunger and pinion don't move, replace magnetic switch.




Fig. 6G1-48

2) Hold-In Test

While connected as above with plunger out, disconnect negative lead from terminal 'M'. Check that plunger and pinion remain out. If plunger and pinion return inward, replace magnetic switch.




Fig. 6G1-49

3) Check Plunger and Pinion Return

Disconnect negative lead from switch body. Check that plunger and pinion return inward. If plunger and pinion don't return, replace magnetic switch.




Fig. 6G1-50

4) No-Load Performance Test

- a) Connect battery and ammeter to starter as shown.
- b) Check that starter rotates smoothly and steadily with pinion moving out. Check that ammeter indicates specified current.

Specified current
50 – 75A at 11V




Fig. 6G1-51

## SPECIFICATIONS

Voltage	12 volts
Output	1.2 kW
	*1.4 kW
Rating	30 seconds
Direction of rotation	Clockwise as viewed from pinion side
Brush length	17.5 mm (0.69 in.)
Number of pinion teeth	8
No-load characteristic	50 – 75A maximum at 11.0 volts, 3,000 r/min (rpm) minimum
	*50 – 75A maximum at 11.0 volts, 2,900 r/min (rpm) minimum
Load characteristic	300A maximum at 7.7 volts, 0.93 kg-m torque, 850 r/min (rpm) minimum
	*300A at 7.7 volts, 1.06 kg-m torque, 930 r/min (rpm) minimum
Locked rotor current	780A maximum at 4.0 volts, 1.9 kg-m minimum
	*980A maximum at 4.0 volts, 2.6 kg-m minimum
Magnetic switch operating voltage	8 volts maximum

**NOTE:**

Data marked with asterisk (\*) is applicable to power steering system equipped car.

## SECTION 6J

## EMISSION CONTROLS

## NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## CONTENTS

GENERAL DESCRIPTION .....	6J-1
Positive Crankcase Ventilation (PCV) System .....	6J-1
ON CAR SERVICE .....	6J-2
PCV System .....	6J-2

## GENERAL DESCRIPTION

## POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM

The term "blow-by gas" stands for the compressed gas and exploded gas which blow through cylinder-to-piston clearance, which contain a large amount of unburned gases such as CO and HC. The PCV (Positive Crankcase Ventilation) system is provided to prevent the blow-by gas from being emitted into atmosphere and it operates as follows.

When the vacuum in the intake manifold is low (throttle valve open), the PCV valve is wide open due to its spring force. Thus a large amount of the blow-by gas is drawn into the intake manifold.

On the other hand, when the vacuum in the manifold is high, the PCV valve opening is limited due to the high vacuum. Thus the amount of the blow-by gas drawn into the intake manifold is small.




Fig. 6J-1 PCV System Operation

## ON CAR SERVICE

### PCV SYSTEM

#### NOTE:

Be sure to check that there is no obstruction in PCV valve or its hoses before adjusting engine idle speed, for obstructed PCV valve or hose hampers its accurate adjustment.

#### PCV HOSE INSPECTION

Check hoses for connection, leakage, clog, and deterioration. Replace as necessary.

#### PCV VALVE INSPECTION

1. Remove PCV valve with hose from cylinder head cover.
2. Run engine at idle.
3. Place your finger over end of PCV valve to check for vacuum. If there is no vacuum, check for clogged valve. Replace as necessary.




Fig. 6J-2 Checking Vacuum

4. After checking vacuum, stop engine and remove PCV valve.

Shake valve and listen for the rattle of check needle inside the valve. If valve does not rattle, replace valve.




Fig. 6J-3 Checking PCV Valve for Sticking

5. After removing the hose, connect PCV hose.

## SECTION 6K

# EXHAUST SYSTEM

**NOTE:**

- For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.
- Whether being equipped with catalytic converter or not depends on regulations of each country. There are two types of catalytic converter.
- What is enclosed in parentheses (\*) in the below description is applicable to the car which has an O<sub>2</sub> sensor on the exhaust manifold.

## GENERAL DESCRIPTION

The exhaust system consists of an exhaust manifold, an exhaust No. 1 pipe, an exhaust No. 2 pipe, a muffler, a tail pipe and seals and gasket etc., and the exhaust No. 2 pipe has the catalytic converter.

The catalytic converter is an emission control device added to the exhaust system to lower the

(CO), (\*and Oxides of Nitrogen (NO<sub>x</sub>)) pollutants in the exhaust gas.

- The catalytic converter requires use of unleaded fuel only.
- Two types of muffler mounting are used. Refer to figure below for their correct installation.




Fig. 6K-1 Exhaust System



## SECTION 7A

## MANUAL TRANSMISSION

## NOTE:

For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

## ON-CAR SERVICE

## GEAR SHIFT CONTROL

## REMOVAL AND INSTALLATION

For removal and installation of gear shift control other than its lever adjustment after installation, use the same procedures as those described in Service Manual mentioned in the FOREWORD of this manual. Shift control lever adjustment is as follows.

For positioning control lever, loosely install 4 guide plate bolts and 4 control lever housing nuts first, adjust position and then tighten those nuts and bolts.

Control lever position distance "A"	215 mm (8.5 in.)
-------------------------------------	---------------------




Fig. 7A-1





**SECTION 8**

**BODY ELECTRICAL SYSTEM**

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

<b>BODY ELECTRICAL SYSTEM</b> .....	8-2
Fuses .....	8-2
<b>INSTRUMENTS AND GAUGES</b> .....	8-3
Combination Meter Wiring .....	8-3
<b>ON CAR SERVICE</b> .....	8-4
Power Window Control System .....	8-4
Main Switch Key Remainder Warning Buzzer .....	8-5
Light Warning Buzzer .....	8-6
Wiring Harness Routing .....	8-7

# BODY ELECTRICAL SYSTEM

## FUSES

The main fuse block is located on the fender apron panel in the engine room and junction/fuse block is installed to underside of instrument cover panel.

The designation and location of each fuse, refer to Service Manual mentioned in the FOREWORD of this manual.

### CAUTION:

- When replacing a fuse, be sure to use one having a correct rated amperage.
- Before replacing a fuse, turn OFF every switch of electric equipments including main switch.

## MAIN FUSE BLOCK CIRCUIT






Fig. 8-1 Main Fuse Block Circuit

Fig. 8-2



**NOTE:**  
Whether equipped with \* marked parts or not depends on car specification.

Terminals position



- |  |                                     |  |                                  |
|--|-------------------------------------|--|----------------------------------|
| 1. To lighting switch  | 11. To water temperature gauge unit | 28. To seat belt switch (Left)                           | 39. To turn signal switch (Left) |
| 2. To illumination controller                                  | 12. Blank                           | 29. To ignition switch                                   | 40. Speed sensor                 |
| 3. Blank   | 13. To ECM                          | 30. To ground  | 41. Hazard circuit               |
| 4. Blank   | 14. Blank                           | 31. To fuel level gauge unit                             | 42. Tachometer                   |
| 5. To ignition   | 15. To ignition switch              | 32, 33. Blank  | 43. Illumination                 |
| 6. Blank   | 16. To generator                    | 34. To parking brake switch                              |                                  |
| 7. Blank   | 17. To turn signal switch (Right)   | 35. To brake fluid level switch and parking brake switch |                                  |
| 8. To ignition coil $\ominus$<br>(for vehicle with tachometer) | 18. To ground                       | 36. To ECM   |                                  |
| 9. To oil pressure switch                                      | 19. To dimmer                       | 37. Blank  |                                  |
| 10. Blank  | 20. To fuse block                   | 38. Blank  |                                  |
|  | 21, 22, 23, 24, 25, 26, 27. Blank   |  |                                  |

# POWER WINDOW CONTROL SYSTEM (If equipped)

## WIRING DIAGRAM




Fig. 8-3

### Trouble Diagnosis

Condition	Possible cause	Correction
All power window motors do not operate.	<ul style="list-style-type: none"> <li>Main fuse and/or fuses blown</li> <li>Wiring or grounding faulty</li> </ul>	Replace main fuse and/or fuses to check for short. Repair as necessary.
Some switches do not operate.	<ul style="list-style-type: none"> <li>Wiring or socket faulty</li> <li>Window lock switch faulty</li> </ul>	Repair as necessary. Replace.
Only one actuator does not faulty.	<ul style="list-style-type: none"> <li>Wiring or socket faulty</li> <li>Actuator faulty</li> </ul>	Repair as necessary. Replace.

## MAIN SWITCH KEY REMAINDER WARNING BUZZER

### DESCRIPTION OF CIRCUIT

The main switch key remainder warning buzzer circuit is a system to sound the buzzer if the driver leaves the car with the main switch key inserted so as to urge him to take it out.

### INSPECTION

If main switch key remainder warning buzzer does not sound, use its wiring diagram in figure below as reference to check buzzer, wiring, etc.




Fig. 8-4 Main Switch Key Remainder Warning Buzzer Circuit

### INSPECTION OF WARNING CONTROLLER/BUZZER

With positive (+) terminal of battery connected to terminal ⑥ of controller and negative (-) one to ④, also connect negative (-) one to ③ as shown in figure.

If buzzer emits buzzing sound then, controller is in good condition. If not, replace.




Fig. 8-5 Checking Warning Controller/Buzzer

## LIGHT WARNING BUZZER

### DESCRIPTION OF CIRCUIT

The light warning buzzer circuit is a system to sound the buzzer when ignition switch turns OFF and door switch (driver's side) turns ON (i.e. driver's side door opens) while lighting switch turns still ON, warning driver to turn off the lights.




Fig. 8-6




Fig. 8-7

### INSPECTION

When the warning buzzer does not make sounding, use the above circuit diagram as reference to check the buzzer, wiring, etc.

### INSPECTION OF WARNING CONTROLLER

First, connect positive (+) terminal of battery to terminal ⑤ of controller and negative (-) one to ③ and ④.


If buzzer emits buzzing sound then, controller is in good condition. If not, replace.

# WIRING HARNESS ROUTING


For the wirings not found in this section, refer to the Service Manual mentioned in the FOREWORD of this manual.

## COWL TOP PANEL WIRING

Right Hand Steering Car



Left Hand Steering Car




- |   |  |
|---|--|
| 1. Wiper motor  | 10. To left headlight, turn signal and small light |
| 2. Main wiring harness No. 1                            | 11. To main fuse and main wiring harness No. 1     |
| 3. Ground   | 12. To battery positive terminal                   |
| 4. Noise suppressor                                     | 13. To starting motor                              |
| 5. Condenser  | 14. Engine wiring harness No. 5                    |
| 6. Ignition coil  | 15. To ground                                      |
| 7. Monitor coupler for Electronic Fuel Injection system | 16. Radiator fan fuse                              |
| 8. To power unit  |  |
| 9. To brake fluid level switch                          |  |

Fig. 8-8 Cowl Top Panel Wiring

## INSTRUMENT PANEL WIRING

(Left hand steering car)



- |   |   |
|---|---|
| <ul style="list-style-type: none"> <li>1. To front speaker (Optional)</li> <li>2. To blower resistor</li> <li>3. To blower motor</li> <li>4. To heater fan switch</li> <li>5. To cigar lighter (Optional)</li> <li>6. Ground</li> <li>7. To rear wiper/washer switch (If equipped)</li> <li>8. To illumination controller (If equipped)</li> <li>9. To floor wiring harness No. 3 (Except West German market)</li> <li>10. To junction block (or main wiring harness No. 1)</li> <li>11. To main wiring harness No. 1</li> <li>12. To front fog light switch (If equipped)</li> <li>13. To combination meter</li> </ul> | <ul style="list-style-type: none"> <li>14. To rear defogger and front fog light switch (If equipped)</li> <li>15. To radio (Optional)</li> <li>16. To seat heater switch (R) (Optional)</li> <li>17. To head light washer switch (If equipped) or to head light leveling switch (If equipped)</li> <li>18. To seat heater switch (L) (Optional)</li> <li>19. To rear fog light switch (If equipped)</li> <li>20. To mirror switch (Optional)</li> <li>21. To mirror motor (Optional)</li> <li>22. ALDL connector</li> <li>23. To clock</li> <li>24. To warning controller/buzzer</li> <li>25. To ash tray illumination</li> </ul> |
|---|---|

(Right hand steering car)




Fig. 8-11 Instrument Panel Wiring



**SECTION 9**

**BODY SERVICE**

**NOTE:**

For the descriptions (items) not found in this section of this manual, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

**CONTENTS**

**ON CAR SERVICE** ..... 9- 2

**FRONT DOOR** ..... 9- 2

    Door Glass ..... 9- 2

    Door Window Regulator ..... 9- 4

    Front Door Lock ..... 9- 5

    Door Assembly ..... 9- 7

**WINDSHEILD** ..... 9- 8

**SEAT BELTS** ..... 9-13

# ON CAR SERVICE

## FRONT DOOR




Fig. 9-1 Front Door Assembly

### DOOR GLASS REMOVAL

Remove following parts.

- 1) Inside handle bezel.
- 2) Trim mounting screw.
- 3) Door mirror inner garnish.
- 4) Door trim, and power window switch lead wire at coupler.




Fig. 9-3 Removing Door Trim

- 5) Door sealing cover.
- 6) Door outside weatherstrip.
- 7) Glass bottom channel attaching screws.




Fig. 9-4

- 8) Take out door glass together with bottom channel.
- 9) Detach glass from bottom channel.

**INSTALLATION**

Reverse the removal sequence to install door glass noting the following points:

1) When installing glass to bottom channel, coat channel with soap water and tap it with a plastic hammer.

Glass-fitted position of bottom channel is as shown below.




Fig. 9-5

2) Adjust equalizer of window regulator so that measurements A and B in Fig. 9-7 are equal to each other.




Fig. 9-6 Adjusting Equalizer




Fig. 9-7

3) Securely seal door sealing cover with adhesive.




Fig. 9-8

## DOOR WINDOW REGULATOR

### REMOVAL

Remove following parts.

- 1) Door glass. (See previous section.)
- 2) Front door trim bracket.
- 3) Power window motor lead wire at coupler.
- 4) Door window regulator attaching screws (six pcs.) Take out regulator through hole "A".




Fig. 9-10


### INSPECTION

- a. Check gear for wear or damage.
- b. Check spring for weakened condition.

### INSTALLATION

Reverse removal sequence to install door window regulator.

- 1) Apply multi-purpose grease to sliding parts.



## FRONT DOOR LOCK




Fig. 9-12 Front Door Lock Assembly

### REMOVAL

Remove following parts.

- 1) Inside handle bezel.
- 2) Trim mounting screw.
- 3) Door trim and power window switch.

4) Door sealing cover.

5) Front door rear sash.

6) Door inside handle and door latch ass'y.

After disconnecting each joint of control link, remove door inside handle and door latch ass'y.




Fig. 9-14 Removing Door Trim




Fig. 9-15 Disconnecting Door Opening Control Link




Fig. 9-16 Disconnecting Rod




Fig. 9-18

**INSTALLATION**

Reverse removal sequence for installation while using care for following items.

1) Door outside opening rod

When installing opening rod 1 to outside handle 2, turn joint 3 to adjust distance "A" to 0 to 2 mm (0 to 0.08 in.) as shown below.

**NOTE:**

Do not push down opening link 6 when adjusting and installing opening rod.




Fig. 9-17

2) Door latch striker

Move door latch striker up and down so that its shaft 3 approximately aligns with the center of groove "C" of door latch.

**NOTE:**

Striker should be placed level and moved vertically. Do not adjust door latch.

Move door latch striker sideways to adjust to 0 mm (0 in.) the door surface-to-body surface difference with door closed.




Fig. 9-19

In order to correctly obtain door striker position in fore-and-aft direction, increase or decrease number of spacers inserted between body and striker to adjust it. Dimension "D" should be adjusted to 12.6 to 14.6 mm (0.50 to 0.57 in.).




Fig. 9-20

**NOTE:**

Apply oil or grease to striker joints periodically.

**DOOR ASSEMBLY**




Fig. 9-21

**REMOVAL**

- 1) Remove stopper pin upward by tapping it with hammer.




Fig. 9-22

- 2) Disconnect door harness at coupler.
- 3) Using a jack, support door panel with a piece of wood placed between jack and panel.
- 4) Remove door ass'y by loosening hinge mounting bolts.




Fig. 9-23

**INSTALLATION**

Reverse removal sequence to install front door.

- When weatherstrip is hardened, water leak may develop. In such case, replace it with new one.
- After installing, adjust door latch striker position by referring to DOOR LOCK INSTALLATION section so that door is positioned correctly.

## WINDSHIELD

The wind shield is installed by using a special type of adhesive (that is, one component urethane adhesive used with primer). For window glass replacement, it is important to use an adhesive which provides sufficient adhesion strength and to follow the proper procedure.

### CAUTION:

Described here is the glass replacement by using one component urethane adhesive to be used with primer in combination. Each adhesive has its own drying and setting time and must be handled and used in a certain specific procedure. Negligence in following such procedure or misuse of the adhesive in any way hinders its inherent adhesive property. Therefore, before the work, make sure to read carefully the instruction and description given by the maker of the adhesive to be used and be sure to follow the procedure and observe each precaution throughout the work.

Use an adhesive of above mentioned type which has following property.

Shearing strength	40 kg/cm <sup>2</sup> or more (569 lb/in <sup>2</sup> )
-------------------	--

Adhesive materials and tools required for removal and installation

- One component urethane adhesive and primers used in combination (For one sheet of window glass).
  - Adhesive (600 g (21.2 oz.))
  - Primer for glass (20 g (0.7 oz.))
  - Primer for body (20 g (0.7 oz.))
  - Primer for urethane (moulding) (20 g (0.7 oz.))
- Eyeleteer
- Piano string
- Brush for primer application (3 pcs)
- Knife
- Rubber sucker grip
- Sealant gun (for filling adhesive)
- Putty spatula (for correcting adhered parts)




Fig. 9-24 Windshield



**REMOVAL**

- 1) Clean both inside and outside of glass and around it.
- 2) Remove wiper arms, garnish and stoppers.
- 3) Remove moulding and moulding joints by cutting with knife.
- 4) Using tape, cover body surface around glass to prevent any damage.
- 5) Remove room mirror, sunshades, and front pillar trims (right & left).
- 6) Warm up front part of roof lining. Then, remove front side rib of roof lining from between front glass and body.




Fig. 9-25

- 7) Drill hole with eyeleteer through adhesive and let piano string through it.




Fig. 9-26

- 8) Cut adhesive all around glass with piano string.

**NOTE:**

Use piano string as close to glass as possible so as to prevent damage to body.




Fig. 9-27




Fig. 9-28

- 9) Using knife, smooth adhesive remaining on body side so that it is 1 – 2 mm thick all around.

**NOTE:**

Before using knife, clean it with alcohol or the like to remove oil from it.




Fig. 9-29

- 10) When re-using glass, remove adhesive from glass, using care not to damage primer coated surface.




Fig. 9-30

### INSTALLATION

- 1) Using cleaning solvent, clean window frame (body) where glass is to be adhered. (Let it dry for more than 10 minutes.)
- 2) Install stoppers (2 pcs) to lower side of window frame (body).
- 3) Peel paper from one side of new glass spacer and attach that lower side to windshield glass.




Fig. 9-31

- 4) Install new upper moulding to glass. Warming moulding for over half an hour at 35°C (95°F) temperature will facilitate work.

- 5) To determine installing position of glass to body, position glass against body so that clearance between upper end of glass and body is about 6 mm (0.236 in) and clearances between each side end (right & left) of glass and body are even. Then mark mating marks on glass and body as shown below. Upper clearance can be adjusted by moving stoppers position.




Fig. 9-32

- 6) Using new brush, apply sufficient amount of primer for body along body surface where window is to be adhered.

### NOTE:

Be sure to refer to maker's instruction for proper handling and drying time.




Fig. 9-33

- 7) Clean glass surface to be adhered to window with clean cloth. If cleaning solvent is used, let it dry for more than 10 minutes.
- 8) Clean moulding surface "A" with clean cloth. (Refer to below figure.)




Fig. 9-34

- 9) Using new brush, apply sufficient amount of primer for glass along glass surface to be adhered to window.

**NOTE:**

- Be sure to refer to maker's instruction for proper handling and drying time.
- Do not touch primer coated surface.




Fig. 9-35

- 10) Using new brush, apply sufficient amount of primer for moulding (Urethane) to surface "A" as shown in Fig. 9-34.

**NOTE:**

- Be sure to refer to maker's instruction for proper handling and drying time.
- Do not touch primer coated surface.

- 11) Apply adhesive referring to Fig. 9-36.

**NOTE:**

- Start from bottom side of glass.
- Be careful not to damage primer.
- Height of adhesive applied to lower side should be higher than that of other three sides.
- Press glass against body quickly after adhesive is applied.
- Use of rubber sucker grip is helpful to hold and carry glass after adhesive is applied.




Fig. 9-36 Application of Adhesive

- 12) Peel remaining paper from moulding and glass spacer.
- 13) Holding rubber sucker grips, place glass onto body by aligning mating marks marked in step 4) and press it.

- 14) Check for water leakage by pouring water over window through hose. If leakage is found, dry window and fill leaky point with adhesive. If water still leaks even after that, remove glass and start installation procedure all over again.

**NOTE:**

- Do not use high pressure water.
- Do not blow compressed air directly at adhesive applied part when drying.
- Do not use infrared lamp or the like for drying.




Fig. 9-37




Fig. 9-38

## SEAT BELTS (If equipped)

### WARNING:

If replacing seat belt is necessary, replace buckle and ELR (or webbing) together as a set. This is for the reason of ensuring locking of tongue plate with buckle.

If these parts are replaced individually, such a locking condition may become unreliable. For this reason, Suzuki will supply only the spare buckle and ELR (or webbing) in a set part.

### CAUTION:

Upon completion of installation, note the following.


- Sudden closing of door before adhesive is completely set may cause glass to become loose or to come off. Therefore, if door is opened or closed before adhesive is completely set, make sure to open all door glasses and use proper care.
- If moulding is not securely in place, hold it down with a tape until adhesive is completely set.
- Each adhesive has its own setting time. Be sure to refer to maker's instruction, check setting time of adhesive to be used and observe precautions to be taken before adhesive is set.
- Refrain from driving till adhesive is completely set so as to ensure proper and sufficient adhesion.

# WIRING DIAGRAM

## CONTENTS

CAR WITH DRL (DAYTIME RUNNING LIGHT) SYSTEM .....	1
CAR WITH DIM-DIP SYSTEM .....	2
GERMANY SPEC. CAR .....	3
OTHER SPEC. CAR .....	4

**WIRING DIAGRAM**  
**1 CAR WITH D.R.L. (DAYTIME RUNNING LIGHT) SYSTEM**



**WIRE COLOR**

1	Blue
2	Black
3	Red
4	Green
5	Yellow
6	Orange
7	Purple
8	Brown
9	Pink
10	Grey
11	White
12	Light Blue
13	Light Green
14	Light Yellow
15	Light Orange
16	Light Purple
17	Light Brown
18	Light Pink
19	Light Grey
20	Light White
21	Light Light Blue
22	Light Light Green
23	Light Light Yellow
24	Light Light Orange
25	Light Light Purple
26	Light Light Brown
27	Light Light Pink
28	Light Light Grey
29	Light Light White
30	Light Light Light Blue
31	Light Light Light Green
32	Light Light Light Yellow
33	Light Light Light Orange
34	Light Light Light Purple
35	Light Light Light Brown
36	Light Light Light Pink
37	Light Light Light Grey
38	Light Light Light White
39	Light Light Light Light Blue
40	Light Light Light Light Green
41	Light Light Light Light Yellow
42	Light Light Light Light Orange
43	Light Light Light Light Purple
44	Light Light Light Light Brown
45	Light Light Light Light Pink
46	Light Light Light Light Grey
47	Light Light Light Light White
48	Light Light Light Light Light Blue
49	Light Light Light Light Light Green
50	Light Light Light Light Light Yellow
51	Light Light Light Light Light Orange
52	Light Light Light Light Light Purple
53	Light Light Light Light Light Brown
54	Light Light Light Light Light Pink
55	Light Light Light Light Light Grey
56	Light Light Light Light Light White
57	Light Light Light Light Light Light Blue
58	Light Light Light Light Light Light Green
59	Light Light Light Light Light Light Yellow
60	Light Light Light Light Light Light Orange
61	Light Light Light Light Light Light Purple
62	Light Light Light Light Light Light Brown
63	Light Light Light Light Light Light Pink
64	Light Light Light Light Light Light Grey
65	Light Light Light Light Light Light White
66	Light Light Light Light Light Light Light Blue
67	Light Light Light Light Light Light Light Green
68	Light Light Light Light Light Light Light Yellow
69	Light Light Light Light Light Light Light Orange
70	Light Light Light Light Light Light Light Purple
71	Light Light Light Light Light Light Light Brown
72	Light Light Light Light Light Light Light Pink
73	Light Light Light Light Light Light Light Grey
74	Light Light Light Light Light Light Light White
75	Light Light Light Light Light Light Light Light Blue
76	Light Light Light Light Light Light Light Light Green
77	Light Light Light Light Light Light Light Light Yellow
78	Light Light Light Light Light Light Light Light Orange
79	Light Light Light Light Light Light Light Light Purple
80	Light Light Light Light Light Light Light Light Brown
81	Light Light Light Light Light Light Light Light Pink
82	Light Light Light Light Light Light Light Light Grey
83	Light Light Light Light Light Light Light Light White
84	Light Light Light Light Light Light Light Light Light Blue
85	Light Light Light Light Light Light Light Light Light Green
86	Light Light Light Light Light Light Light Light Light Yellow
87	Light Light Light Light Light Light Light Light Light Orange
88	Light Light Light Light Light Light Light Light Light Purple
89	Light Light Light Light Light Light Light Light Light Brown
90	Light Light Light Light Light Light Light Light Light Pink
91	Light Light Light Light Light Light Light Light Light Grey
92	Light Light Light Light Light Light Light Light Light White
93	Light Light Light Light Light Light Light Light Light Light Blue
94	Light Light Light Light Light Light Light Light Light Light Green
95	Light Light Light Light Light Light Light Light Light Light Yellow
96	Light Light Light Light Light Light Light Light Light Light Orange
97	Light Light Light Light Light Light Light Light Light Light Purple
98	Light Light Light Light Light Light Light Light Light Light Brown
99	Light Light Light Light Light Light Light Light Light Light Pink
100	Light Light Light Light Light Light Light Light Light Light Grey


**FUSE BOX COLUMN**

1	15A
2	10A
3	5A
4	20A
5	15A
6	10A
7	5A
8	20A
9	15A
10	10A
11	5A
12	20A
13	15A
14	10A
15	5A
16	20A
17	15A
18	10A
19	5A
20	20A
21	15A
22	10A
23	5A
24	20A
25	15A
26	10A
27	5A
28	20A
29	15A
30	10A
31	5A
32	20A
33	15A
34	10A
35	5A
36	20A
37	15A
38	10A
39	5A
40	20A
41	15A
42	10A
43	5A
44	20A
45	15A
46	10A
47	5A
48	20A
49	15A
50	10A
51	5A
52	20A
53	15A
54	10A
55	5A
56	20A
57	15A
58	10A
59	5A
60	20A
61	15A
62	10A
63	5A
64	20A
65	15A
66	10A
67	5A
68	20A
69	15A
70	10A
71	5A
72	20A
73	15A
74	10A
75	5A
76	20A
77	15A
78	10A
79	5A
80	20A
81	15A
82	10A
83	5A
84	20A
85	15A
86	10A
87	5A
88	20A
89	15A
90	10A
91	5A
92	20A
93	15A
94	10A
95	5A
96	20A
97	15A
98	10A
99	5A
100	20A

**WIRE COLOR**

1	Blue
2	Black
3	Red
4	Green
5	Yellow
6	Orange
7	Purple
8	Brown
9	Pink
10	Grey
11	White
12	Light Blue
13	Light Green
14	Light Yellow
15	Light Orange
16	Light Purple
17	Light Brown
18	Light Pink
19	Light Grey
20	Light White
21	Light Light Blue
22	Light Light Green
23	Light Light Yellow
24	Light Light Orange
25	Light Light Purple
26	Light Light Brown
27	Light Light Pink
28	Light Light Grey
29	Light Light White
30	Light Light Light Blue
31	Light Light Light Green
32	Light Light Light Yellow
33	Light Light Light Orange
34	Light Light Light Purple
35	Light Light Light Brown
36	Light Light Light Pink
37	Light Light Light Grey
38	Light Light Light White
39	Light Light Light Light Blue
40	Light Light Light Light Green
41	Light Light Light Light Yellow
42	Light Light Light Light Orange
43	Light Light Light Light Purple
44	Light Light Light Light Brown
45	Light Light Light Light Pink
46	Light Light Light Light Grey
47	Light Light Light Light White
48	Light Light Light Light Light Blue
49	Light Light Light Light Light Green
50	Light Light Light Light Light Yellow
51	Light Light Light Light Light Orange
52	Light Light Light Light Light Purple
53	Light Light Light Light Light Brown
54	Light Light Light Light Light Pink
55	Light Light Light Light Light Grey
56	Light Light Light Light Light White
57	Light Light Light Light Light Light Blue
58	Light Light Light Light Light Light Green
59	Light Light Light Light Light Light Yellow
60	Light Light Light Light Light Light Orange
61	Light Light Light Light Light Light Purple
62	Light Light Light Light Light Light Brown
63	Light Light Light Light Light Light Pink
64	Light Light Light Light Light Light Grey
65	Light Light Light Light Light Light White
66	Light Light Light Light Light Light Light Blue
67	Light Light Light Light Light Light Light Green
68	Light Light Light Light Light Light Light Yellow
69	Light Light Light Light Light Light Light Orange
70	Light Light Light Light Light Light Light Purple
71	Light Light Light Light Light Light Light Brown
72	Light Light Light Light Light Light Light Pink
73	Light Light Light Light Light Light Light Grey
74	Light Light Light Light Light Light Light White
75	Light Light Light Light Light Light Light Light Blue
76	Light Light Light Light Light Light Light Light Green
77	Light Light Light Light Light Light Light Light Yellow
78	Light Light Light Light Light Light Light Light Orange
79	Light Light Light Light Light Light Light Light Purple
80	Light Light Light Light Light Light Light Light Brown
81	Light Light Light Light Light Light Light Light Pink
82	Light Light Light Light Light Light Light Light Grey
83	Light Light Light Light Light Light Light Light White
84	Light Light Light Light Light Light Light Light Light Blue
85	Light Light Light Light Light Light Light Light Light Green
86	Light Light Light Light Light Light Light Light Light Yellow
87	Light Light Light Light Light Light Light Light Light Orange
88	Light Light Light Light Light Light Light Light Light Purple
89	Light Light Light Light Light Light Light Light Light Brown
90	Light Light Light Light Light Light Light Light Light Pink
91	Light Light Light Light Light Light Light Light Light Grey
92	Light Light Light Light Light Light Light Light Light White
93	Light Light Light Light Light Light Light Light Light Light Blue
94	Light Light Light Light Light Light Light Light Light Light Green
95	Light Light Light Light Light Light Light Light Light Light Yellow
96	Light Light Light Light Light Light Light Light Light Light Orange
97	Light Light Light Light Light Light Light Light Light Light Purple
98	Light Light Light Light Light Light Light Light Light Light Brown
99	Light Light Light Light Light Light Light Light Light Light Pink
100	Light Light Light Light Light Light Light Light Light Light Grey

**WIRING DIAGRAM**  
**2 CAR WITH DIM-DIP SYSTEM**




- WIRING COLOR**
- B. BLACK
  - BR. BROWN
  - BU. BLUE
  - LG. LIGHT GRAY
  - PK. PINK
  - RD. RED
  - SL. SILVER
  - TR. TAN
  - Y. YELLOW
  - GRN. GREEN
  - BLK. BLACK
  - BRN. BROWN
  - BLU. BLUE
  - GRY. GRAY
  - PKK. PINK
  - RD. RED
  - SLV. SILVER
  - TAN. TAN
  - YEL. YELLOW
  - GRN. GREEN
  - WH. WHITE
- WIRE END IDENT.**
- B. 100A
  - B. 100B
  - B. 100C
  - B. 100D
  - B. 100E
  - B. 100F
  - B. 100G
  - B. 100H
  - B. 100I
  - B. 100J
  - B. 100K
  - B. 100L
  - B. 100M
  - B. 100N
  - B. 100O
  - B. 100P
  - B. 100Q
  - B. 100R
  - B. 100S
  - B. 100T
  - B. 100U
  - B. 100V
  - B. 100W
  - B. 100X
  - B. 100Y
  - B. 100Z
  - B. 100AA
  - B. 100AB
  - B. 100AC
  - B. 100AD
  - B. 100AE
  - B. 100AF
  - B. 100AG
  - B. 100AH
  - B. 100AI
  - B. 100AJ
  - B. 100AK
  - B. 100AL
  - B. 100AM
  - B. 100AN
  - B. 100AO
  - B. 100AP
  - B. 100AQ
  - B. 100AR
  - B. 100AS
  - B. 100AT
  - B. 100AU
  - B. 100AV
  - B. 100AW
  - B. 100AX
  - B. 100AY
  - B. 100AZ
  - B. 100BA
  - B. 100BB
  - B. 100BC
  - B. 100BD
  - B. 100BE
  - B. 100BF
  - B. 100BG
  - B. 100BH
  - B. 100BI
  - B. 100BJ
  - B. 100BK
  - B. 100BL
  - B. 100BM
  - B. 100BN
  - B. 100BO
  - B. 100BP
  - B. 100BQ
  - B. 100BR
  - B. 100BS
  - B. 100BT
  - B. 100BU
  - B. 100BV
  - B. 100BW
  - B. 100BX
  - B. 100BY
  - B. 100BZ
  - B. 100CA
  - B. 100CB
  - B. 100CC
  - B. 100CD
  - B. 100CE
  - B. 100CF
  - B. 100CG
  - B. 100CH
  - B. 100CI
  - B. 100CJ
  - B. 100CK
  - B. 100CL
  - B. 100CM
  - B. 100CN
  - B. 100CO
  - B. 100CP
  - B. 100CQ
  - B. 100CR
  - B. 100CS
  - B. 100CT
  - B. 100CU
  - B. 100CV
  - B. 100CW
  - B. 100CX
  - B. 100CY
  - B. 100CZ
  - B. 100DA
  - B. 100DB
  - B. 100DC
  - B. 100DD
  - B. 100DE
  - B. 100DF
  - B. 100DG
  - B. 100DH
  - B. 100DI
  - B. 100DJ
  - B. 100DK
  - B. 100DL
  - B. 100DM
  - B. 100DN
  - B. 100DO
  - B. 100DP
  - B. 100DQ
  - B. 100DR
  - B. 100DS
  - B. 100DT
  - B. 100DU
  - B. 100DV
  - B. 100DW
  - B. 100DX
  - B. 100DY
  - B. 100DZ
  - B. 100EA
  - B. 100EB
  - B. 100EC
  - B. 100ED
  - B. 100EE
  - B. 100EF
  - B. 100EG
  - B. 100EH
  - B. 100EI
  - B. 100EJ
  - B. 100EK
  - B. 100EL
  - B. 100EM
  - B. 100EN
  - B. 100EO
  - B. 100EP
  - B. 100EQ
  - B. 100ER
  - B. 100ES
  - B. 100ET
  - B. 100EU
  - B. 100EV
  - B. 100EW
  - B. 100EX
  - B. 100EY
  - B. 100EZ
  - B. 100FA
  - B. 100FB
  - B. 100FC
  - B. 100FD
  - B. 100FE
  - B. 100FF
  - B. 100FG
  - B. 100FH
  - B. 100FI
  - B. 100FJ
  - B. 100FK
  - B. 100FL
  - B. 100FM
  - B. 100FN
  - B. 100FO
  - B. 100FP
  - B. 100FQ
  - B. 100FR
  - B. 100FS
  - B. 100FT
  - B. 100FU
  - B. 100FV
  - B. 100FW
  - B. 100FX
  - B. 100FY
  - B. 100FZ
  - B. 100GA
  - B. 100GB
  - B. 100GC
  - B. 100GD
  - B. 100GE
  - B. 100GF
  - B. 100GG
  - B. 100GH
  - B. 100GI
  - B. 100GJ
  - B. 100GK
  - B. 100GL
  - B. 100GM
  - B. 100GN
  - B. 100GO
  - B. 100GP
  - B. 100GQ
  - B. 100GR
  - B. 100GS
  - B. 100GT
  - B. 100GU
  - B. 100GV
  - B. 100GW
  - B. 100GX
  - B. 100GY
  - B. 100GZ
  - B. 100HA
  - B. 100HB
  - B. 100HC
  - B. 100HD
  - B. 100HE
  - B. 100HF
  - B. 100HG
  - B. 100HH
  - B. 100HI
  - B. 100HJ
  - B. 100HK
  - B. 100HL
  - B. 100HM
  - B. 100HN
  - B. 100HO
  - B. 100HP
  - B. 100HQ
  - B. 100HR
  - B. 100HS
  - B. 100HT
  - B. 100HU
  - B. 100HV
  - B. 100HW
  - B. 100HX
  - B. 100HY
  - B. 100HZ
  - B. 100IA
  - B. 100IB
  - B. 100IC
  - B. 100ID
  - B. 100IE
  - B. 100IF
  - B. 100IG
  - B. 100IH
  - B. 100II
  - B. 100IJ
  - B. 100IK
  - B. 100IL
  - B. 100IM
  - B. 100IN
  - B. 100IO
  - B. 100IP
  - B. 100IQ
  - B. 100IR
  - B. 100IS
  - B. 100IT
  - B. 100IU
  - B. 100IV
  - B. 100IW
  - B. 100IX
  - B. 100IY
  - B. 100IZ
  - B. 100JA
  - B. 100JB
  - B. 100JC
  - B. 100JD
  - B. 100JE
  - B. 100JF
  - B. 100JG
  - B. 100JH
  - B. 100JI
  - B. 100JJ
  - B. 100JK
  - B. 100JL
  - B. 100JM
  - B. 100JN
  - B. 100JO
  - B. 100JP
  - B. 100JQ
  - B. 100JR
  - B. 100JS
  - B. 100JT
  - B. 100JU
  - B. 100JV
  - B. 100JW
  - B. 100JX
  - B. 100JY
  - B. 100JZ
  - B. 100KA
  - B. 100KB
  - B. 100KC
  - B. 100KD
  - B. 100KE
  - B. 100KF
  - B. 100KG
  - B. 100KH
  - B. 100KI
  - B. 100KJ
  - B. 100KK
  - B. 100KL
  - B. 100KM
  - B. 100KN
  - B. 100KO
  - B. 100KP
  - B. 100KQ
  - B. 100KR
  - B. 100KS
  - B. 100KT
  - B. 100KU
  - B. 100KV
  - B. 100KW
  - B. 100KX
  - B. 100KY
  - B. 100KZ
  - B. 100LA
  - B. 100LB
  - B. 100LC
  - B. 100LD
  - B. 100LE
  - B. 100LF
  - B. 100LG
  - B. 100LH
  - B. 100LI
  - B. 100LJ
  - B. 100LK
  - B. 100LL
  - B. 100LM
  - B. 100LN
  - B. 100LO
  - B. 100LP
  - B. 100LQ
  - B. 100LR
  - B. 100LS
  - B. 100LT
  - B. 100LU
  - B. 100LV
  - B. 100LW
  - B. 100LX
  - B. 100LY
  - B. 100LZ
  - B. 100MA
  - B. 100MB
  - B. 100MC
  - B. 100MD
  - B. 100ME
  - B. 100MF
  - B. 100MG
  - B. 100MH
  - B. 100MI
  - B. 100MJ
  - B. 100MK
  - B. 100ML
  - B. 100MM
  - B. 100MN
  - B. 100MO
  - B. 100MP
  - B. 100MQ
  - B. 100MR
  - B. 100MS
  - B. 100MT
  - B. 100MU
  - B. 100MV
  - B. 100MW
  - B. 100MX
  - B. 100MY
  - B. 100MZ
  - B. 100NA
  - B. 100NB
  - B. 100NC
  - B. 100ND
  - B. 100NE
  - B. 100NF
  - B. 100NG
  - B. 100NH
  - B. 100NI
  - B. 100NJ
  - B. 100NK
  - B. 100NL
  - B. 100NM
  - B. 100NN
  - B. 100NO
  - B. 100NP
  - B. 100NQ
  - B. 100NR
  - B. 100NS
  - B. 100NT
  - B. 100NU
  - B. 100NV
  - B. 100NW
  - B. 100NX
  - B. 100NY
  - B. 100NZ
  - B. 100OA
  - B. 100OB
  - B. 100OC
  - B. 100OD
  - B. 100OE
  - B. 100OF
  - B. 100OG
  - B. 100OH
  - B. 100OI
  - B. 100OJ
  - B. 100OK
  - B. 100OL
  - B. 100OM
  - B. 100ON
  - B. 100OO
  - B. 100OP
  - B. 100OQ
  - B. 100OR
  - B. 100OS
  - B. 100OT
  - B. 100OU
  - B. 100OV
  - B. 100OW
  - B. 100OX
  - B. 100OY
  - B. 100OZ
  - B. 100PA
  - B. 100PB
  - B. 100PC
  - B. 100PD
  - B. 100PE
  - B. 100PF
  - B. 100PG
  - B. 100PH
  - B. 100PI
  - B. 100PJ
  - B. 100PK
  - B. 100PL
  - B. 100PM
  - B. 100PN
  - B. 100PO
  - B. 100PP
  - B. 100PQ
  - B. 100PR
  - B. 100PS
  - B. 100PT
  - B. 100PU
  - B. 100PV
  - B. 100PW
  - B. 100PX
  - B. 100PY
  - B. 100PZ
  - B. 100QA
  - B. 100QB
  - B. 100QC
  - B. 100QD
  - B. 100QE
  - B. 100QF
  - B. 100QG
  - B. 100QH
  - B. 100QI
  - B. 100QJ
  - B. 100QK
  - B. 100QL
  - B. 100QM
  - B. 100QN
  - B. 100QO
  - B. 100QP
  - B. 100QQ
  - B. 100QR
  - B. 100QS
  - B. 100QT
  - B. 100QU
  - B. 100QV
  - B. 100QW
  - B. 100QX
  - B. 100QY
  - B. 100QZ
  - B. 100RA
  - B. 100RB
  - B. 100RC
  - B. 100RD
  - B. 100RE
  - B. 100RF
  - B. 100RG
  - B. 100RH
  - B. 100RI
  - B. 100RJ
  - B. 100RK
  - B. 100RL
  - B. 100RM
  - B. 100RN
  - B. 100RO
  - B. 100RP
  - B. 100RQ
  - B. 100RR
  - B. 100RS
  - B. 100RT
  - B. 100RU
  - B. 100RV
  - B. 100RW
  - B. 100RX
  - B. 100RY
  - B. 100RZ
  - B. 100SA
  - B. 100SB
  - B. 100SC
  - B. 100SD
  - B. 100SE
  - B. 100SF
  - B. 100SG
  - B. 100SH
  - B. 100SI
  - B. 100SJ
  - B. 100SK
  - B. 100SL
  - B. 100SM
  - B. 100SN
  - B. 100SO
  - B. 100SP
  - B. 100SQ
  - B. 100SR
  - B. 100SS
  - B. 100ST
  - B. 100SU
  - B. 100SV
  - B. 100SW
  - B. 100SX
  - B. 100SY
  - B. 100SZ
  - B. 100TA
  - B. 100TB
  - B. 100TC
  - B. 100TD
  - B. 100TE
  - B. 100TF
  - B. 100TG
  - B. 100TH
  - B. 100TI
  - B. 100TJ
  - B. 100TK
  - B. 100TL
  - B. 100TM
  - B. 100TN
  - B. 100TO
  - B. 100TP
  - B. 100TQ
  - B. 100TR
  - B. 100TS
  - B. 100TT
  - B. 100TU
  - B. 100TV
  - B. 100TW
  - B. 100TX
  - B. 100TY
  - B. 100TZ
  - B. 100UA
  - B. 100UB
  - B. 100UC
  - B. 100UD
  - B. 100UE
  - B. 100UF
  - B. 100UG
  - B. 100UH
  - B. 100UI
  - B. 100UJ
  - B. 100UK
  - B. 100UL
  - B. 100UM
  - B. 100UN
  - B. 100UO
  - B. 100UP
  - B. 100UQ
  - B. 100UR
  - B. 100US
  - B. 100UT
  - B. 100UU
  - B. 100UV
  - B. 100UW
  - B. 100UX
  - B. 100UY
  - B. 100UZ
  - B. 100VA
  - B. 100VB
  - B. 100VC
  - B. 100VD
  - B. 100VE
  - B. 100VF
  - B. 100VG
  - B. 100VH
  - B. 100VI
  - B. 100VJ
  - B. 100VK
  - B. 100VL
  - B. 100VM
  - B. 100VN
  - B. 100VO
  - B. 100VP
  - B. 100VQ
  - B. 100VR
  - B. 100VS
  - B. 100VT
  - B. 100VU
  - B. 100VV
  - B. 100VW
  - B. 100VX
  - B. 100VY
  - B. 100VZ
  - B. 100WA
  - B. 100WB
  - B. 100WC
  - B. 100WD
  - B. 100WE
  - B. 100WF
  - B. 100WG
  - B. 100WH
  - B. 100WI
  - B. 100WJ
  - B. 100WK
  - B. 100WL
  - B. 100WM
  - B. 100WN
  - B. 100WO
  - B. 100WP
  - B. 100WQ
  - B. 100WR
  - B. 100WS
  - B. 100WT
  - B. 100WU
  - B. 100WV
  - B. 100WW
  - B. 100WX
  - B. 100WY
  - B. 100WZ
  - B. 100XA
  - B. 100XB
  - B. 100XC
  - B. 100XD
  - B. 100XE
  - B. 100XF
  - B. 100XG
  - B. 100XH
  - B. 100XI
  - B. 100XJ
  - B. 100XK
  - B. 100XL
  - B. 100XM
  - B. 100XN
  - B. 100XO
  - B. 100XP
  - B. 100XQ
  - B. 100XR
  - B. 100XS
  - B. 100XT
  - B. 100XU
  - B. 100XV
  - B. 100XW
  - B. 100XX
  - B. 100XY
  - B. 100XZ
  - B. 100YA
  - B. 100YB
  - B. 100YC
  - B. 100YD
  - B. 100YE
  - B. 100YF
  - B. 100YG
  - B. 100YH
  - B. 100YI
  - B. 100YJ
  - B. 100YK
  - B. 100YL
  - B. 100YM
  - B. 100YN
  - B. 100YO
  - B. 100YP
  - B. 100YQ
  - B. 100YR
  - B. 100YS
  - B. 100YT
  - B. 100YU
  - B. 100YV
  - B. 100YW
  - B. 100YX
  - B. 100YY
  - B. 100YZ
  - B. 100ZA
  - B. 100ZB
  - B. 100ZC
  - B. 100ZD
  - B. 100ZE
  - B. 100ZF
  - B. 100ZG
  - B. 100ZH
  - B. 100ZI
  - B. 100ZJ
  - B. 100ZK
  - B. 100ZL
  - B. 100ZM
  - B. 100ZN
  - B. 100ZO
  - B. 100ZP
  - B. 100ZQ
  - B. 100ZR
  - B. 100ZS
  - B. 100ZT
  - B. 100ZU
  - B. 100ZV
  - B. 100ZW
  - B. 100ZX
  - B. 100ZY
  - B. 100ZZ



**WIRING DIAGRAM**  
**3 GERMANY SPEC. CAR**

NOTE: THE SPEAKER IS NOT IN THE RANGE OF THE HEADLIGHTS BEAM.



**WIRE COLOR**

B1	Black
B2	Black
B3	Black
B4	Black
B5	Black
B6	Black
B7	Black
B8	Black
B9	Black
B10	Black
B11	Black
B12	Black
B13	Black
B14	Black
B15	Black
B16	Black
B17	Black
B18	Black
B19	Black
B20	Black
B21	Black
B22	Black
B23	Black
B24	Black
B25	Black
B26	Black
B27	Black
B28	Black
B29	Black
B30	Black
B31	Black
B32	Black
B33	Black
B34	Black
B35	Black
B36	Black
B37	Black
B38	Black
B39	Black
B40	Black
B41	Black
B42	Black
B43	Black
B44	Black
B45	Black
B46	Black
B47	Black
B48	Black
B49	Black
B50	Black
B51	Black
B52	Black
B53	Black
B54	Black
B55	Black
B56	Black
B57	Black
B58	Black
B59	Black
B60	Black
B61	Black
B62	Black
B63	Black
B64	Black
B65	Black
B66	Black
B67	Black
B68	Black
B69	Black
B70	Black
B71	Black
B72	Black
B73	Black
B74	Black
B75	Black
B76	Black
B77	Black
B78	Black
B79	Black
B80	Black
B81	Black
B82	Black
B83	Black
B84	Black
B85	Black
B86	Black
B87	Black
B88	Black
B89	Black
B90	Black
B91	Black
B92	Black
B93	Black
B94	Black
B95	Black
B96	Black
B97	Black
B98	Black
B99	Black
B100	Black


**WIRE COLOR**

B101	Black
B102	Black
B103	Black
B104	Black
B105	Black
B106	Black
B107	Black
B108	Black
B109	Black
B110	Black
B111	Black
B112	Black
B113	Black
B114	Black
B115	Black
B116	Black
B117	Black
B118	Black
B119	Black
B120	Black
B121	Black
B122	Black
B123	Black
B124	Black
B125	Black
B126	Black
B127	Black
B128	Black
B129	Black
B130	Black
B131	Black
B132	Black
B133	Black
B134	Black
B135	Black
B136	Black
B137	Black
B138	Black
B139	Black
B140	Black
B141	Black
B142	Black
B143	Black
B144	Black
B145	Black
B146	Black
B147	Black
B148	Black
B149	Black
B150	Black
B151	Black
B152	Black
B153	Black
B154	Black
B155	Black
B156	Black
B157	Black
B158	Black
B159	Black
B160	Black
B161	Black
B162	Black
B163	Black
B164	Black
B165	Black
B166	Black
B167	Black
B168	Black
B169	Black
B170	Black
B171	Black
B172	Black
B173	Black
B174	Black
B175	Black
B176	Black
B177	Black
B178	Black
B179	Black
B180	Black
B181	Black
B182	Black
B183	Black
B184	Black
B185	Black
B186	Black
B187	Black
B188	Black
B189	Black
B190	Black
B191	Black
B192	Black
B193	Black
B194	Black
B195	Black
B196	Black
B197	Black
B198	Black
B199	Black
B200	Black

**WIRE COLOR**

B201	Black
B202	Black
B203	Black
B204	Black
B205	Black
B206	Black
B207	Black
B208	Black
B209	Black
B210	Black
B211	Black
B212	Black
B213	Black
B214	Black
B215	Black
B216	Black
B217	Black
B218	Black
B219	Black
B220	Black
B221	Black
B222	Black
B223	Black
B224	Black
B225	Black
B226	Black
B227	Black
B228	Black
B229	Black
B230	Black
B231	Black
B232	Black
B233	Black
B234	Black
B235	Black
B236	Black
B237	Black
B238	Black
B239	Black
B240	Black
B241	Black
B242	Black
B243	Black
B244	Black
B245	Black
B246	Black
B247	Black
B248	Black
B249	Black
B250	Black
B251	Black
B252	Black
B253	Black
B254	Black
B255	Black
B256	Black
B257	Black
B258	Black
B259	Black
B260	Black
B261	Black
B262	Black
B263	Black
B264	Black
B265	Black
B266	Black
B267	Black
B268	Black
B269	Black
B270	Black
B271	Black
B272	Black
B273	Black
B274	Black
B275	Black
B276	Black
B277	Black
B278	Black
B279	Black
B280	Black
B281	Black
B282	Black
B283	Black
B284	Black
B285	Black
B286	Black
B287	Black
B288	Black
B289	Black
B290	Black
B291	Black
B292	Black
B293	Black
B294	Black
B295	Black
B296	Black
B297	Black
B298	Black
B299	Black
B300	Black

**WIRING DIAGRAM**  
**4 OTHER SPEC. CAR**



**REP. CODE**

1	12V	12V
2	12V	12V
3	12V	12V
4	12V	12V
5	12V	12V
6	12V	12V
7	12V	12V
8	12V	12V
9	12V	12V
10	12V	12V
11	12V	12V
12	12V	12V
13	12V	12V
14	12V	12V
15	12V	12V
16	12V	12V
17	12V	12V
18	12V	12V
19	12V	12V
20	12V	12V
21	12V	12V
22	12V	12V
23	12V	12V
24	12V	12V
25	12V	12V
26	12V	12V
27	12V	12V
28	12V	12V
29	12V	12V
30	12V	12V
31	12V	12V
32	12V	12V
33	12V	12V
34	12V	12V
35	12V	12V
36	12V	12V
37	12V	12V
38	12V	12V
39	12V	12V
40	12V	12V
41	12V	12V
42	12V	12V
43	12V	12V
44	12V	12V
45	12V	12V
46	12V	12V
47	12V	12V
48	12V	12V
49	12V	12V
50	12V	12V
51	12V	12V
52	12V	12V
53	12V	12V
54	12V	12V
55	12V	12V
56	12V	12V
57	12V	12V
58	12V	12V
59	12V	12V
60	12V	12V
61	12V	12V
62	12V	12V
63	12V	12V
64	12V	12V
65	12V	12V
66	12V	12V
67	12V	12V
68	12V	12V
69	12V	12V
70	12V	12V
71	12V	12V
72	12V	12V
73	12V	12V
74	12V	12V
75	12V	12V
76	12V	12V
77	12V	12V
78	12V	12V
79	12V	12V
80	12V	12V
81	12V	12V
82	12V	12V
83	12V	12V
84	12V	12V
85	12V	12V
86	12V	12V
87	12V	12V
88	12V	12V
89	12V	12V
90	12V	12V
91	12V	12V
92	12V	12V
93	12V	12V
94	12V	12V
95	12V	12V
96	12V	12V
97	12V	12V
98	12V	12V
99	12V	12V
100	12V	12V

**CODE DES COULEURS**

1	12V	12V
2	12V	12V
3	12V	12V
4	12V	12V
5	12V	12V
6	12V	12V
7	12V	12V
8	12V	12V
9	12V	12V
10	12V	12V
11	12V	12V
12	12V	12V
13	12V	12V
14	12V	12V
15	12V	12V
16	12V	12V
17	12V	12V
18	12V	12V
19	12V	12V
20	12V	12V
21	12V	12V
22	12V	12V
23	12V	12V
24	12V	12V
25	12V	12V
26	12V	12V
27	12V	12V
28	12V	12V
29	12V	12V
30	12V	12V
31	12V	12V
32	12V	12V
33	12V	12V
34	12V	12V
35	12V	12V
36	12V	12V
37	12V	12V
38	12V	12V
39	12V	12V
40	12V	12V
41	12V	12V
42	12V	12V
43	12V	12V
44	12V	12V
45	12V	12V
46	12V	12V
47	12V	12V
48	12V	12V
49	12V	12V
50	12V	12V
51	12V	12V
52	12V	12V
53	12V	12V
54	12V	12V
55	12V	12V
56	12V	12V
57	12V	12V
58	12V	12V
59	12V	12V
60	12V	12V
61	12V	12V
62	12V	12V
63	12V	12V
64	12V	12V
65	12V	12V
66	12V	12V
67	12V	12V
68	12V	12V
69	12V	12V
70	12V	12V
71	12V	12V
72	12V	12V
73	12V	12V
74	12V	12V
75	12V	12V
76	12V	12V
77	12V	12V
78	12V	12V
79	12V	12V
80	12V	12V
81	12V	12V
82	12V	12V
83	12V	12V
84	12V	12V
85	12V	12V
86	12V	12V
87	12V	12V
88	12V	12V
89	12V	12V
90	12V	12V
91	12V	12V
92	12V	12V
93	12V	12V
94	12V	12V
95	12V	12V
96	12V	12V
97	12V	12V
98	12V	12V
99	12V	12V
100	12V	12V

**CODE DES LIGES**

1	12V	12V
2	12V	12V
3	12V	12V
4	12V	12V
5	12V	12V
6	12V	12V
7	12V	12V
8	12V	12V
9	12V	12V
10	12V	12V
11	12V	12V
12	12V	12V
13	12V	12V
14	12V	12V
15	12V	12V
16	12V	12V
17	12V	12V
18	12V	12V
19	12V	12V
20	12V	12V
21	12V	12V
22	12V	12V
23	12V	12V
24	12V	12V
25	12V	12V
26	12V	12V
27	12V	12V
28	12V	12V
29	12V	12V
30	12V	12V
31	12V	12V
32	12V	12V
33	12V	12V
34	12V	12V
35	12V	12V
36	12V	12V
37	12V	12V
38	12V	12V
39	12V	12V
40	12V	12V
41	12V	12V
42	12V	12V
43	12V	12V
44	12V	12V
45	12V	12V
46	12V	12V
47	12V	12V
48	12V	12V
49	12V	12V
50	12V	12V
51	12V	12V
52	12V	12V
53	12V	12V
54	12V	12V
55	12V	12V
56	12V	12V
57	12V	12V
58	12V	12V
59	12V	12V
60	12V	12V
61	12V	12V
62	12V	12V
63	12V	12V
64	12V	12V
65	12V	12V
66	12V	12V
67	12V	12V
68	12V	12V
69	12V	12V
70	12V	12V
71	12V	12V
72	12V	12V
73	12V	12V
74	12V	12V
75	12V	12V
76	12V	12V
77	12V	12V
78	12V	12V
79	12V	12V
80	12V	12V
81	12V	12V
82	12V	12V
83	12V	12V
84	12V	12V
85	12V	12V
86	12V	12V
87	12V	12V
88	12V	12V
89	12V	12V
90	12V	12V
91	12V	12V
92	12V	12V
93	12V	12V
94	12V	12V
95	12V	12V
96	12V	12V
97	12V	12V
98	12V	12V
99	12V	12V
100	12V	12V

Prepared by

**SUZUKI MOTOR CORPORATION**

TECHNICAL DEPARTMENT  
AUTOMOBILE SERVICE DIVISION

1st Ed. September, 1991

Printed in Japan

Printing : July, 1993

120