



WIRING DIAGRAM MANUAL

SUZUKI
Caring for Customers

Part No. 99512M70F10-02E
March, 2001 ENG.

FOREWORD

This manual has been prepared to help inspection and service works involving electric wiring of the following model be done efficiently.

Applicable model:SH410

In order to make a good use of this manual, it is important to have a full understanding of its first section "HOW TO USE THIS MANUAL".

All the data and information contained in this manual are based on the vehicle of certain specifications. Therefore, please note that the actual vehicle being serviced may vary somewhat because of differences in specifications or statutory regulations.

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others. Therefore, note that illustrations may differ from the vehicle being actually serviced. SUZUKI MOTOR CORPORATION reserves the right to make changes at any time without notice.

For inspection and service works of electrical parts, following reference materials are also available for your help.

RELATED SERVICE MANUALS

SH410 Euro-3 99500M70F01-01E

SH410 99500M70F00-01E

SUPPLEMENTARY SERVICE MANUAL 99510M70F01-01E

MARUTI UDYOG LIMITED
SERVICE DIVISION

SUZUKI MOTOR CORPORATION

TECHNICAL DEPARTMENT
AUTOMOBILE SERVICE DIVISION

TABLE OF CONTENTS	SECTION
HOW TO USE THIS MANUAL	8A-1
CONNECTOR LAYOUT DIAGRAM	8A-3
INSTALLATION POSITIONS OF SINGLE UNIT PARTS	8A-4
GROUND POINT	8A-5
POWER SUPPLY DIAGRAM	8A-6
SYSTEM CIRCUIT DIAGRAM	8A-7
LIST OF CONNECTORS	8A-8

SECTION 8A-1

8A-1

HOW TO USE THIS MANUAL

CONTENTS

Manual Contents and Description	8A-1-2
Applicability	8A-1-2
Cautions in Servicing	8A-1-3
Symbols and Marks	8A-1-6
Abbreviations	8A-1-7
Wire Color Symbols	8A-1-7
How to Read Connector Layout Diagram (SECTION 8A-3)	8A-1-8
Indication of Connectors and How to Read them	8A-1-9
How to Read Installation Positions of Single Unit Parts (SECTION 8A-4)	8A-1-11
How to Read Ground Point (SECTION 8A-5)	8A-1-12
How to Read Power Supply Diagram (SECTION 8A-6)	8A-1-13
How to Read System Circuit Diagram (SECTION 8A-7)	8A-1-14
How to Read List of Connectors (SECTION 8A-8)	8A-1-16

MANUAL CONTENTS AND DESCRIPTION

This manual consists of diagrams showing the harness routing, connector layout, installation positions of single unit parts (fuse, relay, control unit), ground points, power circuit, system circuit and list of connectors.

SECTION		DESCRIPTION
Connector Layout Diagram	8A-3	Arrangement of connectors used in this vehicle is shown in relation with the wiring harness by using symbols in illustration.
Installation Positions of Single Unit Parts	8A-4	Positions where each fuse, relay and control unit are installed in this vehicle are shown.
Ground Point	8A-5	Points on the body where grounding is made are shown.
Power Supply Diagram	8A-6	Electric flow passage from the positive terminal of the battery to the main fuse and each fuse in the fuse box are shown and names of main systems that apply a load to each fuse are indicated.
System Circuit Diagram	8A-7	Individual circuit from the fuse to the ground of each system is shown. The circuit diagram is designed so as to show the electric flow from the top to the bottom in it.
List of Connectors	8A-8	Shapes of connectors used in this vehicle and arrangements of their pins are shown.


APPLICABILITY

This manual is applicable to the vehicles listed below.

NOTE:

Bear in mind that description in the text may vary from the actual vehicle depending on specifications.


MODEL
SH410




VIN:Vehicle Identification Number

CAUTIONS IN SERVICING


When performing works related to electric systems, observe following cautions for the purpose of protection of electrical parts and prevention of a fire from occurrence.



- When removing the battery from the vehicle or disconnecting the cable from the battery terminals for inspection or service works on the electric systems, always confirm first that the ignition switch and all the other switches have been turned OFF. Otherwise, the semi-conductor part may be damaged.
- When disconnecting cables from the battery, be sure to disconnect the one from the negative (-) terminal first and then the other from the positive (+) terminal.
- Reverse the above order when connecting the cables to the battery terminals.



- When disconnecting connectors, never pull the wiring harnesses. Unlock the connector lock first and then pull them apart by holding connectors themselves.



- When connecting connectors, also hold connectors and put them together until they lock securely (a click is heard).

SYMBOLS AND MARKS

In the diagrams of this manual, each equipments are represented by the symbols and marks as shown below.

Battery	Ground	Normal Fuse	Slow blow fuse	
Circuit breaker	Coil, Solenoid	Heater	Bulb	
Cigarette lighter	Motor	Pump	Horn	Speaker
Buzzer	Chime	Condenser	Thermistor	Reed switch
Resistance	Variable resistance		Transistor	
			 NPN	
Photo transistor	Diode	Reference (zener) diode	Light emitting diode	Photo diode
Piezoelectric element	Harness		Relay	
Connector	Switch	"O" Type terminal		

ABBREVIATIONS

Listed below are the abbreviations as used in this manual and their full terms.


Abbreviation	Full term	Abbreviation	Full term
2WD	2 wheel drive vehicles	ILL	Illumination
4WD	4 wheel drive vehicles	PCM	Power train control module
A/C	Air conditioning	J/C	Joint connector
A/T	Automatic transmission	LH (D)	Left hand (drive vehicle)
ACC	Accessory	LO	Low
CKP	Crank shaft position	MAP	Manifold absolute pressure
CMP	Camshaft position	M/T	Manual transmission
DLC	Data link connector	P/N	Power/Normal
DRL	Daytime running light (If equipped)	RH (D)	Right hand (drive vehicle)
ECT	Engine coolant temperature	ECM	Engine control module
EGR	Exhaust gas recirculation	TCC	Torque converter clutch
HI	High	W/S	Weld splice
IAC	Idle air control	P/S	Power steering
IAT	Intake air temperature	INT	Intermittent
TCM	Transmission control module	O/D	Over drive
IG	Ignition	VSV	Vacuum switching valve

Symbol	Wire core	Symbol	Wire core
B	Black	Or	Orange
Bl	Blue	R	Red
Br	Brown	W	White
G	Green	Y	Yellow
Gr	Gray	P	Pink
Lbl	Light Blue	V	Violet
Lg	Light Green		

WIRE COLOR SYMBOLS

The initial alphabet (s) of the color name is used to represent each color as listed at the left.

There are two types of wire color : one-color type and 2-color type (with a stripe). In case of 2-color type, the first alphabet ("G" of the example in the figure at the left) represents the basic color (color of wire insulation) and the next alphabet ("Y" of the example) represents the color of stripe.




HOW TO READ CONNECTOR LAYOUT DIAGRAM

When necessary to know the location of an electrical part or an intermediate connector, it is easily possible to retrieve it by this diagram.

First consult "SYSTEM CIRCUIT DIAGRAM" section or connector table at the right hand pages of this section for the questioned connector code. Second refer to the diagrams of this section and look for the same code.


More information on use of the code is illustrated below.






INDICATION OF CONNECTORS AND HOW TO READ THEM

The connectors are indicated as shown below in "SYSTEM CIRCUIT DIAGRAM" section. For the shape and pin arrangement of each connector used in this manual, refer to "LIST OF CONNECTORS" section. Described below are how they are indicated and how to read them.




1. · The male terminal and female terminal are identified by a double enclosure and a single one respectively.
· The intermediate connector which connects harnesses is shown by both shapes of the male terminal and the female terminal but the connector to be connected directly to the equipment is shown by the shape of the connector on the harness side.
· The connectors described in this manual are always "harness side connectors" which are viewed from the direction as shown at the right..





2. · There are three types of connectors with respect to the way it is connected and each type is illustrated as shown below.



· To be inserted directly into equipment




· To be connected with harness connector of equipment



· To connect between harnesses (intermediate connector)

8A-1-10 HOW TO USE THIS MANUAL

3. · Joint connectors (if equipped) divide one wire into several different wires or combine several different wires into one wire.
· The joint connector is illustrated below.



How to Read Connector Codes and Pin Nos. (How to Use Manual) :

It is possible to retrieve the location and shape of each connector from the connector code indicated in "SYSTEM CIRCUITDIAGRAM" section and the position of each pin from the connector pin No.

* To retrieve location of connector :


Open "SYSTEM CIRCUIT DIAGRAM" section to consult the connector code of the questioned connector. Then, refer to "CONNECTOR LAYOUT DIAGRAM" section and look for the same code as the connector code in question. The place where the code is found is the location of that connector.

* To retrieve shape or pin No.

Open "SYSTEM CIRCUIT DIAGRAM" section to consult the connector code and pin No. of the questioned connector. Then, refer to "LIST OF CONNECTORS" section as shown at the right in the figure below and look for the desired connector code under which the shape of that connector is shown. This method is convenient when locating the connector in question among similar connectors. Also, by using this page, it is possible to find the position of each pin from the connector pin No. provided in "SYSTEM CIRCUIT DIAGRAM" section.

It is helpful when retrieving pin position in the connector for checking continuity between pins.






To know the location, shape or pin position of the connector, cross-refer "SYSTEM CIRCUIT DIAGRAM", "CONNECTOR LAYOUT DIAGRAM" and "LIST OF CONNECTOR" section as follows:



HOW TO READ INSTALLATION POSITION OF SINGLE UNIT PARTS

The diagram in "INSTALLATION POSITION OF SINGLE UNIT PARTS" section shows installation positions of fuse, relays and control units used in this vehicle. They are illustrated as shown below.

ENGINE ROOM




HOW TO READ GROUND POINT

Ground point means the position where the negative harness among wiring harnesses is grounded. The diagram in "GROUND POINT" section shows such ground points. In "SYSTEM CIRCUIT DIAGRAM" section, there are many ground marks followed by black circles with numerical figures in them (⑩) which mean that the end of the harness with such black circle is grounded to some part of the vehicle.

To locate the ground point (installation position), refer to "GROUND POINT" section.

"SYSTEM CIRCUIT DIAGRAM" section

■ FRONT WIPER & WASHER



[How to locate ground point]


Look in "GROUND POINT" section for the black circle with the same numerical figure (⑩) as the described one in "SYSTEM CIRCUIT DIAGRAM" section.

NOTE:

If there is an electrical part whose ground point is not found in "GROUND POINT" section, that part itself serves as a ground.

CROSS-REFERENCE


"GROUND POINT" section




HOW TO READ POWER SUPPLY DIAGRAM

Power Supply Diagram shows the circuit from the positive terminal of the battery to each fuse in the box and where each fuse is connected (each system circuit name). In addition, the electric load value of each fuse is indicated.

Since every "SYSTEM CIRCUIT DIAGRAM" is drawn from the circuit down the fuse, cross-refer to "POWER SUPPLY DIAGRAM" for the continuity of the upper circuit referring to Fuse No. such as ⑩ .




SYSTEM CIRCUIT DIAGRAM




HOW TO READ SYSTEM CIRCUIT DIAGRAM

The circuit diagram of each system shows the electric circuit from the main fuse, fuse box or the ignition switch (at the top in the diagram) to the ground (at the bottom) so that the circuit can be followed easily when performing inspection and service work.

Further information on connector, ground point and fuses is provided by cross-reference of "SYSTEM CIRCUIT DIAGRAM" and the other sections as described in the preceding indications of this section. Connector code, ground No. and fuse No. are the reference code for cross-reference.





HOW TO READ LIST OF CONNECTORS

"LIST OF CONNECTORS" section is provided to help identification when looking for the connector in question out of similar ones as well as for retrieval for positions of pins in the connector when checking continuity between pins, etc. Please note that the list is drawn to symbolize the basic configurations of the connectors and some connectors in the list may discrepant to the actual ones depending on the specifications.

How to Use List of Connectors :

It is easily possible to find the shape of the connector in question and its pin positions by locating the same connector code and the pin Nos. as those in "SYSTEM CIRCUIT DIAGRAM" section from "LIST OF CONNECTORS" section.

For further information on its use, refer to item "INDICATION OF CONNECTORS AND HOW TO READ THEM" in this section.

SECTION 8A-3

CONNECTOR LAYOUT DIAGRAM

8A-3

CONTENTS

ENGINE ROOM

A: Battery ground cable	8A-3-2
B: Engine room harness (For A/C)	8A-3-2
C: No.5 harness	8A-3-4
E: No.1 harness	8A-3-12

INSTRUMENT PANEL

E: No.1 harness	8A-3-20
G: No.2 harness	8A-3-28

DOOR

J: Power window main wire	8A-3-32
J: Power window sub wire	8A-3-32
J: Speaker wire	8A-3-32
J: Rear door wire	8A-3-32
K: Dome lamp wire	8A-3-32

FLOOR

L: No.3 harness	8A-3-40
-----------------------	---------

REAR

M: No.4 harness	8A-3-44
O: Hatch door harness	8A-3-44


8A-3-2 CONNECTOR LAYOUT DIAGRAM

A

B

ENGINE ROOM

- A: BATTERY GROUND CABLE
- B: ENGINE ROOM HARNESS (FOR A/C)



CONNECTOR	CONNECTIVE POSITION
ENGINE ROOM HARNESS	
B01	A/C COMPRESSOR
B02	CONDENSER FAN MOTOR
B03	DUAL PRESSURE SWITCH
B04	A/C COMPRESSOR RELAY
B05	No.1 HARNESS (TO E56)
B06	A/C CONDENSER FAN RELAY
B07	A/C FUSE
B08	FUSIBLE LINK


8A-3-4 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (RH CARB)

C: No.5 HARNESS

Ⓐ FOR M/T MODEL
Ⓑ FOR A/T MODEL



C No.5 HARNESS

CONNECTOR	CONNECTIVE POSITION
NO. 5 HARNESS	
C06	OIL PRESSURE SWITCH
C09	GENERATOR
C10	GENERATOR
C13	STARTING MOTOR
C14	STARTING MOTOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14) (FOR A/T MODEL)
C22	No.1 HARNESS (TO E16)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C29	THROTTLE POSITION SENSOR (FOR A/T MODEL)
C30	TEMP GAUGE
C31	IDLE UP VSV (FOR A/T MODEL)
C32	RADIATOR FAN SWITCH
C34	CARB SOLENOID (FOR M/T MODEL)
C35	IDLE SWITCH AND FC SOLENOID (FOR A/T MODEL)
C36	DISTRIBUTOR


8A-3-6 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (LH CARB)

C: No.5 HARNESS

Ⓐ FOR M/T MODEL
Ⓑ FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
NO. 5 HARNESS	
C06	OIL PRESSURE SWITCH
C09	GENERATOR
C10	GENERATOR
C13	STARTING MOTOR
C14	STARTING MOTOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14) (FOR A/T MODEL)
C22	No.1 HARNESS (TO E16)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C29	THROTTLE POSITION SENSOR (FOR A/T MODEL)
C30	TEMP GAUGE
C31	IDLE UP VSV (FOR A/T MODEL)
C32	RADIATOR FAN SWITCH
C34	CARB SOLENOID (FOR M/T MODEL)
C35	IDLE SWITCH AND FC SOLENOID (FOR A/T MODEL)
C36	DISTRIBUTOR


8A-3-8 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (RH MPI)

C: No.5 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
No. 5 HARNESS	
C01	INJECTOR #4
C02	INJECTOR #3
C03	INJECTOR #2
C04	INJECTOR #1
C05	IAT SENSOR
C06	OIL PRESSURE SWITCH
C07	HEATED OXYGEN SENSOR
C09	GENERATOR
C10	GENERATOR
C11	THROTTLE POSITION SENSOR
C12	IAC VALVE
C13	STARTING MOTOR
C14	STARTING MOTOR
C15	ECT SENSOR
C17	CKP SENSOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14) (FOR A/T MODEL)
C22	No.1 HARNESS (TO E16)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C26	No.1 HARNESS (TO E17) (FOR A/T MODEL)
C27	No.1 HARNESS (TO E15) (FOR A/T MODEL)
C36	CMP SENSOR


8A-3-10 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (LH MPI)

C: No.5 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
No. 5 HARNESS	
C01	INJECTOR #4
C02	INJECTOR #3
C03	INJECTOR #2
C04	INJECTOR #1
C05	IAT SENSOR
C06	OIL PRESSURE SWITCH
C07	HEATED OXYGEN SENSOR
C09	GENERATOR
C10	GENERATOR
C11	THROTTLE POSITION SENSOR
C12	IAC VALVE
C13	STARTING MOTOR
C14	STARTING MOTOR
C15	ECT SENSOR
C17	CKP SENSOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14)
C22	No.1 HARNESS (TO E16) (FOR A/T MODEL)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C26	No.1 HARNESS (TO E17) (FOR A/T MODEL)
C27	No.1 HARNESS (TO E15) (FOR A/T MODEL)
C28	No.1 HARNESS (TO E69)
C36	CMP SENSOR

8A-3-12 CONNECTOR LAYOUT DIAGRAM


E

ENGINE ROOM (CARB. RH)

E: No. 1 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL

[E] No. 1 HARNESS



[E] No. 1 HARNESS

CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E17	No.5 HARNESS (TO C26) (FOR A/T MODEL)
E18	RADIATOR FAN RELAY
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E55	BRAKE FLUID LEVEL SWITCH
E56	A/C HARNESS (TO B05) (FOR A/T MODEL)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E74	A/C HARNESS (FOR M/T MODEL)


8A-3-14 CONNECTOR LAYOUT DIAGRAM

E

ENGINE ROOM (CARB. LH)

E: No. 1 HARNESS

E No. 1 HARNESS



E No. 1 HARNESS

CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E17	No.5 HARNESS (TO C26) (FOR A/T MODEL)
E18	RADIATOR FAN RELAY
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E56	A/C HARNESS (TO B05) (FOR A/T MODEL)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E74	A/C HARNESS (FOR M/T MODEL)


8A-3-16 CONNECTOR LAYOUT DIAGRAM

E

ENGINE ROOM (MPI RH)

E: No. 1 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21)
E15	No.5 HARNESS (TO C27) (FOR A/T MODEL)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E17	No.5 HARNESS (TO C26) (FOR A/T MODEL)
E18	RADIATOR FAN RELAY
E19	MAIN RELAY
E20	FUEL PUMP RELAY
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E31	IGNITER
E32	MAP SENSOR
E33	EVAP CANSITER PURGE VALVE
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E55	BRAKE FLUID LEVEL SWITCH
E56	A/C HARNESS (TO B05)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E61	HEAD LIGHT BEAM LEVELING ACTUATOR (L)
E65	HEAD LIGHT BEAM LEVELING ACTUATOR (R)
E76	EGR VALVE


8A-3-18 CONNECTOR LAYOUT DIAGRAM

E

ENGINE ROOM (MPI LH)

E: No. 1 HARNESS

- (A) FOR M/T MODEL
- (B) FOR A/T MODEL




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21) (FOR LH MODEL)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E18	RADIATOR FAN RELAY
E19	MAIN RELAY
E20	FUEL PUMP RELAY
E25	REAR WASHER MOTOR
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E31	IGNITER
E32	MAP SENSOR
E33	EVAP CANISTER PURGE VALVE
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E56	BRAKE FLUID LEVEL SWITCH
E56	A/C HARNESS (TO B05)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E61	HEAD LIGHT BEAM LEVELING ACTUATOR (L)
E65	HEAD LIGHT BEAM LEVELING ACTUATOR (R)
E69	No.5 HARNESS (TO C28)
E76	EGR VALVE

8A-3-20 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (RH CARB)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E22	INTERIOR LIGHT WIRE (TO K01)
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E49	TURN SIGNAL RELAY
E70	CARB CONTROLLER
E71	CARB CONTROLLER
E72	CARB CONTROLLER
E73	DIAGNOSIS CONNECTOR
E75	A/C HARNESS

8A-3-22 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (LH CARB)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E22	INTERIOR LIGHT WIRE (TO K01)
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E49	TURN SIGNAL RELAY
E70	CARB CONTROLLER
E71	CARB CONTROLLER
E72	CARB CONTROLLER
E73	DIAGNOSIS CONNECTOR
E75	A/C HARNESS

8A-3-24 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (RH MPI)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E01	ECM
E02	ECM
E03	ECM
E22	INTERIOR LIGHT WIRE (TO K01)
E23	THERMISTOR
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E47	DIODE
E48	DATA LINK CONNECTOR
E49	TURN SIGNAL RELAY
E62	IMMOBILIZER CONTROLLER
E63	IMMOBILIZER OUTPUT DIAGNOSIS COUPLER
E64	COIL ANTENNA

8A-3-26 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (LH MPI)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E01	ECM
E02	ECM
E03	ECM
E22	INTERIOR LIGHT WIRE (TO K01)
E23	THERMISTOR
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E47	DIODE
E48	DATA LINK CONNECTOR
E49	TURN SIGNAL RELAY
E62	IMMOBILIZER CONTROLLER
E63	IMMOBILIZER OUTPUT DIAGNOSIS COUPLER
E64	COIL ANTENNA
E66	DRL CONTROLLER
E67	DRL CONTROLLER

G

INSTRUMENT PANEL (RH)

G: No. 2 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 2 HARNESS	
G02	CIGAR LIGHTER
G03	CIGAR LIGHTER
G04	REAR WIPER & WASHER SWITCH
G05	A/C SWITCH
G06	BLOWER FAN MOTOR SWITCH
G08	COMBINATION METER
G09	COMBINATION METER
G11	REAR FOG LIGHT SWITCH
G13	No.3 HARNESS (TO L02)
G14	No.1 HARNESS (TO E45)
G15	No.1 HARNESS (TO E46)
G17	CLOCK
G18	REAR DEFOGGER SWITCH
G19	HEADLIGHT LEVELING SWITCH

8A-3-30 CONNECTOR LAYOUT DIAGRAM

G

INSTRUMENT PANEL (LH)

G: No. 2 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 2 HARNESS	
G02	CIGAR LIGHTER
G03	CIGAR LIGHTER
G04	REAR WIPER & WASHER SWITCH
G05	A/C SWITCH
G06	BLOWER FAN MOTOR SWITCH
G08	COMBINATION METER
G09	COMBINATION METER
G11	REAR FOG LIGHT SWITCH
G13	No.3 HARNESS (TO L02)
G14	No.1 HARNESS (TO E45)
G15	No.1 HARNESS (TO E46)
G17	CLOCK
G18	REAR DEFOGGER SWITCH
G19	HEADLIGHT LEVELING SWITCH

8A-3-32 CONNECTOR LAYOUT DIAGRAM

J K

FLOOR (5D RH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE



CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E53)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT


8A-3-34 CONNECTOR LAYOUT DIAGRAM

J

K

FLOOR (5D LH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE



CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E59)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT


8A-3-36 CONNECTOR LAYOUT DIAGRAM

J

K

FLOOR (3D RH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE




CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E53)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT

8A-3-38 CONNECTOR LAYOUT DIAGRAM

J K

FLOOR (3D LH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE




CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E53)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT

8A-3-40 CONNECTOR LAYOUT DIAGRAM

L

FLOOR (RH)

L: No.3 HARNESS




CONNECTOR	CONNECTIVE POSITION
No.3 HARNESS	
L01	No.1 HARNESS (TO E44)
L02	No.2 HARNESS (TO G13)
L03	DOOR SWITCH (R)
L04	REAR DOOR WIRE (TO J14)
L06	SHIFT ILLUMINATION LIGHT
L07	PARKING SWITCH
L09	DOOR SWITCH (L)
L10	POWER WINDOW SUB WIRE (TO J16)
L11	FUEL PUMP
L12	FUEL GAUGE
L13	REAR COMBINATION LIGHT (R)
L14	HATCH DOOR HARNESS (TO O01)
L15	No.4 HARNESS (TO M01)
L17	HEATED OXYGEN SENSOR #2

8A-3-42 CONNECTOR LAYOUT DIAGRAM

L

FLOOR (LH)

L: No.3 HARNESS



CONNECTOR	CONNECTIVE POSITION
No.3 HARNESS	
L01	No.1 HARNESS (TO E44)
L02	No.2 HARNESS (TO G13)
L03	DOOR SWITCH (R)
L04	REAR DOOR WIRE (TO J14)
L06	SHIFT ILLUMINATION LIGHT
L07	PARKING SWITCH
L09	DOOR SWITCH (L)
L10	POWER WINDOW SUB WIRE (TO J16)
L11	FUEL PUMP
L12	FUEL GAUGE
L13	REAR COMBINATION LIGHT (R)
L14	HATCH DOOR HARNESS (TO O01)
L15	No.4 HARNESS (TO M01)
L17	HEATED OXYGEN SENSOR #2


8A-3-44 CONNECTOR LAYOUT DIAGRAM

M

O

REAR

M: No. 4 HARNESS
O: HATCH DOOR HARNESS



CONNECTOR	CONNECTIVE POSITION
HATCH DOOR HARNESS	
O01	No.3 HARNESS (TO L14)
O02	REAR DEFOGGER (+)
O03	REAR WIPER MOTOR
O04	HIGH MOUNTED STOP LIGHT
O05	REAR DEFOGGER (-)
No.4 HARNESS	
M01	No.3 HARNESS (TO L15)
M02	REAR FOG LIGHT (R)
M03	LICENSE PLATE LIGHT (R)
M04	LICENSE PLATE LIGHT (L)
M05	REAR FOG LIGHT (L)
M07	REAR COMBINATION LIGHT (L)

SECTION 8A-4

INSTALLATION POSITION OF SINGLE UNIT PARTS






CONTENTS

ENGINE ROOM	8A-4-2
INSTRUMENT PANEL	8A-4-4

8A-4


8A-4-2 INSTALLATION POSITIONS OF SINGLE UNIT PARTS

ENGINE ROOM (MPI)




ENGINE ROOM (MPI)



EVAP CANISTER PURGE VALVE (E33)




NOISE SUPPRESSOR (E29)




<AT> SPEED SENSOR (C23)



OXYGEN SENSOR (C07)








ECT SENSOR (C15)



8A-4-4 INSTALLATION POSITION OF SINGLE UNIT

INSTRUMENT PANEL (MPI)



(A)
DIODE (E4S)

SECTION 8A-5

GROUND POINT







CONTENTS

ENGINE ROOM	8A-5-2
INSTRUMENT PANEL	8A-5-3
FLOOR	8A-5-4


8A-5

8A-5-2 GROUND POINT


ENGINE ROOM




INSTRUMENT PANEL



6






7



8A-5-4 GROUND POINT

FLOOR



SECTION 8A-6

POWER SUPPLY DIAGRAM


CONTENTS

POWER SUPPLY DIAGRAM	8A-6-2
FUSES	8A-6-3

8A-6

8A-6-2 POWER SUPPLY DIAGRAM


POWER SUPPLY DIAGRAM (MPI)



FUSES

The chart below shows the circuits protected by each fuse.


FUSES IN MAIN FUSE BOX




No.	AMPERAGE	PROTECTED CIRCUIT
(1)	60A	BATTERY, 40A MAIN FUSE
(2)	40A	CIRCUIT FUSE

8A-6-4 POWER SUPPLY DIAGRAM

FUSES/CIRCUIT BRAKER IN CIRCUIT FUSE BOX (CARB)



NO.	AMPERAGE	DESCRIPTION ON THE COVER	PROTECTED CIRCUIT
③	15A	HEAD R-L	HEAD LIGHT
④	15A	HEAD R-L	COMBINATION METER HEAD LIGHT
⑤	15A	STOP DOME	DATA LINK CONNECTOR INTERIOR LIGHT BRAKE LIGHT SWITCH REAR FOG LIGHT SWITCH
⑥	15A	HAZARD. HORN	ECM HORN COMBINATION SWITCH
⑦	15A	TAIL	COMBINATION SWITCH
⑧	20A	DOOR LOCK	DOOR LOCK CONTROLLER
⑨	BLANK		
⑩	15A	IG. COIL. METER	RADIATOR FAN SWITCH NOISE SUPPRESSOR ECM GENERATOR COMBINATION METER IGNITION COIL
⑪	15A	WIPER. WASHER	COMBINATION SWITCH FRONT WIPER MOTOR REAR WIPER & WASHER SWITCH REAR WIPER MOTOR TRANSMISSION RANGE SWITCH
⑫	15A	TURN BACK	COMBINATION SWITCH
			BACK-UP LIGHT SWITCH
⑬	15A	HEATER	BLOWER FAN MOTOR CIRCUIT BREAKER
⑭	15A	REAR DEFOGGER	REAR DEFOGGER SWITCH
⑮	15A	CIGAR. RADIO	CIGAR
⑯	30A	R-DTR. FAN	RADIATOR FAN RELAY
⑰	BLANK		
⑱	30A		POWER WINDOW

FUSES/CIRCUIT BRAKER IN CIRCUIT FUSE BOX (MPI)

NO.	AMPERAGE	DESCRIPTION ON THE COVER	PROTECTED CIRCUIT
③	15A	HEAD R-L	HEAD LIGHT
④	15A	HEAD R-L	COMBINATION METER
			HEAD LIGHT
⑤	15A	STOP DOME	DATA LINK CONNECTOR
			INTERIOR LIGHT
			BRAKE LIGHT SWITCH
			REAR FOG LIGHT SWITCH
⑥	15A	HAZARD. HORN	ECM
			HORN
			COMBINATION SWITCH
⑦	15A	TAIL	COMBINATION SWITCH
⑧	20A	DOOR LOCK	DOOR LOCK CONTROLLER
⑨	15A	FI	MAIN RELAY
⑩	15A	IG. COIL. METER	IGNITER, HEATED OXYGEN SENSOR NO. 2
			NOISE SUPPRESSOR
			ECM
			GENERATOR
			COMBINATION METER
			IGNITION COIL
			FUEL PUMP RELAY
			IMMOBILIZER CONTROLLER
⑪	15A	WIPER. WASHER	COMBINATION SWITCH
			FRONT WIPER MOTOR
			REAR WIPER & WASHER SWITCH
			REAR WIPER MOTOR
			TRANSMISSION RANGE SWITCH
⑫	15A	TURN BACK	COMBINATION SWITCH
			BACK-UP LIGHT SWITCH
⑬	15A	HEATER	BLOWER FAN MOTOR
⑭	15A		CIRCUIT BREAKER
⑮	15A	REAR DEFOGGER	REAR DEFOGGER SWITCH
⑯	15A	CIGAR. RADIO	CIGAR
⑰	30A	R-DTR. FAN	RADIATOR FAN RELAY
⑲	BLANK		
⑳	30A		POWER WINDOW


SECTION 8A-7**SYSTEM CIRCUIT DIAGRAM****CONTENTS**

SYSTEM NO.	SYSTEM	PAGE NO.
A-1	CRANKING SYSTEM.....	8A-7-2
A-2	CHARGING SYSTEM	8A-7-3
A-3	IGNITION SYSTEM (MPI)	8A-7-4
A-4	IGNITION SYSTEM (CARB)	8A-7-5
A-5	COOLING SYSTEM (MPI)	8A-7-6
A-6	COLLING SYSTEM (CARB)	8A-7-7
A-7	ENGINE & AT CONTROL SYSTEM	8A-7-8
A-8	ENGINE & CARB CONTROL SYSTEM	8A-7-14
B-1	WINDSHIELD WIPER & WSHER.....	8A-7-18
B-2	REAR WIPER & WASHER	8A-7-19
B-3	REAR DEFOGGER	8A-7-20
B-4	POWER WINDOW	8A-7-22
B-5	POWER DOOR LOCK	8A-7-24
B-6	HORN	8A-7-25
C-1	COMBINATION METER (METER & GAUGE)	8A-7-26
C-2	COMBINATION METER (INDICATOR LAMP)	8A-7-27
C-3	COMBINATION METER (WARNING LAMP)	8A-7-28
D-1	HEADLIGHT SYSTEM (VEHICLE WITH DRL)	8A-7-30
D-2	HEADLIGHT SYSTEM (VEHICLE WITHOUT DRL).....	8A-7-32
D-3	POSITION, TAIL AND LICENSE PLATE LIGHT	8A-7-33
D-4	ILLUMINATION LAMP	8A-7-34
D-5	ROOM LIGHT	8A-7-35
D-6	TURN SIGNAL AND HAZARD WARNING LIGHT	8A-7-36
D-7	BRAKE LIGHT	8A-7-37
D-8	BACK-UP LIGHT (MPI)	8A-7-38
D-9	BACK-UP LIGHT (CARB)	8A-7-39
D-10	REAR FOG LIGHT	8A-7-40
E-1	HEATER SYSTEM (MPI).....	8A-7-42
E-2	HEATER SYSTEM (CARB)	8A-7-44
G-1	CLOCK	8A-7-46
G-2	CIGAR LIGHTER	8A-7-47
G-3	IMMOBILIZER CONTROL SYSTEM	8A-7-48
G-4	HEADLIGHT BEAM LEVELING SYSTEM	8A-7-49


8A-7

8A-7-2 SYSTEM CIRCUIT DIAGRAM

A-1 CRANKING SYSTEM




A-2 CHARGING SYSTEM




8A-7-4 SYSTEM CIRCUIT DIAGRAM

A-3 IGNITION SYSTEM (MPI)




8A-7-5 SYSTEM CIRCUIT DIAGRAM

A-4 IGNITION SYSTEM (CARB)




8A-7-6 SYSTEM CIRCUIT DIAGRAM

A-5 COOLING SYSTEM (MPI)






A-6 COOLING SYSTEM (CARB)



8A-7-8 SYSTEM CIRCUIT DIAGRAM


A-7 ENGINE & AT CONTROL SYSTEM 1 OF 3 (MPI)







8A-7-10 SYSTEM CIRCUIT DIAGRAM

A-7 ENGINE & AT CONTROL SYSTEM 2 OF 3 (MPI)





ECM/PCM





8A-7-12 SYSTEM CIRCUIT DIAGRAM


A-7 ENGINE & AT CONTROL SYSTEM 3 OF 3 (MPI)




MEMO

8A-7-14 SYSTEM CIRCUIT DIAGRAM

A-8 ENGINE & CARB CONTROL SYSTEM (M/T)




CARB CONTROLLER




MEMO


8A-7-16 SYSTEM CIRCUIT DIAGRAM

A-8 ENGINE & CARB CONTROL SYSTEM (A/T)




CARB CONTROLLER






8A-7-18 SYSTEM CIRCUIT DIAGRAM


B-1 WINDSHIELD WIPER & WASHER



B-2 REAR WIPER & WASHER

8A-7-20 SYSTEM CIRCUIT DIAGRAM


B-3 REAR DEFOGGER




MEMO

8A-7-22 SYSTEM CIRCUIT DIAGRAM


B-4 POWER WINDOW






8A-7-24 SYSTEM CIRCUIT DIAGRAM

B-5 POWER DOOR LOCK




B-6 HORN




8A-7-26 SYSTEM CIRCUIT DIAGRAM

C-1 COMBINATION METER (METER GAUGE)




C-2 COMBINATION METER (INDICATOR LAMP)



8A-7-28 SYSTEM CIRCUIT DIAGRAM


C-3 COMBINATION METER (WARNING LAMP)




MEMO

8A-7-30 SYSTEM CIRCUIT DIAGRAM


D-1 HEADLIGHT SYSTEM (VEHICLE WITH DRL)






8A-7-32 SYSTEM CIRCUIT DIAGRAM

D-2 HEADLIGHT SYSTEM (VEHICLE WITHOUT DRL)




D-3 POSITION, TAIL AND LICENSE PLATE LIGHT




8A-7-34 SYSTEM CIRCUIT DIAGRAM

D-4 ILLUMINATION LAMP





D-5 ROOM LIGHT



8A-7-36 SYSTEM CIRCUIT DIAGRAM


D-6 TURN SIGNAL AND HAZARD WARNING LIGHT




D-7 BRAKE LIGHT

8A-7-38 SYSTEM CIRCUIT DIAGRAM

D-8 BACK-UP (MPI)




D-9 BACK-UP LIGHT (CARB)



8A-7-40 SYSTEM CIRCUIT DIAGRAM


D-10 REAR FOG LIGHT




MEMO

8A-7-42 SYSTEM CIRCUIT DIAGRAM


E-1 HEATER SYSTEM (MPI)






8A-7-44 SYSTEM CIRCUIT DIAGRAM


E-2 HEATER SYSTEM (CARB)






8A-7-46 SYSTEM CIRCUIT DIAGRAM


G-1 CLOCK




G-2 CIGAR LIGHTER



G-3 IMMOBILIZER CONTROL SYSTEM



G-4 HEADLIGHT BEAM LEVELING SYSTEM



SECTION 8A-8

LIST OF CONNECTORS

CONTENTS

B : B01-B08	8A-8-2
C: C01-C35	8A-8-2
E : E01-E19	8A-8-2
E20-E76	8A-8-3
G: G01-G09	8A-8-3
G10-G20	8A-8-4
J : J01-J17	8A-8-4
K: K01-K02	8A-8-4
L : L01-L18	8A-8-4
M: M01-M07	8A-8-4
O: O01-O05	8A-8-5
	8A-8

B C E

LIST OF CONNECTORS

B	B01 	B02 	B03 	B04 	B05 (TO E56) 	B06 	B07 	B08 		
C	C01 	C02 	C03 	C04 	C05 	C06 	C07 	C09 	C10 	C11
	C12 	C13 	C14 	C15 	C17 	C18 	C19 	C20 (TO E13) 	C21 (TO E14) 	C22 (TO E16)
	C23 	C24 	C25 	C26 (TO E15) 	C27 (TO E15) 	C28 (TO E69) 	C29 	C30 	C31 	C32
		C34 	C35 	C36 						
E	E01 	E02 	E03 	E04 	E05 	E07 	E06 			
	E10 	E11 	E12 	E13 (TO C20) 	E14 (TO C21) 	E15 (TO C27) 	E16 (TO C22) 	E17 (TO C26) 	E18 	E19

E G

E	E20 	E21 	E22 (TO K01) 	E23 	E24 	E25 	E26 (TO J08) 	E27 (TO J07) 	E28 	E29
	E30 	E31 	E32 	E33 	E34 	E35 	E36 20 19 18 17 16 15 14 13 12 11	E37 	E39 	
	E41 	E42 	E43 	E44 (TOL01) 	E45 (TO G14) 	E46 (TO G15) 	E47 	E48 O 8 7 6 5 4 3 2 1	E49 	
	E51 	E52 (TO J01) 	E53 (TO J02) 	E54 	E55 	E56 (TO B05) 	E57 	E59 	E60 	E61
	E62 	E63 	E64 	E65 	E66 	E67 	E68 	E69 (TO C28) 	E70 	E71
	E72 		E73 	E74 	E75 	E76 				
	G01 	G02 	G03 	G04 	G05 	G06 	G08 	G09 		

LIST OF CONNECTORS 8A-8-4

G J K L M

G	G11 	G13 (TO L02) 	G14 (TO E45) 	G15 (TO E46) 	G16 	G17 	G18 	G19 	G20 	
J	J01 (TO E52) 	J02 (TO E53) 	J03 	J04 	J05 	J06 	J07 (TO E27) 	J08 (TO E26) 	J09 	J10
	J11 	J12 	J14 (TO L04) 	J15 	J16 (TO L10) 	J17 				
K	K01 (TO E22) 	K02 								
L	L01 (TO E44) 	L02 (TO G13) 	L03 	L04 (TO J14) 	L06 	L07 	L09 	L10 (TO J16) 	L11 	L12
	L13 	L14 (TO O01) 	L15 (TO M01) 	L16 	L17 					
M	M01 (TO L15) 	M02 	M03 	M04 	M05 	M06 	M07 			

O	001 (TO L14)	002	003	004	005
					

Prepared by

MARUTI UDYOG LIMITED

Service Division

March, 2001

Part No. 99512M70F10-02E

Printed in India



SUZUKI MOTOR CORPORATION



WIRING DIAGRAM MANUAL

SUZUKI
Caring for Customers

Part No. 99512M70F10-02E
March, 2001 ENG.

FOREWORD

This manual has been prepared to help inspection and service works involving electric wiring of the following model be done efficiently.

Applicable model:SH410

In order to make a good use of this manual, it is important to have a full understanding of its first section "HOW TO USE THIS MANUAL".

All the data and information contained in this manual are based on the vehicle of certain specifications. Therefore, please note that the actual vehicle being serviced may vary somewhat because of differences in specifications or statutory regulations.

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others. Therefore, note that illustrations may differ from the vehicle being actually serviced. SUZUKI MOTOR CORPORATION reserves the right to make changes at any time without notice.

For inspection and service works of electrical parts, following reference materials are also available for your help.

RELATED SERVICE MANUALS

SH410 Euro-3 99500M70F01-01E

SH410 99500M70F00-01E

SUPPLEMENTARY SERVICE MANUAL 99510M70F01-01E

MARUTI UDYOG LIMITED
SERVICE DIVISION

SUZUKI MOTOR CORPORATION

TECHNICAL DEPARTMENT
AUTOMOBILE SERVICE DIVISION

TABLE OF CONTENTS	SECTION
HOW TO USE THIS MANUAL	8A-1
CONNECTOR LAYOUT DIAGRAM	8A-3
INSTALLATION POSITIONS OF SINGLE UNIT PARTS	8A-4
GROUND POINT	8A-5
POWER SUPPLY DIAGRAM	8A-6
SYSTEM CIRCUIT DIAGRAM	8A-7
LIST OF CONNECTORS	8A-8

SECTION 8A-1

8A-1

HOW TO USE THIS MANUAL

CONTENTS

Manual Contents and Description	8A-1-2
Applicability	8A-1-2
Cautions in Servicing	8A-1-3
Symbols and Marks	8A-1-6
Abbreviations	8A-1-7
Wire Color Symbols	8A-1-7
How to Read Connector Layout Diagram (SECTION 8A-3)	8A-1-8
Indication of Connectors and How to Read them	8A-1-9
How to Read Installation Positions of Single Unit Parts (SECTION 8A-4)	8A-1-11
How to Read Ground Point (SECTION 8A-5)	8A-1-12
How to Read Power Supply Diagram (SECTION 8A-6)	8A-1-13
How to Read System Circuit Diagram (SECTION 8A-7)	8A-1-14
How to Read List of Connectors (SECTION 8A-8)	8A-1-16

MANUAL CONTENTS AND DESCRIPTION

This manual consists of diagrams showing the harness routing, connector layout, installation positions of single unit parts (fuse, relay, control unit), ground points, power circuit, system circuit and list of connectors.

SECTION		DESCRIPTION
Connector Layout Diagram	8A-3	Arrangement of connectors used in this vehicle is shown in relation with the wiring harness by using symbols in illustration.
Installation Positions of Single Unit Parts	8A-4	Positions where each fuse, relay and control unit are installed in this vehicle are shown.
Ground Point	8A-5	Points on the body where grounding is made are shown.
Power Supply Diagram	8A-6	Electric flow passage from the positive terminal of the battery to the main fuse and each fuse in the fuse box are shown and names of main systems that apply a load to each fuse are indicated.
System Circuit Diagram	8A-7	Individual circuit from the fuse to the ground of each system is shown. The circuit diagram is designed so as to show the electric flow from the top to the bottom in it.
List of Connectors	8A-8	Shapes of connectors used in this vehicle and arrangements of their pins are shown.


APPLICABILITY

This manual is applicable to the vehicles listed below.

NOTE:

Bear in mind that description in the text may vary from the actual vehicle depending on specifications.


MODEL
SH410




VIN:Vehicle Identification Number

CAUTIONS IN SERVICING


When performing works related to electric systems, observe following cautions for the purpose of protection of electrical parts and prevention of a fire from occurrence.



- When removing the battery from the vehicle or disconnecting the cable from the battery terminals for inspection or service works on the electric systems, always confirm first that the ignition switch and all the other switches have been turned OFF. Otherwise, the semi-conductor part may be damaged.
- When disconnecting cables from the battery, be sure to disconnect the one from the negative (-) terminal first and then the other from the positive (+) terminal.
- Reverse the above order when connecting the cables to the battery terminals.



- When disconnecting connectors, never pull the wiring harnesses. Unlock the connector lock first and then pull them apart by holding connectors themselves.



- When connecting connectors, also hold connectors and put them together until they lock securely (a click is heard).

SYMBOLS AND MARKS

In the diagrams of this manual, each equipments are represented by the symbols and marks as shown below.

Battery	Ground	Normal Fuse	Slow blow fuse	
Circuit breaker	Coil, Solenoid	Heater	Bulb	
Cigarette lighter	Motor	Pump	Horn	Speaker
Buzzer	Chime	Condenser	Thermistor	Reed switch
Resistance	Variable resistance		Transistor	
			 NPN	
Photo transistor	Diode	Reference (zener) diode	Light emitting diode	Photo diode
Piezoelectric element	Harness		Relay	
(Connected)	(Not connected)	Normal open relay	Normal closed relay	
Connector	Switch	"O" Type terminal		

ABBREVIATIONS

Listed below are the abbreviations as used in this manual and their full terms.


Abbreviation	Full term	Abbreviation	Full term
2WD	2 wheel drive vehicles	ILL	Illumination
4WD	4 wheel drive vehicles	PCM	Power train control module
A/C	Air conditioning	J/C	Joint connector
A/T	Automatic transmission	LH (D)	Left hand (drive vehicle)
ACC	Accessory	LO	Low
CKP	Crank shaft position	MAP	Manifold absolute pressure
CMP	Camshaft position	M/T	Manual transmission
DLC	Data link connector	P/N	Power/Normal
DRL	Daytime running light (If equipped)	RH (D)	Right hand (drive vehicle)
ECT	Engine coolant temperature	ECM	Engine control module
EGR	Exhaust gas recirculation	TCC	Torque converter clutch
HI	High	W/S	Weld splice
IAC	Idle air control	P/S	Power steering
IAT	Intake air temperature	INT	Intermittent
TCM	Transmission control module	O/D	Over drive
IG	Ignition	VSV	Vacuum switching valve

Symbol	Wire core	Symbol	Wire core
B	Black	Or	Orange
Bl	Blue	R	Red
Br	Brown	W	White
G	Green	Y	Yellow
Gr	Gray	P	Pink
Lbl	Light Blue	V	Violet
Lg	Light Green		

WIRE COLOR SYMBOLS

The initial alphabet (s) of the color name is used to represent each color as listed at the left.

There are two types of wire color : one-color type and 2-color type (with a stripe). In case of 2-color type, the first alphabet ("G" of the example in the figure at the left) represents the basic color (color of wire insulation) and the next alphabet ("Y" of the example) represents the color of stripe.




HOW TO READ CONNECTOR LAYOUT DIAGRAM

When necessary to know the location of an electrical part or an intermediate connector, it is easily possible to retrieve it by this diagram.

First consult "SYSTEM CIRCUIT DIAGRAM" section or connector table at the right hand pages of this section for the questioned connector code. Second refer to the diagrams of this section and look for the same code.


More information on use of the code is illustrated below.






INDICATION OF CONNECTORS AND HOW TO READ THEM

The connectors are indicated as shown below in "SYSTEM CIRCUIT DIAGRAM" section. For the shape and pin arrangement of each connector used in this manual, refer to "LIST OF CONNECTORS" section. Described below are how they are indicated and how to read them.




1. · The male terminal and female terminal are identified by a double enclosure and a single one respectively.
· The intermediate connector which connects harnesses is shown by both shapes of the male terminal and the female terminal but the connector to be connected directly to the equipment is shown by the shape of the connector on the harness side.
· The connectors described in this manual are always "harness side connectors" which are viewed from the direction as shown at the right..






2. · There are three types of connectors with respect to the way it is connected and each type is illustrated as shown below.



· To be inserted directly into equipment




· To be connected with harness connector of equipment



· To connect between harnesses (intermediate connector)

8A-1-10 HOW TO USE THIS MANUAL

3. · Joint connectors (if equipped) divide one wire into several different wires or combine several different wires into one wire.
 · The joint connector is illustrated below.



How to Read Connector Codes and Pin Nos. (How to Use Manual) :

It is possible to retrieve the location and shape of each connector from the connector code indicated in "SYSTEM CIRCUITDIAGRAM" section and the position of each pin from the connector pin No.

* To retrieve location of connector :


Open "SYSTEM CIRCUIT DIAGRAM" section to consult the connector code of the questioned connector. Then, refer to "CONNECTOR LAYOUT DIAGRAM" section and look for the same code as the connector code in question. The place where the code is found is the location of that connector.

* To retrieve shape or pin No.

Open "SYSTEM CIRCUIT DIAGRAM" section to consult the connector code and pin No. of the questioned connector. Then, refer to "LIST OF CONNECTORS" section as shown at the right in the figure below and look for the desired connector code under which the shape of that connector is shown. This method is convenient when locating the connector in question among similar connectors. Also, by using this page, it is possible to find the position of each pin from the connector pin No. provided in "SYSTEM CIRCUIT DIAGRAM" section.

It is helpful when retrieving pin position in the connector for checking continuity between pins.






To know the location, shape or pin position of the connector, cross-refer "SYSTEM CIRCUIT DIAGRAM", "CONNECTOR LAYOUT DIAGRAM" and "LIST OF CONNECTOR" section as follows:



HOW TO READ INSTALLATION POSITION OF SINGLE UNIT PARTS

The diagram in "INSTALLATION POSITION OF SINGLE UNIT PARTS" section shows installation positions of fuse, relays and control units used in this vehicle. They are illustrated as shown below.

ENGINE ROOM




HOW TO READ GROUND POINT

Ground point means the position where the negative harness among wiring harnesses is grounded. The diagram in "GROUND POINT" section shows such ground points. In "SYSTEM CIRCUIT DIAGRAM" section, there are many ground marks followed by black circles with numerical figures in them (⑩) which mean that the end of the harness with such black circle is grounded to some part of the vehicle.

To locate the ground point (installation position), refer to "GROUND POINT" section.

"SYSTEM CIRCUIT DIAGRAM" section

■ FRONT WIPER & WASHER



[How to locate ground point]


Look in "GROUND POINT" section for the black circle with the same numerical figure (⑩) as the described one in "SYSTEM CIRCUIT DIAGRAM" section.

NOTE:

If there is an electrical part whose ground point is not found in "GROUND POINT" section, that part itself serves as a ground.

CROSS-REFERENCE


"GROUND POINT" section




HOW TO READ POWER SUPPLY DIAGRAM

Power Supply Diagram shows the circuit from the positive terminal of the battery to each fuse in the box and where each fuse is connected (each system circuit name). In addition, the electric load value of each fuse is indicated.

Since every "SYSTEM CIRCUIT DIAGRAM" is drawn from the circuit down the fuse, cross-refer to "POWER SUPPLY DIAGRAM" for the continuity of the upper circuit referring to Fuse No. such as ⑩ .




SYSTEM CIRCUIT DIAGRAM




HOW TO READ SYSTEM CIRCUIT DIAGRAM

The circuit diagram of each system shows the electric circuit from the main fuse, fuse box or the ignition switch (at the top in the diagram) to the ground (at the bottom) so that the circuit can be followed easily when performing inspection and service work.

Further information on connector, ground point and fuses is provided by cross-reference of "SYSTEM CIRCUIT DIAGRAM" and the other sections as described in the preceding indications of this section. Connector code, ground No. and fuse No. are the reference code for cross-reference.





HOW TO READ LIST OF CONNECTORS

"LIST OF CONNECTORS" section is provided to help identification when looking for the connector in question out of similar ones as well as for retrieval for positions of pins in the connector when checking continuity between pins, etc. Please note that the list is drawn to symbolize the basic configurations of the connectors and some connectors in the list may discrepant to the actual ones depending on the specifications.

How to Use List of Connectors :

It is easily possible to find the shape of the connector in question and its pin positions by locating the same connector code and the pin Nos. as those in "SYSTEM CIRCUIT DIAGRAM" section from "LIST OF CONNECTORS" section.

For further information on its use, refer to item "INDICATION OF CONNECTORS AND HOW TO READ THEM" in this section.

SECTION 8A-3

CONNECTOR LAYOUT DIAGRAM

8A-3

CONTENTS

ENGINE ROOM

A: Battery ground cable	8A-3-2
B: Engine room harness (For A/C)	8A-3-2
C: No.5 harness	8A-3-4
E: No.1 harness	8A-3-12

INSTRUMENT PANEL

E: No.1 harness	8A-3-20
G: No.2 harness	8A-3-28

DOOR

J: Power window main wire	8A-3-32
J: Power window sub wire	8A-3-32
J: Speaker wire	8A-3-32
J: Rear door wire	8A-3-32
K: Dome lamp wire	8A-3-32

FLOOR

L: No.3 harness	8A-3-40
-----------------------	---------

REAR

M: No.4 harness	8A-3-44
O: Hatch door harness	8A-3-44


8A-3-2 CONNECTOR LAYOUT DIAGRAM

A

B

ENGINE ROOM

- A: BATTERY GROUND CABLE
- B: ENGINE ROOM HARNESS (FOR A/C)



CONNECTOR	CONNECTIVE POSITION
ENGINE ROOM HARNESS	
B01	A/C COMPRESSOR
B02	CONDENSER FAN MOTOR
B03	DUAL PRESSURE SWITCH
B04	A/C COMPRESSOR RELAY
B05	No.1 HARNESS (TO E56)
B06	A/C CONDENSER FAN RELAY
B07	A/C FUSE
B08	FUSIBLE LINK


8A-3-4 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (RH CARB)

C: No.5 HARNESS

Ⓐ FOR M/T MODEL
Ⓑ FOR A/T MODEL



C No.5 HARNESS

CONNECTOR	CONNECTIVE POSITION
NO. 5 HARNESS	
C06	OIL PRESSURE SWITCH
C09	GENERATOR
C10	GENERATOR
C13	STARTING MOTOR
C14	STARTING MOTOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14) (FOR A/T MODEL)
C22	No.1 HARNESS (TO E16)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C29	THROTTLE POSITION SENSOR (FOR A/T MODEL)
C30	TEMP GAUGE
C31	IDLE UP VSV (FOR A/T MODEL)
C32	RADIATOR FAN SWITCH
C34	CARB SOLENOID (FOR M/T MODEL)
C35	IDLE SWITCH AND FC SOLENOID (FOR A/T MODEL)
C36	DISTRIBUTOR


8A-3-6 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (LH CARB)

C: No.5 HARNESS

Ⓐ FOR M/T MODEL
Ⓑ FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
NO. 5 HARNESS	
C06	OIL PRESSURE SWITCH
C09	GENERATOR
C10	GENERATOR
C13	STARTING MOTOR
C14	STARTING MOTOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14) (FOR A/T MODEL)
C22	No.1 HARNESS (TO E16)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C29	THROTTLE POSITION SENSOR (FOR A/T MODEL)
C30	TEMP GAUGE
C31	IDLE UP VSV (FOR A/T MODEL)
C32	RADIATOR FAN SWITCH
C34	CARB SOLENOID (FOR M/T MODEL)
C35	IDLE SWITCH AND FC SOLENOID (FOR A/T MODEL)
C36	DISTRIBUTOR


8A-3-8 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (RH MPI)

C: No.5 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
No. 5 HARNESS	
C01	INJECTOR #4
C02	INJECTOR #3
C03	INJECTOR #2
C04	INJECTOR #1
C05	IAT SENSOR
C06	OIL PRESSURE SWITCH
C07	HEATED OXYGEN SENSOR
C09	GENERATOR
C10	GENERATOR
C11	THROTTLE POSITION SENSOR
C12	IAC VALVE
C13	STARTING MOTOR
C14	STARTING MOTOR
C15	ECT SENSOR
C17	CKP SENSOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14) (FOR A/T MODEL)
C22	No.1 HARNESS (TO E16)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C26	No.1 HARNESS (TO E17) (FOR A/T MODEL)
C27	No.1 HARNESS (TO E15) (FOR A/T MODEL)
C36	CMP SENSOR


8A-3-10 CONNECTOR LAYOUT DIAGRAM

C

ENGINE ROOM (LH MPI)

C: No.5 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
No. 5 HARNESS	
C01	INJECTOR #4
C02	INJECTOR #3
C03	INJECTOR #2
C04	INJECTOR #1
C05	IAT SENSOR
C06	OIL PRESSURE SWITCH
C07	HEATED OXYGEN SENSOR
C09	GENERATOR
C10	GENERATOR
C11	THROTTLE POSITION SENSOR
C12	IAC VALVE
C13	STARTING MOTOR
C14	STARTING MOTOR
C15	ECT SENSOR
C17	CKP SENSOR
C18	BACK-UP LIGHT SWITCH (FOR M/T MODEL)
C19	MAIN FUSE
C20	No.1 HARNESS (TO E13)
C21	No.1 HARNESS (TO E14)
C22	No.1 HARNESS (TO E16) (FOR A/T MODEL)
C23	OUTPUT SHAFT SPEED SENSOR (FOR A/T MODEL)
C24	TRANSMISSION RANGE SENSOR (FOR A/T MODEL)
C25	SHIFT SOLENOID (FOR A/T MODEL)
C26	No.1 HARNESS (TO E17) (FOR A/T MODEL)
C27	No.1 HARNESS (TO E15) (FOR A/T MODEL)
C28	No.1 HARNESS (TO E69)
C36	CMP SENSOR

8A-3-12 CONNECTOR LAYOUT DIAGRAM


E

ENGINE ROOM (CARB. RH)

E: No. 1 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL

[E] No. 1 HARNESS



[E] No. 1 HARNESS

CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E17	No.5 HARNESS (TO C26) (FOR A/T MODEL)
E18	RADIATOR FAN RELAY
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E55	BRAKE FLUID LEVEL SWITCH
E56	A/C HARNESS (TO B05) (FOR A/T MODEL)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E74	A/C HARNESS (FOR M/T MODEL)


8A-3-14 CONNECTOR LAYOUT DIAGRAM

E

ENGINE ROOM (CARB. LH)

E: No. 1 HARNESS

E No. 1 HARNESS



E No. 1 HARNESS

CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E17	No.5 HARNESS (TO C26) (FOR A/T MODEL)
E18	RADIATOR FAN RELAY
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E56	A/C HARNESS (TO B05) (FOR A/T MODEL)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E74	A/C HARNESS (FOR M/T MODEL)


8A-3-16 CONNECTOR LAYOUT DIAGRAM

E

ENGINE ROOM (MPI RH)

E: No. 1 HARNESS

(A) FOR M/T MODEL
(B) FOR A/T MODEL



CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21)
E15	No.5 HARNESS (TO C27) (FOR A/T MODEL)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E17	No.5 HARNESS (TO C26) (FOR A/T MODEL)
E18	RADIATOR FAN RELAY
E19	MAIN RELAY
E20	FUEL PUMP RELAY
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E31	IGNITER
E32	MAP SENSOR
E33	EVAP CANSITER PURGE VALVE
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E55	BRAKE FLUID LEVEL SWITCH
E56	A/C HARNESS (TO B05)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E61	HEAD LIGHT BEAM LEVELING ACTUATOR (L)
E65	HEAD LIGHT BEAM LEVELING ACTUATOR (R)
E76	EGR VALVE


8A-3-18 CONNECTOR LAYOUT DIAGRAM

E

ENGINE ROOM (MPI LH)

E: No. 1 HARNESS

- (A) FOR M/T MODEL
- (B) FOR A/T MODEL




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E04	FRONT POSITION LIGHT (L)
E05	FRONT WASHER MOTOR
E07	HEAD LIGHT (L)
E08	FRONT TURN SIGNAL LIGHT (L)
E10	HORN #1
E11	HORN #2
E12	RADIATOR FAN MOTOR
E13	No.5 HARNESS (TO C20)
E14	No.5 HARNESS (TO C21) (FOR LH MODEL)
E16	No.5 HARNESS (TO C22) (FOR M/T MODEL)
E18	RADIATOR FAN RELAY
E19	MAIN RELAY
E20	FUEL PUMP RELAY
E25	REAR WASHER MOTOR
E28	MAIN FUSE
E29	NOISE SUPPRESSOR
E30	IGNITION COIL
E31	IGNITER
E32	MAP SENSOR
E33	EVAP CANISTER PURGE VALVE
E51	SIDE TURN SIGNAL LIGHT (R)
E52	POWER WINDOW MAIN WIRE (TO J01)
E53	POWER WINDOW MAIN WIRE (TO J02)
E54	FRONT WIPER MOTOR
E56	BRAKE FLUID LEVEL SWITCH
E56	A/C HARNESS (TO B05)
E57	FRONT TURN SIGNAL LIGHT (R)
E59	FRONT POSITION LIGHT (R)
E60	HEAD LIGHT (R)
E61	HEAD LIGHT BEAM LEVELING ACTUATOR (L)
E65	HEAD LIGHT BEAM LEVELING ACTUATOR (R)
E69	No.5 HARNESS (TO C28)
E76	EGR VALVE

8A-3-20 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (RH CARB)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E22	INTERIOR LIGHT WIRE (TO K01)
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E49	TURN SIGNAL RELAY
E70	CARB CONTROLLER
E71	CARB CONTROLLER
E72	CARB CONTROLLER
E73	DIAGNOSIS CONNECTOR
E75	A/C HARNESS

8A-3-22 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (LH CARB)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E22	INTERIOR LIGHT WIRE (TO K01)
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E49	TURN SIGNAL RELAY
E70	CARB CONTROLLER
E71	CARB CONTROLLER
E72	CARB CONTROLLER
E73	DIAGNOSIS CONNECTOR
E75	A/C HARNESS

8A-3-24 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (RH MPI)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E01	ECM
E02	ECM
E03	ECM
E22	INTERIOR LIGHT WIRE (TO K01)
E23	THERMISTOR
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E47	DIODE
E48	DATA LINK CONNECTOR
E49	TURN SIGNAL RELAY
E62	IMMOBILIZER CONTROLLER
E63	IMMOBILIZER OUTPUT DIAGNOSIS COUPLER
E64	COIL ANTENNA

8A-3-26 CONNECTOR LAYOUT DIAGRAM

E

INSTRUMENT PANEL (LH MPI)

E: No. 1 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 1 HARNESS	
E01	ECM
E02	ECM
E03	ECM
E22	INTERIOR LIGHT WIRE (TO K01)
E23	THERMISTOR
E24	SIDE TURN SIGNAL LIGHT (L)
E25	REAR WASHER MOTOR
E26	POWER WINDOW SUB WIRE (TO J08)
E27	POWER WINDOW SUB WIRE (TO J07)
E34	BLOWER FAN MOTOR
E35	BLOWER FAN MOTOR RESISTOR
E36	COMBINATION SWITCH
E37	MAIN SWITCH P/S
E39	STOP LIGHT SWITCH P/S
E43	DOOR LOCK CONTROLLER
E44	No.3 HARNESS (TO L01)
E45	No.2 HARNESS (TO G14)
E46	No.2 HARNESS (TO G15)
E47	DIODE
E48	DATA LINK CONNECTOR
E49	TURN SIGNAL RELAY
E62	IMMOBILIZER CONTROLLER
E63	IMMOBILIZER OUTPUT DIAGNOSIS COUPLER
E64	COIL ANTENNA
E66	DRL CONTROLLER
E67	DRL CONTROLLER

G

INSTRUMENT PANEL (RH)

G: No. 2 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 2 HARNESS	
G02	CIGAR LIGHTER
G03	CIGAR LIGHTER
G04	REAR WIPER & WASHER SWITCH
G05	A/C SWITCH
G06	BLOWER FAN MOTOR SWITCH
G08	COMBINATION METER
G09	COMBINATION METER
G11	REAR FOG LIGHT SWITCH
G13	No.3 HARNESS (TO L02)
G14	No.1 HARNESS (TO E45)
G15	No.1 HARNESS (TO E46)
G17	CLOCK
G18	REAR DEFOGGER SWITCH
G19	HEADLIGHT LEVELING SWITCH

8A-3-30 CONNECTOR LAYOUT DIAGRAM

G

INSTRUMENT PANEL (LH)

G: No. 2 HARNESS




CONNECTOR	CONNECTIVE POSITION
No. 2 HARNESS	
G02	CIGAR LIGHTER
G03	CIGAR LIGHTER
G04	REAR WIPER & WASHER SWITCH
G05	A/C SWITCH
G06	BLOWER FAN MOTOR SWITCH
G08	COMBINATION METER
G09	COMBINATION METER
G11	REAR FOG LIGHT SWITCH
G13	No.3 HARNESS (TO L02)
G14	No.1 HARNESS (TO E45)
G15	No.1 HARNESS (TO E46)
G17	CLOCK
G18	REAR DEFOGGER SWITCH
G19	HEADLIGHT LEVELING SWITCH

8A-3-32 CONNECTOR LAYOUT DIAGRAM

J K

FLOOR (5D RH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE



CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E53)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT


8A-3-34 CONNECTOR LAYOUT DIAGRAM

J

K

FLOOR (5D LH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE



CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E59)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT


8A-3-36 CONNECTOR LAYOUT DIAGRAM

J

K

FLOOR (3D RH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE




CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E53)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT

8A-3-38 CONNECTOR LAYOUT DIAGRAM

J K

FLOOR (3D LH)

J: POWER WINDOW MAIN WIRE
POWER WINDOW SUB WIRE
REAR DOOR WIRE
SPEAKER WIRE
K: DOME LAMP WIRE




CONNECTOR	CONNECTIVE POSITION
SPEAKER WIRE	
J02	No.1 HARNESS (TO E53)
J04	SPEAKER (DRIVER SIDE)
J08	No.1 HARNESS (TO E26)
J10	SPEAKER (PASSENGER SIDE)
POWER WINDOW MAIN WIRE	
J01	No.1 HARNESS (TO E52)
J02	No.1 HARNESS (TO E53)
J03	FRONT POWER WINDOW MOTOR (R)
J04	SPEAKER (DRIVE SIDE)
J05	POWER WINDOW MAIN SWITCH
J06	KEY SWITCH
POWER WINDOW SUB WIRE	
J07	FLOOR HARNESS (TO E27)
J08	No.1 HARNESS (TO E26)
J09	FRONT POWER WINDOW MOTOR (L)
J10	SPEAKER (PASSENGER SIDE)
J11	POWER WINDOW SUB SWITCH
J12	FRONT DOOR LOCK MOTOR (L)
REAR DOOR WIRE	
J14	No.3 HARNESS (TO L04)
J15	REAR DOOR LOCK MOTOR (R)
J16	No.3 HARNESS (TO L10)
J17	REAR DOOR LOCK MOTOR (L)
DOME LAMP WIRE	
K01	No.1 HARNESS (TO E22)
K02	INTERIOR LIGHT

8A-3-40 CONNECTOR LAYOUT DIAGRAM

L

FLOOR (RH)

L: No.3 HARNESS




CONNECTOR	CONNECTIVE POSITION
No.3 HARNESS	
L01	No.1 HARNESS (TO E44)
L02	No.2 HARNESS (TO G13)
L03	DOOR SWITCH (R)
L04	REAR DOOR WIRE (TO J14)
L06	SHIFT ILLUMINATION LIGHT
L07	PARKING SWITCH
L09	DOOR SWITCH (L)
L10	POWER WINDOW SUB WIRE (TO J16)
L11	FUEL PUMP
L12	FUEL GAUGE
L13	REAR COMBINATION LIGHT (R)
L14	HATCH DOOR HARNESS (TO O01)
L15	No.4 HARNESS (TO M01)
L17	HEATED OXYGEN SENSOR #2

8A-3-42 CONNECTOR LAYOUT DIAGRAM

L

FLOOR (LH)

L: No.3 HARNESS



CONNECTOR	CONNECTIVE POSITION
No.3 HARNESS	
L01	No.1 HARNESS (TO E44)
L02	No.2 HARNESS (TO G13)
L03	DOOR SWITCH (R)
L04	REAR DOOR WIRE (TO J14)
L06	SHIFT ILLUMINATION LIGHT
L07	PARKING SWITCH
L09	DOOR SWITCH (L)
L10	POWER WINDOW SUB WIRE (TO J16)
L11	FUEL PUMP
L12	FUEL GAUGE
L13	REAR COMBINATION LIGHT (R)
L14	HATCH DOOR HARNESS (TO O01)
L15	No.4 HARNESS (TO M01)
L17	HEATED OXYGEN SENSOR #2


8A-3-44 CONNECTOR LAYOUT DIAGRAM

M

O

REAR

M: No. 4 HARNESS
O: HATCH DOOR HARNESS



CONNECTOR	CONNECTIVE POSITION
HATCH DOOR HARNESS	
O01	No.3 HARNESS (TO L14)
O02	REAR DEFOGGER (+)
O03	REAR WIPER MOTOR
O04	HIGH MOUNTED STOP LIGHT
O05	REAR DEFOGGER (-)
No.4 HARNESS	
M01	No.3 HARNESS (TO L15)
M02	REAR FOG LIGHT (R)
M03	LICENSE PLATE LIGHT (R)
M04	LICENSE PLATE LIGHT (L)
M05	REAR FOG LIGHT (L)
M07	REAR COMBINATION LIGHT (L)

SECTION 8A-4

INSTALLATION POSITION OF SINGLE UNIT PARTS






CONTENTS

ENGINE ROOM	8A-4-2
INSTRUMENT PANEL	8A-4-4

8A-4


8A-4-2 INSTALLATION POSITIONS OF SINGLE UNIT PARTS

ENGINE ROOM (MPI)




ENGINE ROOM (MPI)



EVAP CANISTER PURGE VALVE (E33)




NOISE SUPPRESSOR (E29)




<AT> SPEED SENSOR (C23)



OXYGEN SENSOR (C07)








ECT SENSOR (C15)



8A-4-4 INSTALLATION POSITION OF SINGLE UNIT

INSTRUMENT PANEL (MPI)



SECTION 8A-5

GROUND POINT







CONTENTS

ENGINE ROOM	8A-5-2
INSTRUMENT PANEL	8A-5-3
FLOOR	8A-5-4


8A-5

8A-5-2 GROUND POINT


ENGINE ROOM




INSTRUMENT PANEL



6






7



8A-5-4 GROUND POINT

FLOOR



SECTION 8A-6

POWER SUPPLY DIAGRAM


CONTENTS

POWER SUPPLY DIAGRAM	8A-6-2
FUSES	8A-6-3

8A-6

8A-6-2 POWER SUPPLY DIAGRAM


POWER SUPPLY DIAGRAM (MPI)



FUSES

The chart below shows the circuits protected by each fuse.


FUSES IN MAIN FUSE BOX




No.	AMPERAGE	PROTECTED CIRCUIT
(1)	60A	BATTERY, 40A MAIN FUSE
(2)	40A	CIRCUIT FUSE

8A-6-4 POWER SUPPLY DIAGRAM

FUSES/CIRCUIT BRAKER IN CIRCUIT FUSE BOX (CARB)



NO.	AMPERAGE	DESCRIPTION ON THE COVER	PROTECTED CIRCUIT
③	15A	HEAD R-L	HEAD LIGHT
④	15A	HEAD R-L	COMBINATION METER HEAD LIGHT
⑤	15A	STOP DOME	DATA LINK CONNECTOR INTERIOR LIGHT BRAKE LIGHT SWITCH REAR FOG LIGHT SWITCH
⑥	15A	HAZARD. HORN	ECM HORN COMBINATION SWITCH
⑦	15A	TAIL	COMBINATION SWITCH
⑧	20A	DOOR LOCK	DOOR LOCK CONTROLLER
⑨	BLANK		
⑩	15A	IG. COIL. METER	RADIATOR FAN SWITCH NOISE SUPPRESSOR ECM GENERATOR COMBINATION METER IGNITION COIL
⑪	15A	WIPER. WASHER	COMBINATION SWITCH FRONT WIPER MOTOR REAR WIPER & WASHER SWITCH REAR WIPER MOTOR TRANSMISSION RANGE SWITCH
⑫	15A	TURN BACK	COMBINATION SWITCH
			BACK-UP LIGHT SWITCH
⑬	15A	HEATER	BLOWER FAN MOTOR CIRCUIT BREAKER
⑭	15A	REAR DEFOGGER	REAR DEFOGGER SWITCH
⑮	15A	CIGAR. RADIO	CIGAR
⑯	30A	R-DTR. FAN	RADIATOR FAN RELAY
⑰	BLANK		
⑱	30A		POWER WINDOW

FUSES/CIRCUIT BRAKER IN CIRCUIT FUSE BOX (MPI)

NO.	AMPERAGE	DESCRIPTION ON THE COVER	PROTECTED CIRCUIT
③	15A	HEAD R-L	HEAD LIGHT
④	15A	HEAD R-L	COMBINATION METER
			HEAD LIGHT
⑤	15A	STOP DOME	DATA LINK CONNECTOR
			INTERIOR LIGHT
			BRAKE LIGHT SWITCH
			REAR FOG LIGHT SWITCH
⑥	15A	HAZARD. HORN	ECM
			HORN
			COMBINATION SWITCH
⑦	15A	TAIL	COMBINATION SWITCH
⑧	20A	DOOR LOCK	DOOR LOCK CONTROLLER
⑨	15A	FI	MAIN RELAY
⑩	15A	IG. COIL. METER	IGNITER, HEATED OXYGEN SENSOR NO. 2
			NOISE SUPPRESSOR
			ECM
			GENERATOR
			COMBINATION METER
			IGNITION COIL
			FUEL PUMP RELAY
			IMMOBILIZER CONTROLLER
⑪	15A	WIPER. WASHER	COMBINATION SWITCH
			FRONT WIPER MOTOR
			REAR WIPER & WASHER SWITCH
			REAR WIPER MOTOR
			TRANSMISSION RANGE SWITCH
⑫	15A	TURN BACK	COMBINATION SWITCH
			BACK-UP LIGHT SWITCH
⑬	15A	HEATER	BLOWER FAN MOTOR
⑭	15A		CIRCUIT BREAKER
⑮	15A	REAR DEFOGGER	REAR DEFOGGER SWITCH
⑯	15A	CIGAR. RADIO	CIGAR
⑰	30A	R-DTR. FAN	RADIATOR FAN RELAY
⑲	BLANK		
⑳	30A		POWER WINDOW


SECTION 8A-7**SYSTEM CIRCUIT DIAGRAM****CONTENTS**

SYSTEM NO.	SYSTEM	PAGE NO.
A-1	CRANKING SYSTEM.....	8A-7-2
A-2	CHARGING SYSTEM	8A-7-3
A-3	IGNITION SYSTEM (MPI)	8A-7-4
A-4	IGNITION SYSTEM (CARB)	8A-7-5
A-5	COOLING SYSTEM (MPI)	8A-7-6
A-6	COLLING SYSTEM (CARB)	8A-7-7
A-7	ENGINE & AT CONTROL SYSTEM	8A-7-8
A-8	ENGINE & CARB CONTROL SYSTEM	8A-7-14
B-1	WINDSHIELD WIPER & WSHER.....	8A-7-18
B-2	REAR WIPER & WASHER	8A-7-19
B-3	REAR DEFOGGER	8A-7-20
B-4	POWER WINDOW	8A-7-22
B-5	POWER DOOR LOCK	8A-7-24
B-6	HORN	8A-7-25
C-1	COMBINATION METER (METER & GAUGE)	8A-7-26
C-2	COMBINATION METER (INDICATOR LAMP)	8A-7-27
C-3	COMBINATION METER (WARNING LAMP)	8A-7-28
D-1	HEADLIGHT SYSTEM (VEHICLE WITH DRL)	8A-7-30
D-2	HEADLIGHT SYSTEM (VEHICLE WITHOUT DRL).....	8A-7-32
D-3	POSITION, TAIL AND LICENSE PLATE LIGHT	8A-7-33
D-4	ILLUMINATION LAMP	8A-7-34
D-5	ROOM LIGHT	8A-7-35
D-6	TURN SIGNAL AND HAZARD WARNING LIGHT	8A-7-36
D-7	BRAKE LIGHT	8A-7-37
D-8	BACK-UP LIGHT (MPI)	8A-7-38
D-9	BACK-UP LIGHT (CARB)	8A-7-39
D-10	REAR FOG LIGHT	8A-7-40
E-1	HEATER SYSTEM (MPI).....	8A-7-42
E-2	HEATER SYSTEM (CARB)	8A-7-44
G-1	CLOCK	8A-7-46
G-2	CIGAR LIGHTER	8A-7-47
G-3	IMMOBILIZER CONTROL SYSTEM	8A-7-48
G-4	HEADLIGHT BEAM LEVELING SYSTEM	8A-7-49


8A-7

8A-7-2 SYSTEM CIRCUIT DIAGRAM

A-1 CRANKING SYSTEM




A-2 CHARGING SYSTEM




8A-7-4 SYSTEM CIRCUIT DIAGRAM

A-3 IGNITION SYSTEM (MPI)




8A-7-5 SYSTEM CIRCUIT DIAGRAM

A-4 IGNITION SYSTEM (CARB)




8A-7-6 SYSTEM CIRCUIT DIAGRAM

A-5 COOLING SYSTEM (MPI)






A-6 COOLING SYSTEM (CARB)



8A-7-8 SYSTEM CIRCUIT DIAGRAM


A-7 ENGINE & AT CONTROL SYSTEM 1 OF 3 (MPI)







8A-7-10 SYSTEM CIRCUIT DIAGRAM

A-7 ENGINE & AT CONTROL SYSTEM 2 OF 3 (MPI)





ECM/PCM





8A-7-12 SYSTEM CIRCUIT DIAGRAM


A-7 ENGINE & AT CONTROL SYSTEM 3 OF 3 (MPI)




MEMO

8A-7-14 SYSTEM CIRCUIT DIAGRAM

A-8 ENGINE & CARB CONTROL SYSTEM (M/T)




CARB CONTROLLER




MEMO


8A-7-16 SYSTEM CIRCUIT DIAGRAM

A-8 ENGINE & CARB CONTROL SYSTEM (A/T)




CARB CONTROLLER






8A-7-18 SYSTEM CIRCUIT DIAGRAM


B-1 WINDSHIELD WIPER & WASHER



B-2 REAR WIPER & WASHER

8A-7-20 SYSTEM CIRCUIT DIAGRAM


B-3 REAR DEFOGGER




MEMO

8A-7-22 SYSTEM CIRCUIT DIAGRAM


B-4 POWER WINDOW






8A-7-24 SYSTEM CIRCUIT DIAGRAM

B-5 POWER DOOR LOCK




B-6 HORN




8A-7-26 SYSTEM CIRCUIT DIAGRAM

C-1 COMBINATION METER (METER GAUGE)




C-2 COMBINATION METER (INDICATOR LAMP)



8A-7-28 SYSTEM CIRCUIT DIAGRAM


C-3 COMBINATION METER (WARNING LAMP)




MEMO

8A-7-30 SYSTEM CIRCUIT DIAGRAM


D-1 HEADLIGHT SYSTEM (VEHICLE WITH DRL)






8A-7-32 SYSTEM CIRCUIT DIAGRAM

D-2 HEADLIGHT SYSTEM (VEHICLE WITHOUT DRL)




D-3 POSITION, TAIL AND LICENSE PLATE LIGHT




8A-7-34 SYSTEM CIRCUIT DIAGRAM

D-4 ILLUMINATION LAMP





D-5 ROOM LIGHT



8A-7-36 SYSTEM CIRCUIT DIAGRAM


D-6 TURN SIGNAL AND HAZARD WARNING LIGHT




D-7 BRAKE LIGHT

8A-7-38 SYSTEM CIRCUIT DIAGRAM

D-8 BACK-UP (MPI)




D-9 BACK-UP LIGHT (CARB)



8A-7-40 SYSTEM CIRCUIT DIAGRAM


D-10 REAR FOG LIGHT




MEMO

8A-7-42 SYSTEM CIRCUIT DIAGRAM


E-1 HEATER SYSTEM (MPI)






8A-7-44 SYSTEM CIRCUIT DIAGRAM


E-2 HEATER SYSTEM (CARB)






8A-7-46 SYSTEM CIRCUIT DIAGRAM


G-1 CLOCK




G-2 CIGAR LIGHTER



G-3 IMMOBILIZER CONTROL SYSTEM



G-4 HEADLIGHT BEAM LEVELING SYSTEM



SECTION 8A-8

LIST OF CONNECTORS

CONTENTS

B : B01-B08	8A-8-2
C: C01-C35	8A-8-2
E : E01-E19	8A-8-2
E20-E76	8A-8-3
G: G01-G09	8A-8-3
G10-G20	8A-8-4
J : J01-J17	8A-8-4
K: K01-K02	8A-8-4
L : L01-L18	8A-8-4
M: M01-M07	8A-8-4
O: O01-O05	8A-8-5
	8A-8

B C E

LIST OF CONNECTORS

B	B01 	B02 	B03 	B04 	B05 (TO E56) 	B06 	B07 	B08 		
C	C01 	C02 	C03 	C04 	C05 	C06 	C07 	C09 	C10 	C11
	C12 	C13 	C14 	C15 	C17 	C18 	C19 	C20 (TO E13) 	C21 (TO E14) 	C22 (TO E16)
	C23 	C24 	C25 	C26 (TO E15) 	C27 (TO E15) 	C28 (TO E69) 	C29 	C30 	C31 	C32
		C34 	C35 	C36 						
E	E01 	E02 	E03 	E04 	E05 	E07 	E06 			
	E10 	E11 	E12 	E13 (TO C20) 	E14 (TO C21) 	E15 (TO C27) 	E16 (TO C22) 	E17 (TO C26) 	E18 	E19

E G

E	E20 	E21 	E22 (TO K01) 	E23 	E24 	E25 	E26 (TO J08) 	E27 (TO J07) 	E28 	E29
	E30 	E31 	E32 	E33 	E34 	E35 	E36 20 19 18 17 16 15 14 13 12 11	E37 	E39 	
	E41 	E42 	E43 	E44 (TOL01) 	E45 (TO G14) 	E46 (TO G15) 	E47 	E48 	E49 	
	E51 	E52 (TO J01) 	E53 (TO J02) 	E54 	E55 	E56 (TO B05) 	E57 	E59 	E60 	E61
	E62 	E63 	E64 	E65 	E66 	E67 	E68 	E69 (TO C28) 	E70 	E71
	E72 	E73 	E74 	E75 	E76 					
	G01 	G02 	G03 	G04 	G05 	G06 	G08 	G09 		

LIST OF CONNECTORS 8A-8-4

G J K L M

G	G11 	G13 (TO L02) 	G14 (TO E45) 	G15 (TO E46) 	G16 	G17 	G18 	G19 	G20 	
J	J01 (TO E52) 	J02 (TO E53) 	J03 	J04 	J05 	J06 	J07 (TO E27) 	J08 (TO E26) 	J09 	J10
	J11 	J12 	J14 (TO L04) 	J15 	J16 (TO L10) 	J17 				
K	K01 (TO E22) 	K02 								
L	L01 (TO E44) 	L02 (TO G13) 	L03 	L04 (TO J14) 	L06 	L07 	L09 	L10 (TO J16) 	L11 	L12
	L13 	L14 (TO O01) 	L15 (TO M01) 	L16 	L17 					
M	M01 (TO L15) 	M02 	M03 	M04 	M05 	M06 	M07 			

Prepared by

MARUTI UDYOG LIMITED

Service Division

March, 2001

Part No. 99512M70F10-02E

Printed in India



SUZUKI MOTOR CORPORATION