

SUZUKI

SV620

SUPPLEMENTARY SERVICE MANUAL FOR VEHICLE WITH IGNITER INCORPORATED TYPE IGNITION COIL

USE THIS MANUAL WITH:
SV620 SERVICE MANUAL (99500-85F00)

SUZUKI
Caring for Customers

99501-85F20-01E
(英)

IMPORTANT

WARNING/CAUTION/NOTE

Please read this manual and follow its instructions carefully. To emphasize special information, the words **WARNING**, **CAUTION** and **NOTE** have special meanings. Pay special attention to the messages highlighted by these signal words.

WARNING:

Indicates a potential hazard that could result in death or injury.

CAUTION:

Indicates a potential hazard that could result in vehicle damage.

NOTE:

Indicates special information to make maintenance easier or instructions clearer.

FOREWORD

This SUPPLEMENTARY SERVICE MANUAL is a supplement to SV620 SERVICE MANUAL (99500-85F00).

Applicable model:

SV620 vehicles on and after following body No.

GROUP 1

(x) JSAETD11V00150001 (x) ~

and applicable model of GROUP 2

GROUP 2

(x) JSAETD11V00200001 (x) ~

TD11V-200001 ~

Therefore, whenever servicing applicable model of GROUP 2, consult GROUP 2 in this supplement first. And for any section, item or description not found in GROUP 2, refer to GROUP 1 and then "SV620 SERVICE MANUAL (99500-85F00)".

Also, when servicing applicable model of GROUP 1, consult GROUP 1 in this manual first. And for any section, item or description not found in GROUP 1, refer to "SV 620 SERVICE MANUAL (99500-85F00)".

When replacing parts or servicing by disassembling, it is recommended to use SUZUKI genuine parts, tools and service materials (lubricants, sealants, etc.) as specified in each description.

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others. Therefore, note that illustrations may differ from the vehicle being actually serviced. The right is reserved to make changes at any time without notice.

SUZUKI MOTOR CORPORATION

OVERSEAS SERVICE DEPARTMENT

TABLE OF CONTENTS	SECTION
ENGINE	GROUP 1
Electronic Fuel Injection System (Sequential Multiport Fuel Injection for H20A Type Engine) Ignition System (Direct Ignition Type)	
TRANS, AND CLUCH	GROUP 2
Automatic Transmission	

RELATED SERVICE MANUAL

- SV620 SERVICE MANUAL (99500-85F00)
- VITARA SERVICE MANUAL (99500-60A10)
- VITARA SUPPLIMENTARY SERVICE MANUAL (99501-60A70)
- VITARA SUPPLIMENTARY SERVICE MANUAL (99501-61A10)
- SE/SV/SZ/SY SERIES SUPPLEMENTARY SERVICE MANUAL (99501-60G10)

6E2

6F2

7B1

GROUP2

ABBREVIATIONS USED IN THIS MANUAL

A. ABS	: Anti-lock Brake System
A/C	: Air Conditioning
A/F	: Air Fuel mixture ratio
A/T	: Automatic Transmission
B. B+	: Battery Voltage
C. CMP sensor	: Camshaft Position Sensor
CPU	: Central Processing Unit
CTP switch	: Closed Throttle Position switch
D. DLC	: Data Link Connector
E. ECM	: Engine Control Module
ECT sensor	: Engine Coolant Temp. sensor
EGR	: Exhaust Gas Recirculation
EVAP	: Evaporative Emission
F. 4WD	: Four Wheel Drive
G. GND	: Ground
I. IAC valve	: Idle Air Control valve
IAT sensor	: Intake Air Temp. sensor
IC	: Ignition Control
M. MAF sensor	: Mass Air Flow sensor
MAP sensor	: Manifold Absolute Pressure sensor
MIL	: Malfunction Indicator Lamp
M/T	: Manual Transmission
O. O/D	: Over Drive
P. PCM	: Powertrain Control Module
PCV valve	: Positive Crankcase Ventilation valve
PSP switch	: Power Steering Pressure switch
T. TCC	: Torque Converter Clutch
TCM	: Transmission Control Module
TP sensor	: Throttle Position sensor
V. VSS	: Vehicle Speed Sensor

SECTION 6E2

ELECTRONIC FUEL INJECTION SYSTEM

(SEQUENTIAL MULTIPOINT FUEL INJECTION FOR H20A TYPE ENGINE)

NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of SV620 service manual.

CONTENTS

GENERAL DESCRIPTION	6E2- 2	Code No.22 TP Sensor Circuit	6E2-26
ELECTRONIC CONTROL SYSTEM	6E2- 6	Code No.23 IAT Sensor Circuit	6E2-27
Engine Control Module (ECM)	6E2-10	Code No.25 IAT Sensor Circuit	6E2-28
Throttle Position Sensor		Code No.24 VSS Circuit	6E2-29
(TP Sensor)	6E2-12	Code No.33 MAF Sensor Circuit	6E2-30
Engine Coolant Temperature		Code No.34 MAF Sensor Circuit	6E2-31
Sensor (ECT Sensor)	6E2-12	Code No.42 CMP Sensor Circuit	6E2-32
IC (Ignition Control) System	6E2-13	Code No.51 EGR Valve Circuit	
DIAGNOSIS	6E2-14	(if equipped)	6E2-33
Precautions in Diagnosing		Code No.52 Fuel System	
Troubles	6E2-14	(Vehicle with Heated Oxygen Sensor	
DIAGNOSTIC FLOW CHART	6E2-15	Only)	6E2-34
Diagnostic Trouble Code Table	6E2-16	B-1 Fuel Pump Circuit Check	6E2-35
A-1 ECM Power and Ground		B-2 Fuel Injector Circuit Check	6E2-36
Circuit Check	6E2-18	B-3 Fuel Pressure Check	6E2-38
A-2 Malfunction Indicator Lamp		B-4 Idle Air Control System Check	6E2-40
("CHECK ENGINE" Light)		B-5 EGR System Check (if equipped) ...	6E2-42
Circuit Check	6E2-20	B-6 Evaporative Emission Control	
A-3 Malfunction Indicator Lamp		System Check	6E2-43
("CHECK ENGINE" Light)		Inspection of ECM and Its Circuit	6E2-44
Circuit Check	6E2-21	Voltage Check	6E2-44
Code No.13 Left Bank Heated Oxygen		Resistance Check	6E2-52
Sensor Circuit and/or		ON VEHICLE SERVICE	6E2-54
Code No.26 Right Bank Heated Oxygen		ELECTRONIC CONTROL SYSTEM	6E2-54
Sensor Circuit (if equipped)	6E2-22	MAF Sensor (Inspection)	6E2-54
Code No.14 ECT Sensor Circuit	6E2-23	TP Sensor (Inspection, Adjustment)	6E2-55
Code No.15 ECT Sensor Circuit	6E2-24	Heated Oxygen Sensor (Sensor	
Code No.21 TP Sensor Circuit	6E2-25	Inspection)	6E2-57

GENERAL DESCRIPTION

The Electronic Fuel Injection System in this vehicle supplies the combustion chambers with air/fuel mixture of optimized ratio under widely varying driving conditions.

It uses the sequential multiport fuel injection system which injects fuel into each intake port of the cylinder head.

This system has 3 major sub-systems: air intake system, fuel delivery system and electronic control system.


Air intake system includes air cleaner, mass air flow sensor, throttle body, fast idle control system, idle air control valve and intake manifold. Fuel delivery system includes fuel pump, delivery pipe, fuel pressure regulator, etc.

Electronic control system includes ECM, various sensors and controlled devices.

This section explains the system related to the electronic fuel injection as well as such functions of ECM as listed below.

- EGR system. (if equipped)
- Evaporative emission control system.
- IC (Ignition Control) system.

- memo -



1. Air cleaner
2. IAT sensor
3. MAF sensor
4. TP sensor
5. IAC valve
6. Idle speed adjusting screw
7. Throttle body
8. Intake manifold
9. Fuel injector
10. PCV valve
11. Ignition coil with ignitor
12. ECT sensor
13. Heated oxygen sensor
(Right bank : bank 2), if equipped
14. Heated oxygen sensor
(Left bank : bank 1), if equipped
15. Three way catalytic converter (if equipped)
- 15-1. Warm up three way catalytic
converter (if equipped)
16. EVAP canister purge valve
17. EVAP canister
18. Tank pressure control valve
19. Fuel pressure regulator
20. Fuel feed line
21. Fuel return line
22. Fuel filter
23. Fuel pump
24. Fuel tank
25. Transmission range switch (A/T)
26. Shift solenoid valve A (A/T)
27. Shift solenoid valve B (A/T)
28. TCC solenoid valve (A/T)
29. A/C amplifier (if equipped)
30. CMP sensor
31. VSS (in speedometer)
32. PSP switch
33. Lighting switch (A/T)
34. Brake switch (A/T)
35. Mode selector switch (A/T)
36. O/D cut switch (A/T)
37. 4WD low switch (A/T)
38. Diagnosis switch terminal
39. Test switch terminal
40. Malfunction indicator lamp
("CHECK ENGINE" light)
41. "OD/OFF" light (A/T)
42. "POWER" light (A/T)
43. EGR valve
44. Starter magnetic switch
45. Transmission range switch (A/T)
46. Ignition switch
47. Main fuse
48. ECM
49. Battery


ELECTRONIC CONTROL SYSTEM

The electronic control system consists of 1) various sensors which detect the state of engine and driving conditions, 2) ECM which controls various devices according to the signals from the sensors and 3) various controlled devices. Functionally, it is divided into the following sub systems:

- Fuel injection control system

- Heated oxygen sensor heater control system
- Idle air control system
- Fuel pump control system
- Evaporative emission control system
- IC (Ignition Control) system
- EGR system

Also, with A/T model, ECM controls A/T.



NOTE:

Above figure shows left-hand steering vehicle. For right hand steering vehicle, parts with (*) are installed at the other side.

INFORMATION SENSORS


1. MAF sensor
2. IAT sensor
3. Heated oxygen sensor (if equipped)
4. ECT sensor
5. Battery
6. TP sensor
7. Camshaft position sensor (CMP sensor)
8. VSS (in speedometer) (*)
9. CO adjusting resistor (*) (vehicle without heated oxygen sensor only)

CONTROLLED DEVICES

- a: Fuel pump relay
- b: Injector
- c: EGR valve (if equipped)
- d: EVAP canister purge valve
- e: Idle air control valve
- f: Ignition coil (with igniter)
- g: Malfunction indicator lamp (*) ("CHECK ENGINE" light)


OTHERS

- A: ECM (*)
- B: Main relay
- C: Fuse box (*)
- D: EVAP canister
- E: Monitor coupler (*)
- F: Data link connector (*) (Assembly line diag. link)



1. No.1 injector
2. No.2 injector
3. No.3 injector
4. No.4 injector
5. No.5 injector
6. No.6 injector
7. IAC valve
8. EGR valve (stepper motor) (if equipped)
9. EVAP canister purge valve
10. Fuel pump relay
11. Fuel pump
12. To tachometer
13. Malfunction indicator lamp ("CHECK ENGINE" light)
14. Monitor coupler
- 14-1. Diagnosis output terminal
- 14-2. Diagnosis switch terminal
- 14-3. Test switch terminal
- 14-4. Duty output terminal
- 14-5. A/F duty (Right bank, B2) output terminal
- 14-6. Ground terminal
15. To immobilizer (if equipped)
16. To DLC
17. A/C amplifier (if equipped)
18. No.1 ignition coil (with ignitor)
19. No.2 ignition coil (with ignitor)
20. No.3 ignition coil (with ignitor)
21. No.4 ignition coil (with ignitor)
22. No.5 ignition coil (with ignitor)
23. No.6 ignition coil (with ignitor)
24. "OD/OFF" light (A/T vehicle)
25. "POWER" light (A/T vehicle)
26. Shift solenoid valve A (A/T vehicle)
27. Shift solenoid valve B (A/T vehicle)
28. TCC solenoid valve (A/T vehicle)
29. Transmission range switch (A/T vehicle)
30. 4WD low switch (A/T vehicle)
31. O/D cut switch (A/T vehicle)
32. Mode selector switch (A/T vehicle)
33. Brake light switch
34. Lighting switch
35. Vehicle speed sensor (in A/T)
36. Power steering pressure switch
37. Blower fan switch
38. Rear defogger switch
39. Electric load diodes
40. CO adjusting resistor (Vehicle without heated oxygen sensor only)
41. Vehicle speed sensor (in speedometer)
42. CMP sensor
43. IAT sensor
44. Heated oxygen sensor (right bank, if equipped)
45. Heated oxygen sensor (left bank, if equipped)
46. TP sensor
47. ECT sensor
48. MAF sensor
49. Main relay
50. Starter magnetic switch
51. Transmission range switch (A/T vehicle)
52. Ignition switch
53. Battery positive terminal

TER-MINAL	POSITION		CIRCUIT	TER-MINAL	POSITION		CIRCUIT
	M/T	A/T			M/T	A/T	
BB	B11	A19	Power source for back-up	IGN 1	D4	C14	No.1 ignitor (ignition coil)
B	D1	A1	Power source	IGN 2	D7	C15	No.2 ignitor (ignition coil)
	D12	A9		IGN 3	D2	A25	No.3 ignitor (ignition coil)
IGS	-	D1	Ignition switch	IGN 4	D5	A12	No.4 ignitor (ignition coil)
	B7	-	Ignition switch (with immobilizer)	IGN 5	D6	A10	No.5 ignitor (ignition coil)
	C7	-	Ignition switch (without immobilizer)	IGN 6	D3	A11	No.6 ignitor (ignition coil)
SOF	D20	A22	Main relay	EGR 1	C2	D5	EGR valve (stepper motor coil 1, if equipped)
ECUG	D10	A24	Ground	EGR 2	C3	D14	EGR valve (stepper motor coil 2, if equipped)
	D22	A33		EGR 3	C4	D12	EGR valve (stepper motor coil 3, if equipped)
POW G	A13	D18	Ground	EGR 4	C5	D13	EGR valve (stepper motor coil 4, if equipped)
	A26	D22		VCC	A7	D9	Power source for sensors
IGNG	D11	A2	Power source for sensors	ISC	A16	D20	IAC valve
VCC	A7	D9		SE	A20	D21	Sensor ground
SE	A20	D21	Sensor ground	PRG	A4	D2	EVAP canister purge valve
	B8	D22		VTA	A23	D23	Throttle position sensor
VTA	A23	D23	Throttle position sensor	OXH 1	A3	D8	Heated oxygen sensor heater (left bank, if equipped)
THW	A19	D15	ECT sensor	OXH 2	D21	C5	Heated oxygen sensor heater (right bank, if equipped)
AFM	A24	D24	MAF sensor	FP	D9	A20	Fuel pump relay
POS	A8	D16	CMP sensor POSITION signal (with immobilizer)	TACHO	B15	A7	Tachometer
	A9	D17		ACS	B13	A30	A/C amplifier (if equipped)
REF	A10	D25	CMP sensor POSITION signal (without immobilizer)	AF	B9	C8	A/F duty output terminal (right bank)
	A11	D26		DNL	D15	A5	Diagnosis output terminal and MIL ("CHECK ENGINE" light)
SPD	A10	D25	CMP sensor REFERENCE signal (with immobilizer)	DN	B12	A29	Diagnosis switch terminal
	A11	D26		TS	B4	A16	Test switch terminal
STA	B5	A32	Vehicle speed sensor (in speedometer)	MON	D13	A35	Duty output terminal
SPD	B5	A32	Vehicle speed sensor (in speedometer)	SDL	D18	A34	Data link connector
STA	A6	D3		Engine start switch	R	-	A4
PSS	A5	D10	Power steering pressure switch	N	-	A26	N range signal
EL	B3	A17	Electric load signal diodes	D	-	A15	D range signal
THA	A21	D11	Intake air temp. sensor	2	-	A13	2 range signal
OX1	A22	D4	Heated oxygen sensor 1 (left bank, if equipped)	L	-	C11	L range signal
CO	A22	D4	CO adjusting resistor (vehicle without heated oxygen sensor only)	SP	-	C2	A/T vehicle speed sensor (+)
				SPG	-	C1	A/T vehicle speed sensor (-)
OX2	C1	C9	Heated oxygen sensor 2 (right bank, if equipped)	OD	-	A18	O/D cut switch
INJ 1	A1	D28	No.1 injector	LIGHT	-	A3	Lighting switch
INJ 2	A2	D19	No.2 injector	L4	-	A14	4WD low switch
INJ 3	A14	D7	No.3 injector	PWR	-	A31	Mode selector switch
INJ 4	A15	D6	No.4 injector	BK	-	A28	Brake switch
INJ 5	A12	C20	No.5 injector	S1	-	C12	Shift solenoid valve A
INJ 6	A25	C13	No.6 injector	S2	-	C4	Shift solenoid valve B
				S3	-	C3	TCC solenoid valve
				ODL	-	A21	"OD/OFF" light
				PWL	-	A6	"POWER" light



1. ECM
2. Instrument main panel
3. Steering wheel

Engine Control Module (ECM)

ECM is installed to the underside of the instrument panel at the driver's seat side.

ECM is a precision unit consisting of microcomputer, A/D (Analog/Digital) converter, I/O (Input/Output) unit, etc..

It is an essential part of the electronic control system, for its functions include not only such a major function as to control fuel injector, idle air control valve, fuel pump relay, etc. but also on-board diagnostic system (self-diagnosis function) and fail-safe function as described in the following section.

On-board diagnostic system (Self-diagnosis function)


ECM diagnoses troubles which may occur in the areas including the following parts when the ignition switch is ON or the engine is running, and indicates the result by turning on or flashing malfunction indicator lamp ("CHECK ENGINE" light).

- Heated oxygen sensors (Left and right bank, if equipped)
- Intake air temp. sensor
- Engine coolant temp. sensor
- Throttle position sensor
- Vehicle speed sensor
- Mass air flow sensor
- Camshaft position sensor
- EGR stepper motor (if equipped)
- Fuel system (vehicle with heated oxygen sensor)
- CPU (Central Processing Unit) of ECM

ECM and malfunction indicator lamp ("CHECK ENGINE" light) operate as follows.

- Malfunction indicator lamp ("CHECK ENGINE" light) lights when the ignition switch is turned ON (but the engine at stop) with the diagnosis switch terminal ungrounded regardless of the condition of Electronic Fuel Injection system. This is only to check the malfunction indicator lamp ("CHECK ENGINE" light) bulb and its circuit.
- If the above areas of Electronic Fuel Injection system is free from any trouble after the engine start (while engine is running), malfunction indicator lamp ("CHECK ENGINE" light) turns OFF.
- When ECM detects a trouble which has occurred in the above areas, it makes malfunction indicator lamp ("CHECK ENGINE" light) turn ON while the engine is running to warn the driver of such occurrence of trouble and at the same time it stores the exact trouble area in ECM back-up memory.

(The memory is kept as it is even if the trouble was only temporary and disappeared immediately. And it is not erased unless the power to ECM is shut off for 2 minutes or longer.) ECM also indicates trouble area in memory by means of flashing of malfunction indicator lamp ("CHECK ENGINE" light) at the time of inspection (i.e. when diagnosis switch terminal is grounded and ignition switch is turned ON).



1. Malfunction indicator lamp ("CHECK ENGINE" light)
2. Cluster
3. Diagnosis switch terminal
4. Monitor coupler
5. ECM
6. Sensed information
7. Output
8. Main relay
9. Ignition switch


NOTE:

- **Even when a trouble occurs in CMP sensor circuit (circuit open), ECM does not indicate it (or activate malfunction indicator lamp (“CHECK ENGINE” light)).**
And when that troubled circuit regains good condition, the memory of defective area will be erased automatically even if the power circuit to ECM is not opened as described above.
- **For on-board diagnostic system and fail-safe function of A/T related parts, refer to On-Board Diagnostic System in section 7B1.**

Fail-safe function

Even when a trouble has occurred in such areas of Electronic Fuel Injection system that include the following parts and a failure signal is sent to ECM, control over the injector, idle air control valve and other is maintained on the basis of the standard signals and/or back-up program prestored in the ECM while ignoring that failure signal and/or CPU. This function is called “fail-safe function”. Thus, with this function, a certain level of engine performance is available even when some failure occurs in such areas so that disability in running is avoided.

- Engine coolant temp. sensor
- Intake air temp. sensor
- Throttle position sensor
- Mass air flow sensor
- EGR stepper motor (if equipped)
- CPU in ECM



Throttle Position Sensor (TP Sensor)

The throttle position sensor consisting of a potentiometer is installed on the throttle body, and detects the throttle valve opening.

A 5-volt reference voltage is applied to the sensor from ECM and as its brush moves over the print resistance according to the throttle valve opening, the output voltage varies accordingly.

By monitoring the sensor output voltage, ECM detects the throttle valve opening.

ECM uses the signal from TP sensor as one of the signals to control fuel injector, idle air control valve, ignition timing, EVAP canister purge valve, EGR valve (if equipped).


Also for A/T model, ECM controls the automatic transmission.

Engine Coolant Temperature Sensor (ECT Sensor)

Incorporated with engine coolant temp. gauge and located at the water outlet pipe, this sensor measures the temperature of the engine coolant and converts its change into that in resistance through the thermister.

By monitoring the resistance of the coolant temperature sensor, ECM detects the engine coolant temperature and that affects most systems under the control of ECM.

Also for A/T model, ECM control the automatic transmission (TCC operation and gear shift to O/D gear).



IC (IGNITION CONTROL) SYSTEM


This system controls electronically the time of electric current flow to ignition primary coils as well as ignition timing.

ECM judges the engine condition by using signals from various sensors, selects the most suitable electric current flow time and ignition timing for that engine condition from among those prestored in its memory and sends an ignition signal to the igniter.

The igniter (in ignition coil) turns ON and OFF the primary current of the ignition coils according to the signal from ECM.


Control of the system includes three different types as follows.

- Ignition timing control at engine start
- Ignition timing control after engine start
- Electric current flow time control




1. ECM
2. To ignition switch
3. Igniter (in ignition coil)
4. Spark plug

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)



6E2-144



6E2-145

DIAGNOSIS

ECM has on-board diagnostic system (a system self-diagnosis function) as described previously (p. 6E2-10). Investigate where the trouble is by referring to "DIAGNOSTIC FLOW CHART" and "DIAGNOSTIC TROUBLE CODE TABLE" on later pages.


NOTE:

For diagnosis of A/T related part detected by ECM, refer to **DIAGNOSIS** in section 7B1.

PRECAUTIONS IN DIAGNOSING TROUBLES

[PRECAUTIONS IN IDENTIFYING DIAGNOSTIC TROUBLE CODE]


- Before identifying diagnostic trouble code indicated by malfunction indicator lamp ("CHECK ENGINE" light), don't disconnect couplers from ECM, battery cable from battery, ECM ground wire harness from engine. Such disconnection will erase memorized trouble in ECM memory
- If abnormality or malfunction lies in two or more areas, malfunction indicator lamp ("CHECK ENGINE" light) indicates applicable codes three times each. And flashing of these codes is repeated as long as diagnosis terminal is grounded and ignition switch is held at ON position.
- Take a note of diagnostic trouble code indicated first.



6E2-012

6E2-013


DIAGNOSTIC FLOW CHART



DIAGNOSTIC TROUBLE CODE TABLE (1 OF 2, M/T AND A/T)

EXAMPLE :When throttle position sensor is defective (Code No.21)









Malfunction indicator lamp ("CHECK ENGINE" light) ON



6E2-016

DIAGNOSTIC TROUBLE CODE NO.	MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) FLASHING PATTERN	DIAGNOSTIC ITEM	DIAGNOSIS
13	6E2-017	Left bank heated oxygen sensor (if equipped)	Diagnose trouble according to "DIAGNOSTIC FLOW CHART" corresponding to each code No.
26	6E2-018	Right bank heated oxygen sensor (if equipped)	
14	6E2-019	Engine coolant temperature sensor	
15	6E2-020		
21	6E2-021	Throttle position sensor	
22	6E2-022		
23	6E2-023	Intake air temperature sensor	
25	6E2-024		
24	6E2-025	Vehicle speed sensor	
33	6E2-026	Mass air flow sensor	
34	6E2-027		
42	6E2-029	Camshaft position sensor	
51	6E2-030	EGR valve (stepper motor, if equipped)	
52	6E2-031	Fuel system (vehicle with heated oxygen sensor only)	
ON	6E2-032	ECM	
12	6E2-033	Normal	This code appears when none of the other codes (above codes) are identified.


DIAGNOSTIC TROUBLE CODE TABLE (2 OF 2, A/T ONLY)

DIAGNOSTIC TROUBLE CODE NO.	MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) FLASHING PATTERN	DIAGNOSTIC ITEM	DIAGNOSIS
61	 6E2-034	Shift solenoid A	Refer to section 7B1
62	 6E2-03		
63	 6E2-036	Shift solenoid B	
64	 6E2-037		
65	 6E2-038	TCC solenoid	
66	 6E2-039		
72	 6E2-040	Transmission range switch	
75	 6E2-041	A/T VSS	

A-1 ECM POWER AND GROUND CIRCUIT CHECK


(MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) DOESN'T LIGHT AT IGNITION SWITCH ON AND ENGINE DOESN'T START THOUGH IT IS CRANKED UP.)

1. Main fuse
2. Ignition switch
3. Circuit fuse for ignition coil
4. Circuit fuse for ECM
5. Main relay
6. ECM
7. Engine ground for ECM
8. Terminal position of relay coupler (viewed from wire side)




TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)


6E2-042




6E2-043




6E2-044





A-2 MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) CIRCUIT CHECK


(MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) DOESN'T LIGHT AT IGNITION SWITCH ON THOUGH ENGINE STARTS.)




1. Main fuse
2. Ignition switch
3. Circuit fuse
4. Malfunction indicator lamp ("CHECK ENGINE" light) bulb
5. ECM
6. Combination meter

6E2-045


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)




6E2-047



6E2-046




A-3 MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) CIRCUIT CHECK
 (MALFUNCTION INDICATOR LAMP ("CHECK ENGINE" LIGHT) DOESN'T FLASH JUST REMAINS ON EVEN WITH GROUNDING DIAGNOSIS SWITCH TERMINAL.)




6E2-048


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)




6E2-049



6E2-050



**CODE NO.13 LEFT BANK HEATED OXYGEN SENSOR CIRCUIT AND/OR
CODE NO.26 RIGHT BANK HEATED OXYGEN SENSOR CIRCUIT (IF EQUIPPED)**




1. Remove ECM and connect couplers to ECM.
2. Warm up engine to normal operating temperature.
3. Connect voltmeter between OX1 (left bank, code No.13) or OX2 (right bank, code No.26) of ECM coupler and body ground.
4. Maintain engine speed at 2,000 r/min. After 60 seconds, check voltmeter.

```

    graph TD
        Start[1. Remove ECM and connect couplers to ECM.  
2. Warm up engine to normal operating temperature.  
3. Connect voltmeter between OX1 (left bank, code No.13) or OX2 (right bank, code No.26) of ECM coupler and body ground.  
4. Maintain engine speed at 2,000 r/min. After 60 seconds, check voltmeter.] --> Decision1{Remains unchanged at below 0.45 V.}
        Decision1 --> Step2[1. Maintain engine speed at 2,000 r/min for 60 sec.  
2. Check voltmeter while repeating racing engine. Does it indicate 0.45 V or more even once?]
        Step2 -- NO --> Action1[Replace heated oxygen sensor and recheck.]
        Step2 -- YES --> Action2[Poor OX1 or OX2 connection of ECM coupler or lean A/F mixture. Check MAF sensor, ECT sensor, fuel pressure, injectors and their circuit. If all above are OK, check ECM and its circuit referring to p. 6E2-44.]
        Decision1 --> Decision2{Deflects between above and below 0.45 V repeatedly}
        Decision2 --> Action3[Heated oxygen sensor and its circuit (closea roop system, Air/fuel ratio feed back system) are in good condition. Intermittent trouble or faulty ECM. Rereck referring to Intermittent trouble.]
    
```

CODE NO.14 ECT SENSOR (ENGINE COOLANT TEMP. SENSOR) CIRCUIT

(LOW TEMPERATURE INDICATED, SIGNAL VOLTAGE HIGH)




- 1. ECM
- 2. ECT sensor
- 3. Coupler
- 4. ECM coupler
- 5. To other sensors


NOTE:
When Code Nos. 13, 14, 21, 23, 26 and 33 are indicated together, it is possible that "Gr/Y" wire is open or SE terminal connections are poor.

6E2-054

TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)




6E2-055



6E2-056

1. Disconnect ECT sensor coupler with ignition switch OFF.
2. With ignition switch ON, check voltage at "R/Y" wire terminals of ECT sensor coupler. Is it about 4 - 5 V?



6E2-057


- 1. ECT sensor coupler disconnected
- 2. Engine ground

YES

NO

1. Using service wire, connect ECT sensor coupler terminals.
2. Check voltage at "R/Y" wire terminal of ECT sensor coupler with ignition switch ON. Is it below 0.15V?

"R/Y" wire open, poor THW connection or "R/Y" wire shorted to power circuit. If wire and connection are OK, substitute a known-good ECM and recheck.



6E2-058

- 1. ECT sensor coupler disconnected
- 2. Service wire
- 3. Engine ground

NO


YES

"Gr/Y" wire open or poor SE connection. If wire and connection are OK, faulty ECM. Substitute a known-good ECM and recheck.


Poor ECT sensor-to-coupler connection of faulty ECT sensor. If connection and ECT sensor are OK, intermittent trouble or faulty ECM. Recheck referring to Intermittent trouble.

CODE NO.15 ECT SENSOR (ENGINE COOLANT TEMP. SENSOR) CIRCUIT

(HIGH TEMPERATURE INDICATED, SIGNAL CIRCUIT VOLTAGE LOW)



1. Disconnect ECT sensor coupler with ignition switch OFF.
2. With ignition switch ON, is voltage applied to "R/Y" wire terminals of ECT sensor coupler 4V or more?



YES

NO

Check ECT sensor. Is it in good condition?

"R/Y" wire shorted to "Gr/Y" wire or ground circuit. If wire is OK, substitute a known-good ECM and recheck.


YES

NO

Intermittent trouble or faulty ECM. Recheck referring to Intermittent trouble.

Faulty ECT sensor.

CODE NO.21 TP SENSOR (THROTTLE POSITION SENSOR) CIRCUIT (SIGNAL VOLTAGE HIGH)




1. ECM
2. TP sensor
3. Coupler
4. ECM coupler
5. To other sensors
6. To CO adjusting resistor (if equipped)

6E2-063


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)

A/T Vehicle



6E2-064

M/T Vehicle



6E2-065

1. Disconnect TP sensor coupler with ignition switch OFF.
2. Check voltage between "Gr/R" wire terminal and "Gr/Y" wire terminal of disconnected TP sensor coupler with ignition switch ON.
3. Is it about 4 - 5V?

YES

NO

1. Connect TP sensor coupler with ignition switch OFF.
2. Remove ECM and connect ECM couplers with ignition switch OFF.
3. Check voltage between VTA terminal and body ground with ignition switch ON.

"Gr/Y" with open, poor SE connections, or "Gr/R" wire shorted to power circuit.

VTA terminal voltage is:
 0.50 ± 0.15 V at throttle valve is fully close
 4.0 ± 0.5 V at throttle valve is fully open.

Poor VTA connection.
 If connection is OK, substitute a known good ECM and recheck.


VTA terminal voltage is about 4 - 5 V.

"Gr" wire open or shorted to "Gr/R" wire circuit or poor TP sensor coupler connection.

Other

Maladjusted TP sensor or faulty TP sensor.

CODE NO.22 TP SENSOR (THROTTLE POSITION SENSOR) CIRCUIT (SIGNAL VOLTAGE LOW)




1. ECM
2. TP sensor
3. Coupler
4. ECM coupler
5. To other sensors
6. To CO adjusting resistor (if equipped)

6E2-066


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)

A/T Vehicle




6E2-067

M/T Vehicle



6E2-068

1. Disconnect TP sensor coupler with ignition switch OFF.
2. With ignition switch ON, is voltage applied to "Gr/R" wire terminal of TP sensor coupler about 4 - 5V?



6E2-069

1. TP sensor coupler disconnected
2. Engine ground
3. "Gr/R" wire terminal

YES

NO

Check TP sensor referring to p. 6E2-55. Is it in good condition?

"Gr/R" wire open, "Gr/R" wire shorted to ground circuit or "Gr/Y" wire, or poor VCC connection. If wire and connection are OK, substitute a known-good ECM and recheck.


YES

NO

Intermittent trouble or faulty ECM. Recheck referring to Intermittent trouble.

Poor TP sensor coupler connection or faulty TP sensor.

CODE NO.23 IAT (INTAKE AIR TEMP.) SENSOR CIRCUIT (LOW TEMPERATURE INDICATED, SIGNAL VOLTAGE HIGH)




- 1. ECM
- 2. IAT sensor
- 3. Coupler
- 4. ECM coupler
- 5. To other sensors

6E2-070


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)

A/T Vehicle




6E2-071

M/T Vehicle



6E2-072

1. Disconnect IAT sensor coupler with ignition switch OFF.
2. With ignition switch ON, check voltage at "Lbl" wire terminals of IAT sensor coupler. Is it about 4 - 5 V?




6E2-073

YES

NO

1. Using service wire, connect IAT sensor coupler terminals.
2. Check voltage at "Lbl" wire terminal of IAT sensor coupler with ignition switch ON. Is it below 0.15 V?

"Lbl" wire open, poor THA connection or "Lbl" wire shorted to power circuit. If wire and connection are OK, substitute a known-good ECM and recheck.



6E2-074



NO

YES


"Gr/Y" wire open or poor SE connection. If wire and connection are OK, faulty ECM. Substitute a known-good ECM and recheck.

Poor coupler connection of IAT sensor or faulty IAT sensor. If connection and IAT sensor are OK, intermittent trouble or faulty ECM. Recheck referring to Intermittent trouble.

CODE NO.25 IAT (INTAKE AIR TEMP.) SENSOR CIRCUIT (HIGH TEMPERATURE INDICATED, SIGNAL VOLTAGE LOW)



CODE NO.24 VSS (VEHICLE SPEED SENSOR) CIRCUIT (VEHICLE SPEED SIGNAL NOT INPUTTED ALTHOUGH FUEL IS KEPT CUT FOR LONGER THAN 5 SECONDS)




6E2-079

6E2-080


6E2-081

NOTE:

Be sure to turn OFF ignition switch for this check.



CODE NO.33 MAF SENSOR (MASS AIR FLOW SENSOR) (LARGE SIGNAL CURRENT FLOW, SIGNAL VOLTAGE HIGH)
CIRCUIT




1. ECM
2. ECM coupler
3. MAF sensor
4. MAF sensor coupler
5. From main relay
6. To other sensors

6E2-083


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)

A/T Vehicle



6E2-084

M/T Vehicle



6E2-085

Turn ignition switch ON and check voltage at AFM terminal.
Is it within 0.5 – 1.0 V?

YES

Start engine and check voltage at AFM terminal.
Does voltage rise within 5V range when engine speed is increased?

YES

Poor AFM connection. If connection is OK, intermittent trouble or faulty ECM.
Recheck referring to Intermittent trouble.


NO

"Gr/Y" wire open or "Gr/B" wire shorted to power circuit.
If wires are OK, substitute a known-good MAF sensor and recheck.

NO

Substitute a known-good MAF sensor and recheck.


CODE NO.34 MAF SENSOR (MASS AIR FLOW SENSOR) (SMALL SIGNAL CURRENT FLOW, SIGNAL VOLTAGE LOW)
CIRCUIT



6E2-086


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)

A/T Vehicle




6E2-087

M/T Vehicle



6E2-088

1. Disconnect MAF sensor coupler with ignition switch OFF.
2. With ignition switch ON, is voltage applied to "BI/B" wire terminal of MAF sensor coupler about 10 - 14 V?



6E2-089

YES

NO

1. Connect MAF sensor coupler with ignition switch OFF.
2. Turn ignition switch ON and check voltage at AFM terminal. Is it within 0.5 - 1.0 V?

"BI/B" wire open.

YES


NO

Intermittent trouble or faulty ECM.
Recheck referring to Intermittent trouble.


Poor AFM connection, "Gr/B" wire open, or poor MAF sensor-to-coupler connection.
If wire and connection are OK, substitute a known-good MAF sensor and recheck.

CODE NO.42 CMP SENSOR (CAMSHAFT POSITION SENSOR) CIRCUIT

(REF SIGNAL NOT INPUTTED FOR 3 SECONDS AT ENGINE CRANKING AND/OR POS SIGNAL NOT INPUTTED AT ENGINE RUNNING)



Disconnect CMP sensor coupler with ignition switch OFF and Check voltage between "BI/B" wire terminal and "B/BI" wire terminal of disconnected CMP sensor coupler with ignition switch ON.
Is it battery voltage?




YES

NO

Check voltage between REF terminal of ECM coupler and body ground with ignition switch ON and crankshaft turned slowly.
Does voltmeter indicator deflect between 0 - 1 V and 4 - 6 V 6 times while crankshaft turned two revolutions?

BI/B wire open, B/BI wire open or poor B/BI wire ground.




YES

NO

Check voltage between POS terminal of ECM coupler and body Ground with ignition switch ON and crankshaft turned slowly.
Does voltmeter indicator deflect between 0 - 1 V and 4 - 6 V?

CMP sensor faulty or "Y/R" wire open or short.




YES

NO


Poor REF connection or POS connection of ECM coupler.
If connections are OK, substitute a known-good ECM and recheck.

CMP sensor faulty or "Y/G" wire open or short.

CODE NO.51 EGR VALVE (STEPPER MOTOR OR ITS CIRCUIT OPEN OR SHORT) (IF EQUIPPED)




Does EGR stepper motor operate for about 1 second after ignition switch ON?




```

    graph TD
        Q1[Does EGR stepper motor operate for about 1 second after ignition switch ON?]
        
        Q1 -- YES --> Q2[Check voltage between EGR1, EGR2, EGR3 and EGR4 terminals of ECM coupler for about 1 second after ignition switch ON. Is each measured voltage 4 - 8.4 V?]
        
        Q1 -- NO --> Q3[1. Disconnect EGR valve coupler with ignition switch OFF.  
2. Check voltage between "BI/B" wire terminals and body ground.  
3. Are they about 10 - 14 V?]
        
        Q2 -- YES --> R1[Intermittent trouble or faulty ECM. Recheck referring to intermittent trouble.]
        
        Q2 -- NO --> Q4[Check EGR valve. Is it OK?]
        
        Q3 -- NO --> R2["BI/B" wire open.]
        
        Q3 -- YES --> Q4
        
        Q4 -- YES --> R1
        
        Q4 -- NO --> R3[Faulty EGR valve.]
    
```

CODE NO.52 FUEL SYSTEM (FUEL LEAKAGE FROM FUEL INJECTOR, OXYGEN SENSOR
OUTPUT VOLTAGE DOES NOT REDUCE WHEN FUEL IS CUT)
(VEHICLE WITH HEATED OXYGEN SENSOR ONLY)




B-1 FUEL PUMP CIRCUIT CHECK



- 1. ECM
- 2. ECM coupler
- 3. Fuel pump relay
- 4. Fuel pump
- 5. Main relay

6E2-100

TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)



6E2-101


6E2-102

Is fuel pump heard to operate for 3 sec. after ignition switch ON?

NO

YES

1. Turn OFF ignition switch.
2. Using service wire, connect "P/B" and "B/W" wire terminals.
3. Is fuel pump heard to operate at ignition switch ON?



6E2-103

Fuel pump circuit in good condition.

YES

NO

Check fuel pump relay. Is it in good condition?

"P/B" wire open, poor fuel pump coupler connection or faulty fuel pump.

YES


NO

Poor relay coupler connection, "P" wire open or poor FP connection. If wire and connection are OK, substitute a known-good ECM and recheck.

Faulty fuel pump relay.


NOTE:
Before substituting a known-good ECM, check to make sure that resistance of coil in relay is as specified.

B-2 FUEL INJECTOR CIRCUIT CHECK




- 1. ECM
- 2. No.1 injector
- 3. No.2 injector
- 4. No.3 injector
- 5. No.4 injector
- 6. No.5 injector
- 7. No.6 injector
- 8. Main relay

TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)




6E2-104




6E2-105

6E2-106



None of 6 injectors makes operating sound.

1. Disconnect coupler from No. 1 injector with ignition switch OFF.
2. Check voltage at "B/B" wire terminal with ignition switch ON.
Is it battery voltage?



YES

NO


Power circuit open.

Disconnect ECM couplers with ignition switch OFF and check all 6 injectors for resistance respectively.

No.1 injector: INJ1 and B
 No.2 injector: INJ2 and B
 No.3 injector: INJ3 and B
 No.4 injector: INJ4 and B
 No.5 injector: INJ5 and B
 No.6 injector: INJ6 and B


If resistance is OK, substitute a known-good ECM and recheck.

B-3 FUEL PRESSURE CHECK



NOTE:

Before using following flow chart, check to make sure that battery voltage is higher than 11V. If battery voltage is low, pressure becomes lower than specification even if fuel pump and line are in good condition.



B-3 FUEL PRESSURE CHECK (continued)**① NO PRESSURE**

With fuel pump operated and fuel return hose blocked by pinching it, is fuel pressure applied?

NO

Shortage of fuel or fuel pump or its circuit defective (Refer to "Diagnostic Flow Chart B-1").

YES

Faulty fuel pressure regulator

③ LOW PRESSURE

1. Operate fuel pump.
2. With fuel return hose blocked by pinching it, check fuel pressure. Is it 450 kPa (4.5 kg/cm², 64.0 psi) or more?

NO

- Clogged fuel filter,
- Restricted fuel feed hose or pipe,
- Faulty fuel pump or
- Fuel leakage from hose connection in fuel tank.

YES

Faulty fuel pressure regulator

② PRESSURE WITHIN SPEC. BUT NOT RETAINED

Is there fuel leakage from fuel feed line hose, pipe or their joint?

NO

1. Disconnect fuel return hose from fuel pipe and connect new return hose to it.
2. Put the other end of new return hose into approved gasoline container.
3. Check again if specified pressure is retained. While doing so, does fuel come out of return hose?

NO

- Fuel leakage from injector,
- Faulty fuel pump (faulty check valve in fuel pump) or
- Fuel leakage from fuel pressure regulator diaphragm.

YES

Fuel leakage from hose, pipe or joint.

YES

Faulty fuel pressure regulator

④ HIGH PRESSURE

1. Disconnect fuel return hose from fuel pipe and connect new return hose to it.
2. Put the other end of new return hose into approved gasoline container.
3. Operate fuel pump. Is specified fuel pressure obtained then?


NO

Faulty fuel pressure regulator.

YES


Restricted fuel return hose or pipe.

B-4 IDLE AIR CONTROL SYSTEM CHECK





- A. Right bank A/F duty output terminal
- B. Diagnosis switch terminal
- C. Diagnosis output terminal
- D. Ground terminal
- E. Test switch terminal
- F. Duty output terminal

- 1. IAC valve
- 2. Idle air adjusting screw
- 3. Fast idle control system
- 4. Bypass air
- 5. Engine coolant
- 6. From main relay
- 7. ECM
- 8. Monitor coupler
- 9. To combustion chamber




6E2-109

TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)



6E2-110

6E2-111



6E2-112

1. Warm up engine to normal operating temperature and keep it idling.
 2. Using service wire, ground diagnosis switch terminal.
 3. Is diagnostic trouble code No.12 indicated?

YES

NO

Check idle air control duty (IAC duty) and idle speed.
 Are they within specification?

Go back to "Diagnostic Flow Chart".

High idle speed
 To ① on next page

Low idle speed
 To ② on next page.

NO

Is engine idle speed kept specified speed even with headlights turned ON?

Idle speed is within specification but duty is not.
 1. Adjust IAC duty to specification.
 2. Proceed to next step.

YES




YES

NO

System is in good condition.

Proceed to system circuit check ③ on next page.

B-4 IDLE AIR CONTROL SYSTEM CHECK (continued)




NOTE:
IAC duty can be checked by using analog type voltmeter with high impedance ($M\Omega/V$ minimum), although not accurate. IAC duty to voltage relation is as follows.

ON DUTY METER INDICATION	OFF DUTY METER INDICATION	VOLTMETER INDICATION
0 (%)	100 (%)	0 (V)
30	70	$0.3 \times V_B$
70	30	$0.7 \times V_B$
100	0	V_B


- "OFF" DUTY METER" is such duty meter that indicates approx. 100% when terminal voltage is approx. "0V".
- "V_B" represents battery voltage while engine of vehicle being checked is running.

B-5 EGR SYSTEM CHECK (IF EQUIPPED)




6E2-113

TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)



6E2-114



6E2-115

1. Warm up engine to normal operating temperature.
2. Using service wire, ground diag. switch terminal in monitor coupler
3. Is diagnostic trouble code No.12?

YES NO

Check EGR system by using tech-1. Is it good condition?


Go back to "Diagnostic Flow Chart" on p. 6E2-15.

YES NO

EGR system is in good condition.


Clogged EGR pipe, stuck or faulty EGR valve or poor performance of ECT sensor, TP sensor.

B-6 EVAPORATIVE EMISSION CONTROL SYSTEM CHECK



6E2-116


TERMINAL ARRANGEMENT OF ECM COUPLER (Viewed from harness side)




6E2-117



6E2-118





INSPECTION OF ECM AND ITS CIRCUITS

ECM and its circuits can be checked at ECM wiring couplers by measuring voltage and resistance.

CAUTION:

ECM cannot be checked by itself. It is strictly prohibited to connect voltmeter or ohmmeter to ECM with couplers disconnected from it.

Voltage Check


- 1) Remove ECM from body referring to ECM REMOVAL.
- 2) Connect ECM couplers to ECM.
- 3) Check voltage at each terminal of couplers connected.

NOTE:

As each terminal voltage is affected by the battery voltage, confirm that it is 11V or more when ignition switch is ON.

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)

A/T vehicle



6E2-119

M/T vehicle



6E2-120

M/T Vehicle

TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
INJ1	A1	Gr	No.1 injector	10 – 14V	Ignition switch ON
INJ2	A2	Gr/B	No.2 injector	10 – 14V	Ignition switch ON
OXH1	A3	P	Left bank heated oxygen sensor heater (if equipped)	10 – 14V 0 – 2V	Ignition switch ON At specified idle speed after engine warmed up.
PRG	A4	Br/R	EVAP canister purge valve	10 – 14V	Ignition switch ON
PSS	A5	Bl/O	Power steering pressure switch	4.75 – 5.25V 0 – 0.8V	Ignition switch ON Engine running at idle speed and steering wheel turned to the right and left as far as it stops.
STA	A6	B/Y	Engine start switch (Engine start signal)	0 – 1V 6 – 14V	Ignition switch ON While engine cranking
VCC	A7	Gr/R	Power source (for sensors)	4.75 – 5.25V	Ignition switch ON
POS	A8 A9	Y/G	CMP sensor signal (Position signal, vehicle with immobilizer)	Indicator deflection between 0 – 1V and 4 – 6V	Ignition switch ON Crank shaft turned slowly
REF	A8 A9	Y/Bl	CMP sensor signal (Reference signal, vehicle without immobilizer)	Indicator deflection between 0 – 1V and 4 – 6V	Ignition switch ON Crank shaft turned slowly
REF	A10 A11	Y/Bl	CMP sensor signal (Reference signal, vehicle with immobilizer)	Indicator deflection between 0 – 1V and 4 – 6V	Ignition switch ON Crank shaft turned slowly
POS	A10 A11	Y/G	CMP sensor signal (Position signal, vehicle without immobilizer)	Indicator deflection between 0 – 1V and 4 – 6V	Ignition switch ON Crank shaft turned slowly
INJ5	A12	Gr/G	No.5 injector	10 – 14V	Ignition switch ON
POWG	A13	B/G	Ground	—————	—————
INJ3	A14	Gr/W	No.3 injector	10 – 14V	Ignition switch ON
INJ5	A15	Gr/Y	No.4 injector	10 – 14V	Ignition switch ON
ISC	A16	Lg/B	IAC valve	{ 6.2 – 8.7V (62% : ON DUTY) }	At specified idle speed after engine warmed up.
-	A17 A18	-	Blank	—————	—————
THW	A19	R/Y	ECT sensor	About 0.8V	Ignition switch ON Engine coolant temp.: 80°C (176°F)
SE	A20	Gr/Y	Sensor ground	—————	—————
THA	A21	Lbl	IAT sensor	About 3.0V	Ignition switch ON sensor ambient temp.: 20°C (68°F)
OX1	A22	R/Bl	Left bank heated oxygen sensor (if equipped)	Indicator deflection repeated between over and under 0.31V	While engine running at 2,000 r/min for 1 minute or longer after warmed up.
CO	A22	R/Bl	CO adjusting resistor (vehicle without heated oxygen sensor only)	Ignition switch ON Voltage varies as specified in graph in p. 6E2-20 of SV620 service manual while CO adjusting resistor knob turned.	
VTA	A23	Gr	TP sensor	0.35 – 0.65V 3.6 – 4.5V	Ignition switch ON after engine warmed up. Throttle valve at idle position. Ignition switch ON Throttle valve at full open position.
AFM	A24	Gr/B	MAF sensor	0.5 – 1.0V 1.5 – 1.8V	Ignition switch ON With engine running at idle speed
INJ6	A25	Gr/R	No.6 injector	10 – 14V	Ignition switch ON
POWG	A26	B/G	Ground	—————	—————


TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)

A1	A2	A3	A4	A5	A6	A7	A8	A9	A10	A11	A12	A13	B1	B2	B3	B4	B5	B6	B7	B8	C1	C2	C3	C4	C5	C6	D1	D2	D3	D4	D5	D6	D7	D8	D9	D10	D11
A14	A15	A16	A17	A18	A19	A20	A21	A22	A23	A24	A25	A26	B9	B10	B11	B12	B13	B14	B15	B16	C7	C8	C9	C10	C11	C12	D12	D13	D14	D15	D16	D17	D18	D19	D20	D21	D22

TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
-	B1 B2	-	Blank	_____	_____
EL	B3	Bl/G	Electric load signal diode	0 - 1V	Ignition switch ON. Small light, heater fan and rear defogger all turned OFF.
				10 - 14V	Ignition switch ON. Small light, heater fan and rear defogger all turned ON.
TS	B4	Bl/R	Test switch terminal	4.75 - 5.25V	Ignition switch ON
				0 - 0.8V	Ignition switch ON Test switch terminal grounded
SPD	B5	Y	Vehicle speed sensor	Indicator deflection repeated between 0 - 1V and 4 - 5V	Ignition switch ON Rear left tire turned slowly with rear right tire locked.
-	B6	-	Blank	_____	_____
IGS	B7	B/W	Ignition switch (Vehicle with immobilizer)	10 - 14V	Ignition switch ON
				0 - 0.8V	Ignition switch OFF
SE	B8	Gr/Y	Sensor ground	_____	_____
AF	B9	W/Bl	A/F duty (Right bank) output terminal	4.75 - 5.25V	Ignition switch ON
-	B10	-	Blank	_____	_____
BB	B11	W	Power source for back-up	10 - 14V	Ignition switch ON and OFF
DN	B12	Bl/Y	Diagnosis switch terminal	4.75 - 5.25V	Ignition switch ON
				0 - 0.8V	Ignition switch ON Diagnosis switch terminal grounded
ACS	B13	Y/B	A/C amplifier (if equipped)	4.75 - 5.25V	Ignition switch ON
				0 - 1.5V	A/C ON
-	B14	-	Blank	_____	_____
TACHO	B15	Br/W	Tachometer	0 - 0.8V	Ignition switch ON
-	B16	-	Noise suppressor	10 - 14V	Ignition switch ON


TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
OX2	C1	R	Right bank heated oxygen sensor (if equipped)	Indicator deflection repeated between over and under 0.31 V	While engine running at 2,000 r/min for 1 minute or longer after engine warmed up
EGR1	C2	Lg/W	EGR valve (stepper motor coil 1), if equipped	10 - 14V	More than 3 seconds after ignition switch ON
				0 - 3.5V	After engine start (At fast idle)
EGR2	C3	Lg/B	EGR valve (stepper motor coil 2), if equipped	0 - 3.5V	More than 3 seconds after ignition switch ON
				10 - 14V	After engine start (At fast idle)
EGR3	C4	Lg/R	EGR valve (stepper motor coil 3), if equipped	0 - 3.5V	More than 3 seconds after ignition switch ON
				10 - 14V	After engine start (At fast idle)
EGR6	C5	Lg/Y	EGR valve (stepper motor coil 4), if equipped	10 - 14V	More than 3 seconds after ignition switch ON
				0 - 3.5V	After engine start (At fast idle)
-	C6	-	Blank	_____	_____
IGS	C7	B/W	Ignition switch (Vehicle without immobilizer)	10 - 14V	Ignition switch ON
				0 - 0.8V	Ignition switch OFF
-	C8 C9 C10 C11 C12	-	Blank	_____	_____

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)



TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
B	D1	Bl/B	Power source	10 - 14V	Ignition switch ON
IGN3	D2	Lg/W	Ignitor (No.3 ignition coil)	_____	_____
IGN6	D3	B/Br	Ignitor (No.6 ignition coil)	_____	_____
IGN1	D4	Lg	Ignitor (No.1 ignition coil)	_____	_____
IGN4	D5	Br/Y	Ignitor (No.4 ignition coil)	_____	_____
IGN5	D6	Lg/R	Ignitor (No.5 ignition coil)	_____	_____
IGN2	D7	Br/B	Ignitor (No.2 ignition coil)	_____	_____
-	D8	-	Blank	_____	_____
FP	D9	P	Fuel pump relay	0 - 2.5V	For 3 seconds after ignition switch ON
				10 - 14V	After the above time
ECUG	D10	B/Bl	Ground	_____	_____
IGNG	D11	B/O	Ground	_____	_____
B	D12	Bl/B	Power source	10 - 14V	Ignition switch ON
MON	D13	V	Duty output terminal	10 - 14V	Ignition switch ON
-	D14	-	Blank	_____	_____
DNL	D15	V/Y	Diagnosis output terminal and malfunction indicator lamp ("CHECK ENGINE" light)	0 - 2.5V	Ignition switch ON
				10 - 14V	Engine running
-	D16	-	Blank	_____	_____
-	D17	-	Blank	_____	_____
SDL	D18	V/W	Data link connector	4 - 5V	Ignition switch ON
-	D19	-	Blank	_____	_____
SOF	D20	Bl	Main relay	0 - 2.0V	Ignition switch ON
				10 - 14V	Ignition switch OFF
OXH2	D21	P/W	Right bank heated oxygen sensor heater (if equipped)	10 - 14V	Ignition switch ON
				0 - 2.0V	At specified idle speed after engine warmed up
ECUG	D22	B/Bl	Ground	_____	_____


TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)



A/T Vehicle


TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
B	A1	Bl/B	Power source	10 - 14V	Ignition switch ON
IGNG	A2	B/O	Ground	_____	_____
LIGHT	A3	R/Y	Lighting switch	10 - 14V	lighting switch ON
				0 - 1V	lighting switch OFF
R	A4	R	Transmission range switch ("R" range)	10 - 14V	Ignition switch ON Selector lever in "R" range
				0 - 1V	Ignition switch ON Selector lever in other than "R" range
DNL	A5	V/Y	Diagnosis output terminal and malfunction indicator lamp ("CHECK ENGINE" light)	0 - 2.5V	Ignition switch ON
				10 - 14V	Engine running
PWL	A6	P/W	"POWER" indicator light	0 - 2.5V	Ignition switch ON Mode selector switch is in POWER mode
				10 - 14V	Ignition switch ON Mode selector switch is in NORMAL mode
TACHO	A7	Br/W	Tachometer	0 - 0.8V	Ignition switch ON
-	A8	-	Blank	_____	_____
B	A9	Bl/B	Power source	10 - 14V	Ignition switch ON
IGN5	A10	Lg/R	Ignitor (No.5 ignition coil)	_____	_____
IGN6	A11	B/Br	Ignitor (No.6 ignition coil)	_____	_____
IGN4	A12	Br/Y	Ignitor (No.4 ignition coil)	_____	_____
2	A13	G/O	Transmission range switch ("2" range)	10 - 14V	Ignition switch ON Selector lever in "2" range
				0 - 1V	Ignition switch ON Selector lever in other than "2" range
L4	A14	O/W	4WD Low switch	10 - 14V	Ignition switch ON Transfer lever in "2H" or "4H" position
				0 - 1V	Ignition switch ON Transfer lever in "4L" or "N" position
D	A15	G/Bl	Transmission range switch ("D" range)	10 - 14V	Ignition switch ON Selector lever in "D" range
				0 - 1V	Ignition switch ON Selector lever in other than "D" range
TS	A16	Bl/R	Test switch terminal	4.75 - 5.25V	Ignition switch ON
				0 - 0.8V	Ignition switch ON Test switch terminal grounded
EL	A17	Bl/G	Electric load signal diode	0 - 1V	Ignition switch ON. Small light, heater fan and rear defogger all turned OFF
				10 - 14V	Ignition switch ON. Small light, heater fan or rear defogger turned ON
OD	A18	O/G	OD cut switch	10 - 14V	Ignition switch ON OD cut switch OFF
				0 - 1V	Ignition switch ON OD cut switch ON
BB	A19	W	Power source for back-up	10 - 14V	Ignition switch ON and OFF

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)




TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
FP	A20	P	Fuel pump relay	0 - 2.5V	For 3 seconds after ignition switch ON
				10 - 14V	After the above time
ODL	A21	W/B	"OD OFF" indicator light	0 - 2.5V	Ignition switch ON OD cut switch ON
				10 - 14V	Ignition switch ON OD cut switch OFF
SOF	A22	BI	Main relay	0 - 2.0V	Ignition switch ON
				10 - 14V	Ignition switch OFF
-	A23	-	Blank	_____	_____
ECUG	A24	B/BI	Ground	_____	_____
IGN3	A25	Lg/W	Ignitor (No.3 ignition coil)	_____	_____
N	A26	O/BI	Transmission range switch ("N" range)	10 - 14V	Ignition switch ON Selector lever in "N" range
				0 - 1V	Ignition switch ON Selector lever in other than "N" range
-	A27	-	Blank	_____	_____
BK	A28	G/W	Brake switch	10 - 14V	Brake pedal depressed
				0 - 1V	Brake pedal released
DN	A29	BI/Y	Diagnosis switch terminal	4.75 - 5.25V	Ignition switch ON
				0 - 0.8V	Ignition switch ON Diagnosis switch terminal grounded
ACS	A30	Y/B	A/C amplifier (if equipped)	4.75 - 5.25V	Ignition switch ON
				0 - 1.5V	A/C ON
PWR	A31	O	Mode selector switch (Power/Normal)	4.75 - 5.25V	Ignition switch ON Mode selector switch is in Normal mode
				0 - 1V	Ignition switch ON Mode selector switch is in Power mode
SPD	A32	Y	Vehicle speed sensor	Indicator deflection repeated between 0 - 1V and 4 - 5V	Ignition switch ON Rear left tire turned slowly with rear right tire locked
ECUG	A33	B/BI	Ground	_____	_____
SDL	A34	V/W	Data link connector	4 - 5V	Ignition switch ON
MON	A35	V	Duty output terminal	10 - 14V	Ignition switch ON

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)




TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
SPG	C1	O	A/T vehicle speed sensor (-)	_____	_____
SP	C2	W	A/T vehicle speed sensor (+)	_____	_____
S3	C3	G/Y	TCC solenoid valve	0 - 1V	Ignition switch ON
S2	C4	G/R	Shift solenoid valve B	0 - 1V	Ignition switch ON
OXH2	C5	P/W	Right bank heated oxygen sensor heater (if equipped)	10 - 14V	Ignition switch ON
				0 - 2V	At specified idle speed after warmed up
-	C6 C7	-	Blank	_____	_____
AF	C8	W/BI	A/F duty (Right bank) output terminal	4.75 - 5.25V	Ignition switch ON
OX2	C9	R	Right bank heated oxygen sensor (if equipped)	Indicator deflection repeated between over and under 0.31V	While engine running at 2,000 r/min for 1 minute or longer after engine warmed up.
-	C10	-	Blank	_____	_____
L	C11	G/BI	Transmission range switch ("L" range)	10 - 14V	Ignition switch ON Select lever in "L" range
				0 - 1V	Ignition switch ON Select lever in other than "L" range
S1	C12	G	Shift solenoid valve A	10 - 14V	Ignition switch ON
INJ6	C13	Gr/R	No.6 injector	10 - 14V	Ignition switch ON
IGN1	C14	Lg	Ignitor (No.1 ignition coil)	_____	_____
IGN2	C15	Br/B	Ignitor (No.2 ignition coil)	_____	_____
-	C16 C17 C18 C19	-	Blank	_____	_____
INJ5	C20	G/R	No.5 injector	10 - 14V	Ignition switch ON

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)



TERMINAL			CIRCUIT	NORMAL VOLTAGE	CONDITION
NAME	POSITION	WIRE COLOR			
IGS	D1	B/W	Ignition switch	10 - 14V	Ignition switch ON
				0 - 1V	Ignition switch OFF
PRG	D2	Br/R	EVAP canister purge valve	10 - 14V	Ignition switch ON
STA	D3	B/Y	Engine start switch (Engine start signal)	0 - 1V	Ignition switch ON
				6 - 14V	While engine cranking
OX1	D4	R/BI	Left bank heated oxygen sensor (if equipped)	Indicator deflection repeated between over and under 0.31V	While engine running at 2,000 r/min for 1 minute or longer after warmed up
EGR1	D5	Lg/W	EGR valve (stepper motor coil 1), if equipped	10 - 14V	More than 3 seconds after ignition switch ON
				0 - 3.5V	After engine start (At fast idle)
INJ4	D6	Gr/W	No.4 injector	10 - 14V	Ignition switch ON
INJ3	D7	Gr/B	No.3 injector	10 - 14V	Ignition switch ON
OXH1	D8	P	Left bank heated oxygen sensor heater (if equipped)	10 - 14V	Ignition switch ON
				0 - 2V	At specified idle speed after engine warmed up
VCC	D9	Gr/R	Power source (for sensors)	4.75 - 5.25V	Ignition switch ON
PSS	D10	BI/O	Power steering pressure switch	4.75 - 5.25V	Ignition switch ON
				0 - 0.8V	Engine running at idle speed and steering wheel turned to the right and left as for as it stops
THA	D11	LbI	IAT sensor	About 3.0V	Ignition switch ON Sensor ambient temp.: 20°C (68°F)
EGR3	D12	Lg/R	EGR valve (stepper motor coil 3), if equipped	0 - 3.5V	More than 3 seconds after ignition switch ON
				10 - 14V	After engine start (At fast idle)
EGR4	D13	Lg/Y	EGR valve (stepper motor coil 4), if equipped	10 - 14V	More than 3 seconds after ignition switch ON
				0 - 3.5V	After engine start (At fast idle)
EGR2	D14	Lg/B	EGR valve (stepper motor coil 2), if equipped	0 - 3.5V	More than 3 seconds after ignition switch ON
				10 - 14V	After engine start (At fast idle)
THW	D15	R/Y	ECT sensor	About 0.8V	Ignition switch ON Engine coolant temp.: 80°C (176°F)
POS	D16 D17	Y/G	CMP sensor signal (Position signal, vehicle with im- mobilizer)	Indicator deflection between 0 - 1V and 4 - 6V	Ignition switch ON Crank shaft turned slowly
POW G	D18	B/G	Ground	—————	—————
INJ2	D19	Gr/B	No.2 injector	10 - 14V	Ignition switch ON
ISC	D20	Lg/B	IAC valve	{ 6.2 - 8.7V (62% : ON DUTY) }	At specified idle speed after warmed up
SE	D21 D22	Gr/Y	Sensor ground	—————	—————
VTA	D23	Gr	TP sensor	0.35 - 0.65V	Ignition switch ON after engine warmed up Throttle valve at idle position
				3.6 - 4.5V	Ignition switch ON Throttle valve at full open position
AFM	D24	Gr/B	MAF sensor	0.5 - 1.0V	Ignition switch ON
				1.5 - 1.8V	With engine running at idle speed
REF	D25 D26	Y/BI	CMP sensor signal (Reference signal, vehicle with immobilizer)	Indicator deflection between 0 - 1V and 4 - 6V	Ignition switch ON Crank shaft turned slowly
POW G	D27	B/G	Ground	—————	—————
INJ1	D28	Gr	No.1 injector	10 - 14V	Ignition switch ON



Resistance Check

- 1) Disconnect ECM couplers from ECM with ignition switch OFF.

CAUTION:
Never touch terminals of ECM itself or connect voltmeter or ohmmeter.


- 2) Check resistance between each pair of terminals of disconnected couplers as listed in following table.

CAUTION:

- Be sure to connect ohmmeter probe from wire harness side of coupler.
- Be sure to turn OFF ignition switch for this check.
- Resistance in table represents that when parts temperature is 20°C (68°F).

TERMINAL ARRANGEMENT OF ECM COUPLER (VIEWED FROM HARNESS SIDE)

M/T vehicle



A/T vehicle





6E2-129

6E2-130

CIRCUIT	TERMINAL POSITION		STANDARD RESISTANCE	CONDITION
	M/T	A/T		
No.1 injector	A1 - D1/D12	D28 - A1/A6	10.8 - 13.2Ω	_____
No.2 injector	A2 - D1/D12	D19 - A1/A6	10.8 - 13.2Ω	_____
No.3 injector	A14 - D1/D12	D7 - A1/A6	10.8 - 13.2Ω	_____
No.4 injector	A15 - D1/D12	D6 - A1/A6	10.8 - 13.2Ω	_____
No.5 injector	A12 - D1/D12	C20 - A1/A6	10.8 - 13.2Ω	_____
No.6 injector	A25 - D1/D12	C13 - A1/A6	10.8 - 13.2Ω	_____
Left bank heated oxygen sensor heater (if equipped)	Vehicle with immobilizer	A3 - B7	D8 - D1	_____
	Vehicle without immobilizer	A3 - C7		
Right bank heated oxygen sensor heater (if equipped)	Vehicle with immobilizer	D21 - B7	C5 - D1	_____
	Vehicle without immobilizer	D21 - C7		
CO adjusting resistor (if equipped)	A3 - A7	D4 - D9	0 - 50kΩ	_____
EVAP canister purge valve	A4 - D1/D12	D2 - A1/A6	28 - 36Ω	_____
IAC valve	A16 - D1/D12	D20 - A1/A6	8.7 - 10.5Ω	_____

CIRCUIT		TERMINAL POSITION		STANDARD RESISTANCE	CONDITION
		M/T	A/T		
ECT sensor		A19 – A20/B8	D15 – D21/D22	305 – 324Ω	Engine coolant temp.: 80°C (176°F)
IAT sensor		A21 – A20/B8	D11 – D21/D22	2.21 – 2.69kΩ	Intake air temp.: 20°C (68°F)
Vehicle speed sensor (in speedometer)		B5 – Body ground	A32 – Body ground	Ohmmeter indicator deflects between 0 and ∞	Rear left wheel turned slowly with rear right wheel locked
EGR valve (coil 1), if equipped		C2 – D1/D12	D5 – A1/A6	21 – 23Ω	—————
EGR valve (coil 2), if equipped		C3 – D1/D12	D14 – A1/A6	21 – 23Ω	—————
EGR valve (coil 3), if equipped		C4 – D1/D12	D12 – A1/A6	21 – 23Ω	—————
EGR valve (coil 4), if equipped		C5 – D1/D12	D13 – A1/A6	21 – 23Ω	—————
Fuel pump relay	Vehicle with immobilizer	D9 – B7	A20 – D1	61 – 73Ω	—————
	Vehicle without immobilizer	D9 – C7			
Main relay		D20 – B11	A22 – A19	61 – 73Ω	—————
Transmission range switch ("R" range)		–	A4 – D1	Continuity	Selector lever in "R" range
				Not continuity	Selector lever in other than "R" range
Transmission range switch ("N" range)		–	A26 – D1	Continuity	Selector lever in "N" range
				Not continuity	Selector lever in other than "N" range
Transmission range switch ("D" range)		–	A15 – D1	Continuity	Selector lever in "D" range
				Not continuity	Selector lever in other than "D" range
Transmission range switch ("2" range)		–	A13 – D1	Continuity	Selector lever in "2" range
				Not continuity	Selector lever in other than "2" range
Transmission range switch ("L" range)		–	C11 – D1	Continuity	Selector lever in "L" range
				Not continuity	Selector lever in other than "L" range
A/T vehicle speed sensor		–	C1 – C2	369 – 451Ω	—————
4WD low switch		–	A14 – Body ground	Continuity	Transfer lever in "4L" or "N" position
				Not continuity	Transfer lever in "4H" or "2H" position
Mode selector switch		–	A31 – Body ground	Continuity	Mode selector switch in "POWER"
				Not continuity	Mode selector switch in "NORMAL"
Shift solenoid valve A		–	C12 – Body ground	11 – 15Ω	—————
Shift solenoid valve B		–	C4 – Body ground	11 – 15Ω	—————
TCC solenoid valve		–	C3 – Body ground	11 – 15Ω	—————



ON VEHICLE SERVICE

ELECTRONIC CONTROL SYSTEM

MASS AIR FLOW SENSOR (MAF SENSOR)

Inspection

NOTE:

Use voltmeter with high-impedance (10 k Ω /V minimum) or digital type voltmeter.

- 1) Remove ECM.
- 2) Connect couplers to ECM.

- 3) Connect voltmeter to "BI/B" wire terminal of MAF sensor coupler disconnected and ground.
- 4) Turn ignition switch ON and check that voltage is battery voltage.
If not, check if wire harness is open or connection is poor.

- 5) Turn ignition switch OFF and connect MAF sensor coupler to MAF sensor.
- 6) Turn ignition switch ON and check voltage at "AFM" terminal.


"AFM" voltage: 0.5 – 1.0 V

- 7) Start engine and check that voltage is lower than 5V and it rises as engine speed increases.
(Reference data: 1.5 – 1.8 V at specified idle speed)


If check result is not as specified above, cause may lie in wire harness, coupler connection, MAF sensor or ECM.

TERMINAL ARRANGEMENT OF ECM COUPLER
(VIEWED FROM HARNESS SIDE)

A/T VEHICLE



M/T VEHICLE



THROTTLE POSITION SENSOR (TP SENSOR)

Inspection

- 1) Remove ECM as previously outlined.
- 2) Warm up engine and stop it when its temperature has reached normal operating temperature (Check to make sure that they have some clearance between fast idle cam and cam follow lever.).
- 3) Using voltmeter, check voltage at "VTA" terminal under following each condition.

When throttle is fully close : 0.50 ± 0.15 V

When throttle is fully open : 4.0 ± 0.5 V


If measured voltage is out of above specified range, diagnose trouble by referring to "Diagnostic Flow Chart for Diag. Trouble Code No. 21 or 22".

Also, check that voltage varies according to throttle valve opening linearly. If not, it is possible that TP sensor has failed. Replace.

- 4) Upon completion of checking, install ECM.

Adjustment

- 1) Warm up engine to normal operating temperature.
- 2) Check to make sure that fast idle cam and cam follower lever are not in contact with each other. If they are, check fast idle control system.



- 3) Loosen TP sensor screws.
- 4) Remove ECM as previously outlined and with couplers connected to ECM, connect digital type voltmeter to VTA terminal and body ground.
- 5) Turn TP sensor clockwise or counterclockwise and tighten TP sensor screw at a position where voltage as specified below is obtained at coupler terminal VTA.

NOTE:


If tech 1 and cartridge are available, it is not necessary to remove ECM. Make an adjustment by using tech 1 while observing TP sensor voltage.

TP sensor voltage when throttle is fully close :
 $0.50 \pm 0.15 \text{ V}$

Tightening Torque

(a): $2.5 \text{ N}\cdot\text{m}$ (0.25 kg-m, 1.8 lb-ft)

- 6) Check to make sure that when throttle is fully open TP sensor voltage is as shown below.
- TP sensor voltage when throttle is fully open :**
 $4.0 \pm 0.5 \text{ V}$
- 7) Install ECM.
 - 8) Warm up engine completely.
 - 9) Turn OFF ignition switch when engine is at idle and shift lever is in Neutral (or Parking) position.

**TERMINAL ARRANGEMENT OF ECM COUPLER
(VIEWED FROM HARNESS SIDE)**

HEATED OXYGEN SENSOR (if equipped)
Sensor Inspection

- 1) Remove ECM.
- 2) Warm up engine to normal operating temperature.
- 3) Connect voltmeter between OX1 (for left bank: OX2 for right bank) and body ground.
- 4) Maintain engine speed at 2,000 r/min. After 60 seconds, check voltmeter.

Voltmeter Indication	Possible Cause	Correction
About 0 V	Heated oxygen sensor wire shorted to ground (circuit)	Repair or replace
About 0.3 V	Heated oxygen sensor wire or sensor ground wire open	Repair or replace
0.35 ~ 0.45 V	<ul style="list-style-type: none"> ● Faulty heated oxygen sensor itself ● Lean A/F mixture ● Faulty fuel injector (s) 	Replace heated oxygen sensor Inspect ECM and its circuit Replace fuel injector(s)
Deflect between above and below 0.45 V repeatedly	Heated oxygen sensor and its circuit is in good condition	_____
Remains unchanged at above 0.45 V	<ul style="list-style-type: none"> ● Rich A/F mixture 	Inspect ECM and its circuit

SECTION 6F2

6F2

IGNITION SYSTEM

(DIRECT IGNITION TYPE)

NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of service manual mentioned in the FOREWORD of this manual.

CONTENTS

GENERAL DESCRIPTION	6F2-2
System Wiring	6F2-2
DIAGNOSIS	6F2-3
ON VEHICLE SERVICE	6F2-5
Ignition Coil (with igniter)	6F2-5

GENERAL DESCRIPTION

The ignition system used for this vehicle uses a direct ignition system so as to avoid jamming caused by the secondary voltage which occurred in the ignition coil and ensure stable ignition even during a high engine speed. Also, IC (Ignition Control) system is adopted to obtain the ignition timing suitable for the every engine conditions.

The components of this system are as follows.


- ECM
It detects the engine condition through the signals from the sensors, determines the most suitable ignition timing and time for electricity to flow to the primary coil and sends a signal to the igniter (power unit).
- Igniters (in ignition coil)
It turns ON and OFF the primary current of the ignition coil according to the signal from ECM.
- Ignition coils
When the ignition coil primary current is turned OFF, a high voltage is induced in the secondary winding.
One ignition coil is in charge of ignition of one cylinder only.
- CMP sensor(Camshaft Position Sensor)
Being photoelectrically operated, this system converts timing and time by and during which the light is received at the light receiving part in the CMP sensor into the electric signals. It also outputs the engine speed (position) signal and the cylinder identification (reference) signal to ECM.
- Spark plugs.
- TP sensor, ECT sensor and MAF sensor
For their details, refer to Section 6E2.

The direct ignition system does not have a distributor or high tension cords but each cylinder has an ignition coil and the secondary voltage which occurred in the ignition coil is sent to the spark plug directly.

Also, the engine speed (position) signal and cylinder identification (reference) signal are sent from the CMP sensor to ECM so as to control each ignition coil independently through the igniter.

In IC (Ignition Control) system, the ECM is programmed for the best ignition timing under every engine condition. Receiving signals which indicate the engine condition from the sensors, e.g., engine revolution, intake air volume, coolant temperature, etc., it selects the most suitable ignition timing from its memory and operates the igniter (power unit). Thus ignition timing is controlled to yield the best engine performance.


SYSTEM WIRING




DIAGNOSIS

Condition	Possible Cause	Correction
Engine cranks, but will not start or hard to start	No spark <ul style="list-style-type: none"> ● Blown fuse for ignition coil ● Loose connection or disconnection of lead wire ● Faulty spark plug(s) ● Faulty ignition coil (with igniter) ● Faulty CMP sensor ● Faulty ECM Maladjusted ignition timing	Replace Connect securely Adjust, clean or replace Replace Replace Replace Adjust
Poor fuel economy or engine performance	<ul style="list-style-type: none"> ● Incorrect ignition timing ● Faulty spark plug(s) ● Faulty ignition coil (with igniter) ● Faulty CMP sensor ● Faulty ECM 	Adjust Adjust, clean or replace Replace Replace Replace



DIAGNOSTIC FLOW CHART (When engine does not start though it is cranked up)





ON-BOARD DIAGNOSTIC SYSTEM (SELF-DIAGNOSIS)


1. To insure correct diagnosis, check to confirm that battery voltage is within standard value when engine is standstill.
2. Turn on ignition switch and make sure that malfunction indicator lamp ("CHECK ENGINE" light) lights.
3. If engine will not start but cranking is possible, crank it for more than 3 seconds.
4. While ignition switch is ON, ground diagnosis switch terminal in monitor coupler (6 terminals) and then read diagnostic trouble code (observe malfunction indicator lamp ("CHECK ENGINE" light)).



DIAGNOSTIC TROUBLE CODE NO.42

ECM memory indicates that no CMP sensor signal has been experienced for more that 2 seconds while engine is being cranked.

Diagnose trouble according to "Diagnostic Flow Chart for Code No.42" in Section 6E2.




ON VEHICLE SERVICE

IGNITION COIL (WITH IGNITER)

REMOVAL

- 1) Remove ignition coil cover(s).
- 2) Disconnect ignition coil coupler(s).
- 3) Remove ignition coil bolt(s), and then pull out ignition coil(s).



INSPECTION

Igniter and Primary Coil

Using analog tester, check resistance between following terminals.

Terminal	Resistance
① and ②	Not 0
① and ③	Not 0
② and ③	Neither 0 nor ∞

If check result is not satisfactory, replace ignition coil.


Secondary Coil


- 1) Connect 12 V vehicle battery and digital ammeter and measure current value as shown in left figure.

Specified current: 0.3 ~ 1.4 mA

- 2) Reverse polarities and check that current does not flow.

If check result is not satisfactory, replace ignition coil.





INSTALLATION

- 1) Install ignition coil(s) securely.
- 2) Tighten ignition coil bolt(s), and then connect ignition coil coupler(s).

Tightening Torque

(a): 3 N·m (0.3 kg-m, 2.5 lb-ft)

- 3) Install ignition coil cover(s).

SECTION 7B1

AUTOMATIC TRANSMISSION

(4 A/T)

7B1

NOTE:


For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in FOREWORD of this manual.

CONTENTS

GENERAL DESCRIPTION	7B1- 2
ELECTRONIC SHIFT CONTROL SYSTEM	7B1- 2
Powertrain (Engine) Control Module (PCM/ECM)	7B1- 2
Automatic Gear Shift Diagram	7B1- 6
DIAGNOSIS	7B1- 8
TRANSMISSION UNIT	7B1- 8
Manual Road Test	7B1- 8
ELECTRONIC SHIFT CONTROL SYSTEM	7B1- 9
On-Board Diagnostic System	7B1- 9
Precaution in Identifying Diag. Trouble Code	7B1- 9
Precaution on Troubleshooting	7B1- 9
Diagnostic Flow Chart	7B1-10


GENERAL DESCRIPTION

ELECTRONIC SHIFT CONTROL SYSTEM





POWERTRAIN (ENGINE) CONTROL MODULE (PCM/ECM)

The PCM is an electronic circuit component that controls gear shift and lock-up according to the signal from each sensor. It is a microcomputer consisting of an IC, transistor, diode, etc. It is installed to the underside of the instrument panel at the driver's seat side.



TERMINAL ARRANGEMENT OF PCM COUPLER (VIEWED FROM HARNESS SIDE)






- 1. Reference voltage
- 2. Output
- 3. Ground
- 4. Resistor
- 5. Conductor
- 6. Rotor
- 7. Brush
- 8. Resistive segment

Throttle Position Sensor

This sensor is installed to the throttle valve shaft. Throttle valve opening signal are transmitted from TP sensor to PCM as voltage signal.

PCM uses it as one of the signals to control transmission gear shift.




- 1. Vehicle speed sensor
- 2. Oil pan
- 3. Transfer

Vehicle Speed Sensor

This sensor is a pulse generator type that detects revolution of the output shaft (vehicle speed) in the transmission case. The pulse generator is a noncontact sensor consisting of a permanent magnet, coil and gears.


As the gear of the output shaft turns, the magneflux from the permanent magnet varies and a voltage of the frequency corresponding to the rotor revolution occurs in the coil. This voltage is inputted to the PCM where PCM judges the output shaft revolution or the vehicle speed. The vehicle speed is also detected from the speed meter.



Transmission Range Switch


A transmission range switch is provided so that the engine can be started only when the shift lever is in the "P" or "N" position.

Terminal position	6	5	9	8	4	7	3	2	1
P	○—○		○—○						
R			○—○		○				
N	○—○		○—○			○			
D			○—○				○		
2			○—○					○	
L			○—○						○




Brake Switch

The same switch is used as the brake lamp switch. It disengages the TCC when the brake is depressed while the TCC is operating.




Engine Coolant Temperature Sensor (ECT Sensor)

The coolant temperature sensor is used and it prevents gear change to the O/D gear and TCC operation when the engine coolant temperature is 30°C (86°F) or lower.




O/D Cut Switch

The gear shift up or shift down to and from the O/D gear can be selected with this switch.



Transfer 4L Switch

This switch detects that the 4-wheel drive low gear is engaged and prevents the gear change into O/D and lock-up.



Mode Selector Switch


The gear shift timing, normal or power, can be selected by using this switch.

Fail Safe Function

This function is provided by the safe mechanism that assures safe driveability even when the shift solenoid valve or speed sensor fails.

The table below shows the gear position in each shift under a normal/abnormal condition.

Condition \ Shift position	Normal	Shift solenoid valve-A abnormal	Shift solenoid valve-B abnormal	Shift solenoid valves-A & B abnormal
D	1st	3rd	1st	O/D
	2nd		O/D	
	3rd			
	O/D	O/D		
2	1st	3rd	1st	3rd
	2nd		3rd	
	(3rd)			
L	1st	1st	1st	1st
	(2nd)	(2nd)		



Change Mechanism

The same select pattern shift lever is used as the floor type and frequently used "N" and "D" ranges are made selectable freely.

AUTOMATIC GEAR SHIFT DIAGRAM

Automatic shift schedule as a result of shift control is shown below. In case that select lever shifted to L at a speed higher than 55 km/h (34 mile/h), 2nd gear operates first and then down shifts to 1st at a speed lower than that. No up shift is available in L.


The same as, the select lever shifted to 2 at a speed higher than 105 km/h (66 mile/h), 3rd gear operates first and then down shifts to 2nd at a speed lower than that. No up shift is available in 2.

Power Mode

Unit: km/h
(mile/h)


Throttle opening \ Shift	1 → 2	2 → 3	3 → 4	4 → 3	3 → 2	2 → 1
Full throttle	48 (30)	100 (63)	— —	135 (84)	88 (55)	43 (27)
Closed throttle	18 (11)	36 (23)	48 (30)	35 (22)	29 (18)	7 (4)

Gear Shift Diagram



7B1-012

TCC Lock-up Diagram




7B1-013

Normal Mode

Unit: km/h
(mile/h)


Throttle opening \ Shift	Shift					
	1 → 2	2 → 3	3 → 4	4 → 3	3 → 2	2 → 1
Full throttle	46 (29)	94 (59)	135 (84)	123 (77)	82 (51)	35 (22)
Closed throttle	16 (10)	37 (23)	45 (28)	35 (22)	29 (18)	7 (4)

Gear Shift Diagram



7B1-014

TCC Lock-up Diagram



7B1-015

DIAGNOSIS

TRANSMISSION UNIT

MANUAL ROAD TEST

This test checks the gears being used in "L", "2" or "D" range when driven with unoperated gear shift control system. Test drive vehicle on a level road.

- 1) Disconnect coupler of shift solenoid valves on transmission.

WARNING:

To avoid the danger of being burned, do not touch the hot exhaust system when disconnecting shift solenoid valves coupler.

- 2) With selector lever in "P" range, start engine and warm it up.
- 3) With select lever in "L" range, start vehicle and accelerate to 20 km/h (12.5 mile/h). Check in this state that 1st gear is being used.
- 4) At 20 km/h (12.5 mile/h), shift select lever to 2 range and accelerate to 40 km/h (25 mile/h). Check in this state that 3rd gear is being used.
- 5) At 40 km/h (25 mile/h), shift select lever to D range and check that O/D gear is used when speed is higher than 40 km/h (25 mile/h).
- 6) After above checks, stop vehicle then engine, and connect solenoid valves coupler.

WARNING:


To avoid the danger of being burned, do not touch the exhaust system when connecting shift solenoid valves coupler.

- 7) Ground diagnosis switch terminal in monitor coupler, turn ON ignition switch and make sure that MIL ("CHECK ENGINE" light) indicates code No.12.

ELECTRONIC SHIFT CONTROL SYSTEM


The powertrain (engine) control module (P(E)CM) with on-board diagnostic system (self-diagnosis function) operates as described below.

When diagnosing a trouble in the electronic shift control system, use "DIAGNOSTIC FLOW CHART" and "DIAGNOSTIC TROUBLE CODE TABLE" on the following page.



ON-BOARD DIAGNOSTIC SYSTEM (SELF-DIAGNOSIS FUNCTION)

- When the engine is OFF and the ignition switch is turned ON, the malfunction indicator lamp ("CHECK ENGINE" light) lights for its bulb check of malfunction indicator lamp ("CHECK ENGINE" light).
- Should an abnormality have occurred in the electronic shift control system while the ignition switch is ON or the engine running, the area where the abnormality has occurred is stored in the P(E)CM memory and it remains in the memory till ignition switch is turned OFF.
- The affected area in the memory is indicated by flashing of malfunction indicator lamp ("CHECK ENGINE" light) when the diag. switch terminal is grounded.




PRECAUTION IN IDENTIFYING DIAG. TROUBLE CODE

- Before checking the diag. trouble code, be sure not to turn OFF the ignition switch, disconnect the P(E)CM or battery negative cable. Or the memory will be erased.
- Each trouble code is indicated 3 times. Write it down so as not to forget it. When an abnormality exists in more than one area, their code Nos. are indicated from the smallest to larger numbers.

PRECAUTION ON TROUBLESHOOTING

- "Normal operating temperature" in the diagnostic flow chart means that the engine coolant temperature is 80°C (176°F) and A/T fluid temperature is 70–80°C (158–176°F).
- Do not connect an ohmmeter, voltmeter, etc. directly (with the coupler disconnected) to the P(E)CM terminal. It may cause damage to the P(E)CM.

DIAGNOSTIC FLOW CHART




Diagnostic Trouble Code Table (A/T Related Code)

Code No.	Diagnostic Area	Diagnosis
12	-	Normal
61	Shift solenoid valve A	Shift solenoid valve A or its circuit open or shorted to power circuit.
62		Shift solenoid valve A or its circuit shorted to ground.
63	Shift solenoid valve B	Shift solenoid valve B or its circuit open or shorted to power circuit.
64		Shift solenoid valve B or its circuit shorted to ground.
65	TCC solenoid valve	TCC solenoid valve or its circuit open or shorted to power circuit.
66		TCC solenoid valve or its circuit shorted to ground.
72	Transmission range switch	Defective switch or its circuit (more than two shift switches of "R", "N", "D", "2" and "L" turned ON simultaneously or no shift switch turned ON while vehicle running).
75	A/T vehicle speed sensor	Defective sensor or its circuit. (open or short)


Fail-Safe Table

Code No.	Diagnostic Area	Fail-Safe Function
14	ECT sensor	After 15 min. from engine start, TCM release inhibitions of shift to OD gear and TCC lock-up.
15		
21	TP sensor	Throttle opening is controlled as closed.
22		
61	Shift solenoid valve A	Shift solenoid valve B. 1st, 2nd and 3rd gears ON, 4th (O/D) gear OFF. For shift position, refer to Fail-Safe Function in ELECTRONIC SHIFT CONTROL SYSTEM.
62		
63	Shift solenoid valve B	Shift solenoid valve A. 1st gear ON, 2nd 3rd and 4th (O/D) gears OFF. For shift position, refer to Fail-Safe Function in ELECTRONIC SHIFT CONTROL SYSTEM.
64		
65	TCC solenoid valve	TCC solenoid valve OFF.
66		
72	Transmission range switch	Priority order is "L" → "2" → "N" → "D" → "R". (When two or more signals inputted same time) Transmission range switch is controlled as "D" range. (When no signal inputted)
75	A/T vehicle speed sensor	Signal from vehicle speed sensor (in speedometer) is used.

DIAGNOSTIC FLOW CHART A





Terminal Arrangement of P(E)CM Coupler (Viewed from harness side)






- S₁: Shift solenoid A (S₁) terminal
- S₂: Shift solenoid B (S₂) terminal
- L: "L" range signal terminal
- 2: "2" range signal terminal

DIAGNOSTIC FLOW CHART B





DIAGNOSTIC CHART C





DIAGNOSTIC FLOW CHART D



GROUP2

SUZUKI

SV620

SUPPLEMENTARY SERVICE MANUAL

FOREWORD

This SUPPLEMENTARY SERVICE MANUAL (GROUP 2) is a supplement to GROUP 1.

Applicable model:

SV620 vehicles on and after following body No.
(x) JSAETD11V00200001 (x)~
TD11V-200001~

Therefore, whenever servicing applicable model, consult GROUP 2 first. And for any section, item or description not found in GROUP 2, refer to GROUP 1.

When replacing parts or servicing by disassembling, it is recommended to use SUZUKI genuine parts, tools and service materials (lubricants, sealants, etc.) as specified in each description.

All information, illustrations and specifications contained in this literature are based on the latest product information available at the time of publication approval. And used as the main subject of description is the vehicle of standard specifications among others. Therefore, note that illustrations may differ from the vehicle being actually serviced. The right is reserved to make changes at any time without notice.

TABLE OF CONTENTS	SECTION
HEATING AND AIR CONDITIONING Heating and Ventilation	1A
STEERING, SUSPENSION WHEELS AND TIRES Front Suspension	3D
ENGINE Engine Mechanical Engine Cooling Electronic Fuel Injection System (Sequential Multiport Fuel Injection For H20A type Engine) Exhaust System	6A2 6B 6E2 6K
BODY ELECTRICAL SYSTEM	8

RELATED SERVICE MANUAL

Refer to FOREWORD of GROUP 1

SUZUKI MOTOR CORPORATION
OVERSEAS SERVICE DEPARTMENT

GROUP2

1A

3D

6A2

6B

6E2

6K

8

SECTION 1A

HEATER AND VENTILATION

WARNING:

For vehicles equipped with a Supplemental Inflatable Restraint Air Bag System:

- Service on or around Air Bag System Components or Wiring must be performed only by an authorized Suzuki dealer. Please observe all WARNINGS and SERVICE PRECAUTIONS in Section 9J under "On-Vehicle Service" and the Air Bag System Component and Wiring Location view in Section 9J before performing service on or around Air Bag System Components or Wiring. Failure to follow WARNINGS could result in unintended air bag deployment or could render the air bag inoperative. Either of these two conditions may result in severe injury.
- Technical service work must be started at least 90 seconds after the ignition switch is turned to the "LOCK" position and the negative cable is disconnected from the battery. Otherwise, the air bags may be deployed by reserve energy in the Sensing and Diagnostic module (SDM).

1A

NOTE:

- For the descriptions (items) not found in this section, refer to SECTION 1A of the Service Manual mentioned in FOREWORD of this manual.
- The link mechanism of the heater varies depending on the specifications.


CONTENTS


GENERAL DESCRIPTION	1A- 2
HEATER CONTROL OPERATION	1A- 3
TROUBLE DIAGNOSIS	1A- 5
WIRING CIRCUIT	1A- 6
ON-VEHICLE SERVICE	1A- 7
Mode Control Switch	1A- 7
Mode Actuator	1A- 8
Heater Control Lever Assembly	1A- 9
Control Cables	1A-11

GENERAL DESCRIPTION

The heater, an in and out air selectable-type hot water heater, is so constructed that it is possible to assure an agreeable ventilation at all times by providing the ventilator air outlets at the center and both sides (right and left) of the instrument panel, the hot air outlet at a place close to the feet of front passengers, and the defroster air outlets at places, right and left, along the windshield glass.

The heater and ventilation consist of following parts.





60A40-1A-3-1

	VENTILATION
	BI-LEVEL
	HEAT
	HEAT & DEFROSTER
	DEFROSTER

60A20-1A-3-2

	CIRCULATION
	FRESH AIR

60A20-1A-3-3


60A20-1A-3-4

60A20-1A-3-5

HEATER CONTROL OPERATION

For mode selection, press mode control switch as desired. Then the mode actuator will move the link to change the mode.

MODE CONTROL SWITCH

BI-LEVEL () is a position used to keep cooling the head and warming the feet.

CONTROL LEVER A

CONTROL LEVER B

A temperature control lever.


The temperature of air is controlled by this lever.

To make the heater warmer, set it to the "HOT" position.

CONTROL LEVER C


A blower speed selecting lever. The blower speed is increased as the lever is moved from left to right.

A. FORCED VENTILATION




60A40-1A-4-1

B. OUTSIDE AIR-INTRODUCED HEATING




60A40-1A-4-2

C. INSIDE AIR-CIRCULATED HEATING



60A40-1A-4-3

D. HEAD-COOLED/FEET-WARMED HEATING




60A40-1A-5-1


TROUBLE DIAGNOSIS

Trouble	Possible cause	Remedy
Heater blower won't work even when its switch is ON.	Blower fuse blown Blower resistor faulty Blower motor faulty Wiring or grounding faulty	Replace fuse to check for short. Check resistor. Replace motor. Repair as necessary.
Incorrect temperature output.	Control cables broken or binding Air damper broken Air ducts clogged Heater radiator leaking or clogged Heater hoses leaking or clogged	Check cables. Repair damper. Repair air ducts. Replace radiator. Replace hoses.
When mode control switch is changed, air outlet port is not changed.	Mode control switch faulty Mode actuator faulty Fuse blown Wiring or grounding faulty Air damper broken Air ducts clogged	Check and replace as necessary. Check and replace as necessary. Replace fuse to check for short. Repair as necessary. Repair damper Repair air ducts.

60A20-1A-5-2


WIRING CIRCUIT






1. Center garnish

78E00-1A-7-1



1. Mode control switch

78E00-1A-7-2



1. Mode control switch coupler

78E00-1A-7-3

ON-VEHICLE SERVICE MODE CONTROL SWITCH

REMOVAL

- 1) Disconnect negative (-) cable at battery.
- 2) If equipped with air bag system, disable air bag system. Refer to "Disabling Air Bag System" in Section 9J.
- 3) Pull off control lever knobs.
- 4) Remove ashtray and center garnish mounting screws.
- 5) Remove center garnish with mode control switch.
- 6) Remove mode control switch from center garnish.

INSPECTION

Mode Control Switch

- Check if continuity exists between each pair of terminals listed below when mode control button is pressed.

Mode	Mode control switch terminals
VENT	e - k
BI-LEVEL	e - l
HEAT	e - d
DEF/HEAT	e - c
DEF	e - b

- With battery voltage (+) connected to terminal "i" and (-) to terminal "e", press each mode control button and check if indicator lamp lights.
- With battery voltage (+) connected to terminal "j" and (-) to terminal "e", check if illumination lamp lights.

A/C Switch (if equipped)

- Press A/C button and check if there is continuity between terminals "a" and "f".
- With battery voltage (+) connected to terminal "g" and (-) to terminal "h", press A/C button and check if indicator lamp lights.

INSTALLATION


- 1) Install in reverse order of removal.
- 2) If equipped with air bag system, enable air bag system. Refer to "Enabling Air Bag System" in Section 9J.

MODE ACTUATOR


REMOVAL

- 1) Disconnect negative (-) cable at battery.
- 2) If equipped with air bag system, disable air bag system. Refer to "Disabling Air Bag System" in Section 9J.
- 3) Remove EBCM bracket with EBCM and ICM (if equipped).
- 4) Disconnect mode actuator coupler.
- 5) Disconnect mode actuator rod from heater unit.
- 6) Remove mode actuator from heater unit.


78E00-1A-8-1




78E00-1A-8-2



FOR LEFT HAND STEERING VEHICLE



FOR RIGHT HAND STEERING VEHICLE



1. Lever

78E00-1A-8-3

INSPECTION


- 1) Connect battery voltage (+) to terminal "a" and (-) to terminal "g".
- 2) Connect each terminal listed below to terminal "g" (negative (-) terminal of battery) and check if lever rotation angle is as specified in figure at the left.

MODE	TERMINAL	
	Left hand steering vehicle	Right hand steering vehicle
VENT	f'	b'
BI-LEVEL	e'	c'
HEAT	d'	d'
DEF/HEAT	c'	e'
DEF	b'	f'


INSTALLATION

- 1) Install in reverse order of removal.
- 2) If equipped with air bag system, enable air bag system.
Refer to "Enabling Air Bag System" in Section 9J.


78E00-1A-9-1



78E00-1A-9-2



78E00-1A-9-4



60A50-1A-10-1

HEATER CONTROL LEVER ASSEMBLY**REMOVAL**

- 1) Disconnect negative (-) cable at battery.
 - 2) If equipped with air bag system, disable air bag system.
Refer to "Disabling Air Bag System" in Section 9J.
 - 3) Pull off control lever knobs.
 - 4) Remove ashtray and center garnish mounting screws.
 - 5) Remove center garnish.
 - 6) Remove glove box and column hole cover.
 - 7) Remove instrument glove box compartment.
- 8) Disconnect control cables from blower motor unit and heater unit.
 - 9) Disconnect heater blower motor switch connector.
- 10) Remove heater control lever assembly.

INSPECTION OF HEATER BLOWER MOTOR SWITCH

Check heater blower motor switch for each terminal-to-terminal continuity. For the detail refer to "WIRING CIRCUIT" earlier in this section.

	Lg	P/B	P/BI	P/G	P
LOW	○	○			
M1	○	○	○		
M2	○	○		○	
HIGH	○	○			○

Lg : Lightgreen

P/BI : Pink with Blue tracer

P : Pink

P/B : Pink with Black tracer

P/G : Pink With Green tracer


60A50-1A-10-2

INSTALLATION

- 1) Install in reverse order of removal.
- 2) If equipped with air bag, enable air bag system.
Refer to "Enabling Air Bag System" in Section 9J.

60A50-1A-10-3

CONTROL CABLES




85F00-1A-6-1

REMOVAL


- 1) Remove heater control lever assembly.
Refer to "HEATER BLOWER MOTOR SWITCH" in this section.

85F00-1A-6-3



- 2) Disconnect control cables from control lever.


85F00-1A-6-4




A. Heater Control (HOT-COOL Selector) Cable

- 1) Move control lever to COOL position.
- 2) Push lever fully in arrow direction to fix cable in position, as shown.

78E00-1A-11-5



78E00-1A-12-1



78E00-1A-12-2

B. Fresh Air Control (FRESH-CIRC Selector) Cable

1) Move control lever to FRESH position.

2) Push lever fully in arrow direction and fix cable with clamp in position as shown in left figure.

SECTION 3D

FRONT SUSPENSION

NOTE:

- For the descriptions (items) not found in this section, refer to the same section of the Service Manual mentioned in Foreword of this manual.
- All front suspension fasteners are an important attaching part in that it could affect the performance of vital parts and systems, and / or could result in major repair expense. They must be replaced with one of the same part number or with an equivalent part if replacement becomes necessary. Do not use a replacement part of lesser quality or substitute design. Torque values must be used as specified during reassembly to assure proper retention of this part.
- Never attempt to heat, quench or straighten any front suspension part. Replace it with a new part or damage to the part may result.

3D

CONTENTS

FRONT FREE WHEELING HUB (IF EQUIPPED)	3D- 2
TIGHTENING TORQUE SPECIFICATIONS	3D- 5
SPECIAL TOOLS	3D- 5

FRONT FREE WHEELING HUB (IF EQUIPPED)

There are two types of the front free wheeling hub in this vehicle (if equipped). One is manual type and the other is automatic type.

As removal, installation and maintenance procedures vary between them, be sure to correct section applicable to each kind.


CAUTION:


- Make sure that the same front free wheeling hub is installed for both right and left.
- For vehicle equipped with manual free wheeling hub, both of the right and left wheeling hub knobs must be set to the same position (either FREE or LOCK). Don't set one to "FREE" and the other to "LOCK" positions.
- Never disassemble free wheeling hub assembly. Disassembly will spoil its original function.

MANUAL FREE WHEELING HUB


Refer to the same section of the Service Manual mentioned in Foreword of this manual for operation, installation and maintenance.

AUTOMATIC FREE WHEELING HUB




**REMOVE**

- 1) Set free wheeling hub to free condition. (Set transfer gear shift lever to 2H position, and move vehicle 2 m (6.5 ft) or more backward slowly.)
- 2) Hoist vehicle, if wheel (tire) removal is necessary.
- 3) Remove wheel (tire), if necessary.
- 4) Remove free wheeling hub (sub assembly and brake assembly) slowly.

**INSTALLATION**


- 1) Check O-ring for damage and clean mating surfaces of hubs.
- 2) Install free wheeling hub brake assembly to spindle aligning key of brake assembly with slot in spindle.



- 3) Install free wheeling hub sub assembly to spindle aligning the match marks of brake assembly and sub assembly.

CAUTION:

Make sure that match marks are aligned. If they aren't, wire brake and release plate may interfere with each other, causing spring to break.



- 4) Tighten hub bolts to specified torque.


Special Tool

(A): 09900-00414 (6 mm bit)

(B): 09900-00411 (Socket)

Tightening Torque

(b): 33 N·m (3.3 kg-m, 24 lb-ft)





- 5) Install front wheels and tighten wheel nuts to specified torque, if removed.

Tightening Torque

(c): 95 N·m (9.5 kg-m, 69.0 lb-ft)

- 6) Dismount the vehicle from the lift, and be sure to carry out the operation check of free wheeling hub mentioned in the next item "Post-assembly confirmation".



Post-assembly confirmation

Confirm automatic free wheeling hub for proper operation in the sequence described below.

- 1) Set transfer gear shift lever to 4H or 4L position, and move vehicle 2 m (6.5 ft) or more forward slowly.
- 2) Hoist vehicle and check that wheel (tire) rotation is transmitted to drive shaft (lock condition) when rotating right wheel clockwise (left wheel counterclockwise) by hand.
- 3) Dismount vehicle from lift.
- 4) Set transfer gear shift lever to 2H position, and move vehicle 2 m (6.5 ft) or more backward slowly.
- 5) Hoist vehicle and check that wheel (tire) rotation is not transmitted to drive shaft (free condition) when rotating right wheel clockwise (left wheel counterclockwise) by hand.
- 6) Check to ensure that free wheeling hub locks and unlocks properly by reversing vehicle moving directions described in steps 1) and 4). (It should lock when moving backward and unlock when moving forward.)


If any malfunction is found as to the confirmation in the above steps 1) through 6), reinstall or replace free wheeling hub assembly.

MAINTENANCE SERVICE


Confirm automatic free wheeling hub for proper operation periodically according to the procedure described previously in "Post-assembly confirmation". If automatic free wheeling hub shows any malfunction, replace it with new one.

TIGHTENING TORQUE SPECIFICATIONS

Fastening parts	Tightening torque		
	N·m	kg-m	lb-ft
Automatic free wheeling hub bolts	33	3.3	24



SPECIAL TOOLS



SECTION 6A2

ENGINE MECHANICAL

NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of SV620 SERVICE MANUAL.


CONTENTS

6A2

ON VEHICLE SERVICE	6A2-1
Throttle Body and Intake Manifold	6A2-1

ON VEHICLE SERVICE

THROTTLE BODY AND INTAKE MANIFOLD



85F20-6A2-1-1S

REMOVAL/INSTALLATION

Refer to SV620 SERVICE MANUAL.

SECTION 6B

ENGINE COOLING

NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of SV620 SERVICE MANUAL.

CONTENTS

GENERAL DESCRIPTION 6B-1

6B

GENERAL DESCRIPTION

RADIATOR CAP

A pressure-vent cap is used on the radiator. The cap contains a pressure valve and ventilation valve.

The pressure valve is held against its seat by a spring of predetermined strength which protects the cooling system by relieving the pressure if the pressure in cooling system rises by 110 kPa (1.1 kg/cm², 15.6 psi).

The ventilation valve operates as follows.

- It opens to let the air out of the radiator when the temperature and the pressure in the radiator are lower than ventilation valve weight.
- It closes when the engine has warmed up and the pressure in the radiator has risen.
- It opens when the engine has cooled after being warmed up once and vacuum has occurred in the radiator so as to prevent the coolant level in the radiator from falling and the radiator from being collapsed due to the vacuum in it.


NOTE:

Do not remove radiator cap to check engine coolant level; check coolant visually at the see-through coolant reservoir.

Coolant should be added only to reservoir as necessary.

WARNING:

As long as there is pressure in the cooling system, the temperature can be considerably higher than the boiling temperature of the solution in the radiator without causing the solution to boil. Removal of the radiator cap while engine is hot and pressure is high will cause the solution to boil instantaneously and possibly with explosive force, spewing the solution over engine, fenders and person removing cap. If the solution contains flammable anti-freeze such as alcohol (not recommended for use at any time), there is also the possibility of causing a serious fire.



SECTION 6E2

ELECTRONIC FUEL INJECTION SYSTEM

(SEQUENTIAL MULTIPOINT FUEL INJECTION
FOR H20A TYPE ENGINE)

NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of GROUP 1.

CONTENTS

6E2

GENERAL DESCRIPTION	6E2-1
ELECTRONIC CONTROL SYSTEM	6E2-1
Air Conditioning Cut Signal (For Vehicle with A/C)	6E2-1

GENERAL DESCRIPTION

ELECTRONIC CONTROL SYSTEM


Air Conditioning Cut Signal
(For Vehicle with A/C)

ECM outputs A/C CUT signal to A/C amplifier when conditions listed below are satisfied.

Throttle valve opening : above 25.2°

Vehicle speed : below 10 km/h

When A/C amplifier receives A/C cut signal, A/C amplifier turns OFF A/C compressor for 4 seconds.



SECTION 6K

EXHAUST SYSTEM

NOTE:

For the descriptions (items) not found in this section of this manual, refer to the same section of SV620 SERVICE MANUAL.

CONTENTS

GENERAL DESCRIPTION 6K-1

GENERAL DESCRIPTION


The exhaust system consists of an exhaust manifold, exhaust pipes, a muffler, a tail pipe, and seals and gaskets etc.

The three way catalytic converter (TWC) is an emission control device added to the exhaust system to lower the levels of Hydrocarbon

(HC), Carbon Monoxide (CO), and Oxides of Nitrogen (NOx) pollutants in the exhaust gas.

THE CATALYTIC CONVERTER REQUIRES USE OF UNLEADED FUEL ONLY.

6K



1. Exhaust manifold gasket
2. Exhaust manifold
3. Heated oxygen sensor (if equipped)
4. Gasket
5. Exhaust No.1 pipe (without WU-TWC)
6. Exhaust No.1 pipe (with WU-TWC)
7. Gasket
8. Exhaust No.2 pipe (without TWC)
9. Exhaust No.2 pipe (with TWC)
10. Muffler
11. Rubber mounting

SECTION 8

BODY ELECTRICAL SYSTEM

NOTE:

- For the descriptions not found in this section of this manual, refer to the same section of SV620 SERVICE MANUAL.
- *1 and *2 of system circuit in this section indicate as shown below.
 - *1; For General & European spec. (Except German spec.)
 - *2; For German spec.

CONTENTS

BODY ELECTRICAL SYSTEM	8-1
Fuses and Switches	8-1
ON VEHICLE SERVICE	8-2
Windshield Wipers (Front Wiper)	8-2
Rear Window Wiper and Washer	8-3
Rear Fog Light (If equipped)	8-6

BODY ELECTRICAL SYSTEM


FUSES AND SWITCHES

COMBINATION SWITCH

The turn signal/dimmer switch incorporates the turn signal, hazard warning, dimmer and passing light switches.

Inspection

1. Disconnect negative cable at battery.
2. Remove lower steering column cover.
3. Disconnect combination switch couplers.




ON VEHICLE SERVICE

WINDSHIELD WIPERS (FRONT WIPER)

The windshield wiper is 3-speed type with variable intermittent switch and the windshield washer is equipped with a separate-type washer pump.

WIRING CIRCUIT



1. To connect fuses
The wire No.s (⑮ and ⑳) are same No. as figure of FUSES and SWITCHES
2. Combination switch
3. Wiper motor
4. Wiper return switch
5. Washer motor
6. Wiper intermittent relay
7. Variable resistor


B : Black
 Bl : Blue
 B/B : Blue/Black
 B/R : Blue/Red
 B/W : Blue/White
 Y/Bl : Yellow/Blue

85F20-8-2-2S


INSPECTION

A. Wiper/washer Switch

Use a circuit tester to check switch for each terminal-to-terminal continuity.




85F20-8-2-4S



D. Intermittent Wiper Relay Circuit (If equipped)

1. Disconnect wiper & washer switch coupler.

85F20-8-2-5S




85F20-8-3-1S

2. Turn wiper switch to "INT" position.
3. Connect (+) cord and (-) cord of 12 V battery to coupler terminals as shown left. If an operating sound is heard from relay, it is at work properly.


REAR WINDOW WIPER AND WASHER

The rear window wiper is 2-speed type, and its washer is equipped with a separate-type washer pump.


WIRING CIRCUIT




85F20-8-3-4S




85F20-8-4-1S




85F20-8-4-2S



85F20-8-4-3S



85F20-8-4-4S



85F20-8-4-5S


INSPECTION

A. Wiper And Washer Switches

Use a circuit tester to check switches for continuity.

COUPLER

① ②



⑭ ⑮

D. Rear Wiper Intermittent Relay

ON circuit.

1. Connect positive terminal of battery to terminals ① and ④ of controller, negative terminal to terminal ⑤ of controller and check voltage between terminals ⑥ and ⑤ of controller.

If measured voltage is battery voltage, controller is in good condition.

If not, replace controller.

2. Connect positive terminal of battery to terminal ② of controller, then disconnect positive terminal from terminal ④ of controller and check voltage between terminals ⑥ and ⑤ of controller.

If measured voltage is battery voltage, controller is in good condition.

If not, replace controller.

3. Disconnect positive terminal from terminal ② of controller and check voltage between terminals ⑥ and ⑤ of controller.


If measured voltage is about 0V, controller is in good condition.

If not replace controller.


WASH circuit

1. Connect positive terminal of battery to terminal ① of controller and negative terminal to terminal ⑤ of controller. Then connect positive terminal to terminal ⑦ checking voltage between terminals ⑥ and ⑤ of controller.


If measured voltage changes from about 0V to battery voltage 0.6 to 1.5 seconds after connecting positive terminal to terminal ⑦, controller is in good condition. If not, replace controller.



85F20-8-5-1S



85F20-8-5-2S



85F20-8-5-3S


2. Disconnect positive terminal from terminal ⑦ checking voltage between terminal ⑥ and ⑤ of controller.
If measured voltage changes from battery voltage to about 0V 2.7 to 4.6 seconds after disconnecting positive terminal from terminal ⑦, controller is in good condition.
If not replace controller.

INT circuit

1. Connect positive terminal of battery to terminals ① of controller and negative terminal to terminal ⑤ of controller. Then positive terminal to terminal ③ of controller checking voltage between terminals ⑥ and ⑤ of controller.
If measured voltage changes from about 0V to battery voltage when connecting positive terminal to terminal ③, controller is in good condition.
If not replace controller.
2. Connect positive terminal of battery to terminal ② of controller, then disconnect positive terminal from terminal ② of controller checking voltage between terminals ⑥ and ⑤ of controller.
If measured voltage changes from battery voltage to about 0V when disconnecting positive terminal from terminal ② and about 0V to battery voltage 8 ± 2 seconds after disconnecting positive terminal from terminal ②, controller is in good condition.
If not replace.

REAR FOG LIGHT (If equipped)

WIRING CIRCUIT




78E00-8-9-1S

TROUBLE DIAGNOSIS

Trouble	Possible Cause	Correction
Lights do not light.	<ul style="list-style-type: none"> • Main fuse and/or fuses blown • Light relay faulty • Lighting switch faulty • Wiring or grounding faulty 	Replace main fuse and/or fuses to check for short. Replace light relay Check switch. Repair as necessary.

78E00-9-4-2S



INSPECTION

Use a circuit tester to check rear fog light switch for continuity. Hold switch button (ON or OFF) pushed during checking switch according to left figure.

WIRING DIAGRAM



CONTENTS

ELECTRONIC FUEL INJECTION SYSTEM	1
4A/T CONTROL SYSTEM	2
BACK-UP LIGHT (M/T)	2
BACK-UP LIGHT (A/T)	2
DATA LINK CONNECTOR (DLC)/DIAGNOSIS CONNECTOR	2
DAYTIME RUNNING LIGHT & HEAD LIGHT CLEANER SYSTEM (IF EQUIPPED)	2
REAR WIPER AND WASHER (IF EQUIPPED)	3
REAR FOG LIGHT	3

NOTE:


For the descriptions not found in this section, refer to the same section of the Service Manual mentioned in the FOREWORD of this manual.

WIRING DIAGRAM



NOTE: #1 FOR OTHER THAN GERMAN OR ITALIAN SPEC #3 VEHICLE WITHOUT IMMOBILIZER #5 VEHICLE WITHOUT DRL CONTROLLER #7 RIGHT HAND STEERING VEHICLE
#2 FOR GERMAN OR ITALIAN SPEC #4 VEHICLE WITH IMMOBILIZER #6 VEHICLE WITH DRL CONTROLLER

ELECTRONIC FUEL INJECTION SYSTEM




4 A/T CONTROL SYSTEM

NOTE: #1 FOR OTHER THAN GERMAN OR ITALIAN SPEC #2 FOR GERMAN OR ITALIAN SPEC #3 VEHICLE WITHOUT IMMOBILIZER #4 VEHICLE WITH IMMOBILIZER #5 VEHICLE WITHOUT DRL CONTROLLER #6 VEHICLE WITH DRL CONTROLLER #7 RIGHT HAND STEERING VEHICLE


BACK-UP LIGHT <M/T>

BACK-UP LIGHT <A/T>




DATA LINK CONNECTOR (DLC) /DIAGNOSIS CONNECTOR


DAYTIME RUNNING LIGHT & HEAD LIGHT CLEANER SYSTEM (IF EQUIPPED)



REAR WIPER AND WASHER<IF EQUIPPED>



REAR FOG LIGHT



NOTE: #1 FOR OTHER THAN GERMAN OR ITALIAN SPEC #3 VEHICLE WITHOUT IMMOBILIZER #5 VEHICLE WITHOUT DRL CONTROLLER #7 RIGHT HAND STEERING VEHICLE
 #2 FOR GERMAN OR ITALIAN SPEC #4 VEHICLE WITH IMMOBILIZER #6 VEHICLE WITH DRL CONTROLLER

Prepared by

SUZUKI MOTOR CORPORATION

Overseas Service Department
1st Ed, April, 1996

2nd Ed, September, 1996

Printed in Japan

Printing: December, 1997

111

SUZUKI MOTOR CORPORATION



* 9 9 5 0 1 - 8 5 F 2 0 - 0 1 E *